Selection tables for connections, housing size, current and cross-section.

Applicant: R. STAHL Schaltgeräte GmbH Am Bahnhof 30 74638 Waldenburg (Württ.) Germany

Electrical Apparatus:	Terminal Box type 8150/1-****-****-****	and
	8150/2-****-****-***	

Example:

cross section/mm ²	current/A	number of conductors	utilization
2,5	16	10 (of 30)	= 33 %
16	50	12 (of 48)	= 25 %
25	63	36 (of 90)	= 40 %
		Total	= <u>98 %</u> < 100 %



Fitting of the terminal box type 8150/1-0200-0200-100

Enclosure size / mm L,B = 200 B,H = 200

$$H,T = 100$$

Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	$/ \text{mm}^2$						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	63															
16	21	42	163													
20	9	24	47													
25		11	26	51									addit	ional		
35			7	20	50								condu	uctors		
50				3	16	41							opti	onal		
63					5	19	68									
80						7	21	76								
100			9 20													
125																
160									7	18						
200		to be s	pecifie	d by						6	15	48				
225		the ma	nufactu	urer						2	9	19				
250		(includ	ing tem	peratu	re rise t	est)					4	11	24			
315												2	7	14		
400														3	9	28
500																5
	108	108	75	36	36	21	18	9	0	0	0	0	0	0	0	0
		max. n	umber	of term	inals de	ependin	g on th	e abov	e menti	oned e	nclosur	e size a	and the	cross s	section	
				resp. r	nax per	missibl	e cond	uctor cr	oss see	ction of	the bui	lt-in ter	minals			

When applying the values of this table simultaneous factors or load factors to IEC 439 may be considered. Mixed equipment with circuits of different cross sections and currents is possible, if the various values of the table are applied proportionally:

Fitting of the terminal box type 8150/1-0200-0300-100

Enclosure size / mm L,B = 300 B,H = 200 H,T = 100

Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	/ mm ²							
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300	
6																	
10	61																
16	21	41	158														
20	8	24	46														
25		11	26	50									addit	tional			
35			7	19	49								condu	uctors			
50				2	16	40							opti	onal			
63					5	18	66										
80																	
100																	
125			9 19 9														
160									6	17							
200		to be s	pecifie	d by						6	15	47					
225		the ma	nufactu	urer						2	8	18					
250		(includ	ing tem	nperatu	re rise t	est)					4	11	23				
315												2	6	14			
400														3	9	28	
500																5	
	140	140	112	66	40	32	22	11	7	0	0	0	0	0	0	0	
		max. n	umber	of term	inals de	ependin	g on th	e abov	e menti	ioned e	nclosur	e size a	and the	cross s	section		
				resp. r	nax per	missibl	e cond	uctor ci	oss se	ction of	the bui	ilt-in ter	minals				



Fitting of the terminal box type 8150/1-0200-0300-150Enclosure size / mm L,B = 300 B,H = 200 H,T = 150

Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	/ mm ²						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	75															
16	26	50	195													
20	10	29	56													
25		14	32	61									addit	ional		
35			9	24	60								condu	uctors		
50				3	19	49							opti	onal		
63					6	23	81									
80						8	25	91								
100							11	24								
125								9	24							
160									8	21						
200		to be s	pecifie	d by						7	18	57				
225		the ma	Inufactu	urer						3	10	22				
250		(includ	ing terr	nperatui	re rise t	est)					5	13	28			
315												2	8	17		
400														3	11	34
500																6
	140	140	112	66	40	32	22	11	7	0	0	0	0	0	0	0
		max. n	umber	of term	inals de	ependir	ig on th	e abov	e menti	oned e	nclosur	e size a	and the	cross s	section	
				resp. n	nax per	missibl	e cond	uctor cr	oss se	ction of	the bui	lt-in ter	minals			

When applying the values of this table simultaneous factors or load factors to IEC 439 may be considered. Mixed equipment with circuits of different cross sections and currents is possible, if the various values of the table are applied proportionally:

Fitting of the terminal box type 8150/1-0200-0300-155Enclosure size / mm L,B = 300 B,H = 200 H,T = 155

Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	$/ \text{mm}^2$						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	77															
16	26	51	198													
20	11	30	57													
25		14	32	62									addit	tional		
35			9	24	61								cond	uctors		
50				3	20	50							opti	onal		
63					6	23	83									
80						9	26	93								
100							11	24								
125								10	25							
160																
200		to be s	specifie	d by						7	19	58				
225		the ma	anufactu	urer						3	11	23				
250		(includ	ling tem	nperatu	re rise t	est)					5	14	29			
315												3	8	17		
400														3	12	35
500																7
	140	140	112	66	40	32	22	11	7	0	0	0	0	0	0	0
		max. n	umber	of term	inals de	ependin	g on th	e abov	e ment	ioned e	nclosur	e size a	and the	cross	section	
				resp. r	nax per	missibl	e cond	uctor cr	oss se	ction of	the bui	It-in ter	minals			



Fitting of the terminal box type 8150/1-0300-0300-100Enclosure size / mm L,B = 300 B,H = 200 H,T = 100

Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	$/ \text{mm}^2$						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	71															
16	24	47	184													
20	10	27	53													
25		13	30	58									addit	tional		
35			9	22	56								cond	uctors		
50				3	18	47							opti	onal		
63					6	21	77									
80						8	24	86								
100							10	22								
125																
160									8	20						
200		to be s	pecifie	d by						7	17	54				
225		the ma	nufactu	urer						2	10	21				
250		(includ	ing tem	peratu	re rise t	est)					5	13	27			
315												2	7	16		
400														3	11	32
500																6
	225	225	180	99	64	52	22	17	12	0	0	0	0	0	0	0
		max. n	umber	of term	inals de	ependin	ig on th	e abov	e menti	oned e	nclosur	e size a	and the	cross s	section	
				resp. r	nax per	missibl	e cond	uctor ci	oss se	ction of	the bui	lt-in ter	minals			

When applying the values of this table simultaneous factors or load factors to IEC 439 may be considered. Mixed equipment with circuits of different cross sections and currents is possible, if the various values of the table are applied proportionally:

Fitting of the terminal box type 8150/1-0300-0300-150Enclosure size / mm L,B = 300 B,H = 300 H,T = 150

Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	$/ \text{mm}^2$						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	85															
16	29	57	221													
20	12	33	64													
25		15	36	70									addit	tional		
35			10	27	68								condu	uctors		
50				4	22	56							opti	onal		
63					7	26	92									
80						10	29	103								
100																
125																
160									9	24						
200		to be s	pecifie	d by						8	21	65				
225		the ma	anufactu	urer						3	12	25				
250		(includ	ling terr	peratu	re rise t	est)					6	15	32			
315												3	9	19		
400														4	13	39
500																7
	225	225	180	99	64	52	22	17	12	0	0	0	0	0	0	0
		max. n	umber	of term	inals de	ependin	g on th	e abov	e menti	ioned e	nclosur	e size a	and the	cross	section	
				resp. r	nax pei	missibl	e cond	uctor cr	oss se	ction of	the bui	lt-in ter	minals			

When applying the values of this table simultaneous factors or load factors to IEC 439 may be considered. Mixed equipment with circuits of different cross sections and currents is possible, if the various values of the table are applied proportionally:



Fitting of the terminal box type 8150/1-0380-0300-155Enclosure size / mm L,B = 300 B,H = 380 H,T = 155

Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	$/ mm^2$						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	91															
16	31	60	236													
20	13	35	68													
25		16	38	74									addit	tional		
35			11	29	72								cond	uctors		
50				4	23	60							opti	onal		
63					8	28	99									
80						10	31	111								
100							13	29								
125								11	29							
160									10	26						
200		to be s	pecifie	d by						9	22	69				
225		the ma	Inufactu	urer						3	13	27				
250		(includ	ing terr	peratu	re rise t	est)					7	16	34			
315												3	10	20		
400														4	14	41
500															2	8
	315	315	232	132	96	68	44	23	15	12	7	0	0	0	0	0
		max. n	umber	of term	inals de	ependin	g on th	e abov	e menti	oned e	nclosur	e size a	and the	cross s	section	
				resp. r	nax pei	missibl	e cond	uctor cr	oss se	ction of	the bu	lt-in ter	minals			

When applying the values of this table simultaneous factors or load factors to IEC 439 may be considered. Mixed equipment with circuits of different cross sections and currents is possible, if the various values of the table are applied proportionally:

Fitting of the terminal box type 8150/1-0380-0300-210Enclosure size / mm L,B = 300 B,H = 380 H,T = 210

Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	$/ \text{mm}^2$						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	107															
16	36	71	276													
20	15	41	80													
25		19	45	87									addit	tional		
35			13	34	85								condu	uctors		
50				5	27	70							opti	onal		
63					9	32	116									
80						12	36	130								
100							15	34								
125								13	34							
160									12	30						
200		to be s	pecifie	d by						11	26	81				
225		the ma	Inufacti	urer						4	15	32				
250		(includ	ing terr	nperatu	re rise t	est)					8	19	40			
315												4	11	24		
400														5	16	48
500															2	9
	315	315	232	132	96	68	44	23	15	12	7	0	0	0	0	0
		max. n	umber	of term	inals de	ependir	ng on th	e abov	e menti	ioned e	nclosur	e size a	and the	cross s	section	
				resp. r	nax per	missibl	e cond	uctor cr	oss se	ction of	the bui	It-in ter	minals			



Fitting of the terminal box type 8150/1-0300-0400-150Enclosure size / mm L,B = 400 B,H = 300 H,T = 150

Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	/ mm ²						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	90															
16	31	60	234													
20	13	35	68													
25		16	38	74									addit	ional		
35			11	29	72								condu	uctors		
50				4	23	59							opti	onal		
63					8	27	98									
80						10	30	110								
100							13	29								
125								11	29							
160									10	26						
200		to be s	pecifie	d by						9	22	69				
225		the ma	nufactu	urer						3	13	27				
250		(includ	ing terr	peratu	re rise t	est)					6	16	34			
315												3	10	20		
400														4	14	41
500															2	9
	360	360	244	138	96	72	44	24	16	12	7	7	0	0	0	0
		max. n	umber	of term	inals de	ependin	g on th	e abov	e menti	oned e	nclosur	e size a	and the	cross s	section	
				resp. r	nax pei	missibl	e cond	uctor cr	oss se	ction of	the bui	lt-in ter	minals			

When applying the values of this table simultaneous factors or load factors to IEC 439 may be considered. Mixed equipment with circuits of different cross sections and currents is possible, if the various values of the table are applied proportionally:

Fitting of the terminal box type 8150/1-0300-0400-210

Enclosure size / mm L,B = 400 B,H = 300 H,T = 210Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	/ mm ²						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	107															
16	37	71	278													
20	15	42	80													
25		20	45	88									addit	tional		
35			13	34	85								cond	uctors		
50				5	28	71							opti	onal		
63					9	33	116									
80						12	34	130								
100							15	34								
125								14	35							
160									12	30						
200		to be s	specifie	d by						11	26	82				
225		the ma	anufacti	urer						4	15	32				
250		(includ	ling terr	nperatu	re rise	test)					8	19	41			
315												4	11	24		
400														5	17	49
500															2	9
	360	360	244	138	96	72	44	24	16	12	7	7	0	0	0	0
		max. n	umber	of term	inals de	ependir	ng on th	e abov	e menti	ioned e	nclosu	e size a	and the	cross	section	-
				resp. r	nax pe	rmissib	le cond	uctor ci	ross se	ction of	the bu	ilt-in ter	minals			



Fitting of the terminal box type 8150/1-0300-0400-215Enclosure size / mm L,B = 400 B,H = 300 H,T = 215

Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	/ mm ²						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	109															
16	37	72	281													
20	15	42	81													
25		20	46	89									addit	ional		
35			13	35	86								condu	uctors		
50				5	28	71							opti	onal		
63					9	33	118									
80																
100		12 37 132 16 35 10														
125		16 35 16 16 14 35 14 14														
160									12	31						
200		to be s	pecifie	d by						11	27	83				
225		the ma	nufactu	urer						4	15	32				
250		(includ	ing terr	nperatu	re rise t	est)					8	20	41			
315												4	20	41		
400														4	12	24
500															2	9
	360	360	244	138	96	72	44	24	16	12	7	7	0	0	0	0
		max. n	umber	of term	inals de	ependin	g on th	e abov	e menti	oned e	nclosur	e size a	and the	cross s	section	
				resp. r	nax per	missibl	e cond	uctor cr	oss see	ction of	the bui	lt-in ter	minals			

When applying the values of this table simultaneous factors or load factors to IEC 439 may be considered. Mixed equipment with circuits of different cross sections and currents is possible, if the various values of the table are applied proportionally:

Fitting of the terminal box type 8150/1-0380-0380-210Enclosure size / mm L,B = 380 B,H = 380 H,T = 210

Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	/ mm ²						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	114															
16	39	76	294													
20	16	44	85													
25		21	48	93									addit	ional		
35			14	36	90								condu	uctors		
50	5 29 75 optional 10 35 123 13 38 138															
63	10 35 123 123 110 35 123 123 123 12 13 38 138 138 13 16 36 130 130															
80	10 35 123															
100							16	36								
125	16 36 14 37															
160									12	32						
200		to be s	pecifie	d by						11	28	87				
225		the ma	Inufactu	urer						4	16	34				
250		(includ	ing terr	peratu	re rise t	est)					8	21	43			
315												4	12	26		
400														5	18	52
500															2	10
	406	406	290	172	126	68	56	23	15	15	9	0	0	0	0	0
		max. n	umber	of term	inals de	ependin	ig on th	e abov	e menti	oned e	nclosur	e size a	and the	cross s	section	
				resp. r	nax per	missibl	e cond	uctor ci	oss se	ction of	the bui	lt-in ter	minals			

When applying the values of this table simultaneous factors or load factors to IEC 439 may be considered. Mixed equipment with circuits of different cross sections and currents is possible, if the various values of the table are applied proportionally:



Fitting of the terminal box type 8150/1-0400-0400-150Enclosure size / mm L,B = 400 B,H = 400 H,T = 150

Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	$/ \text{mm}^2$						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	100															
16	34	66	257													
20	14	38	74													
25		18	42	81									addit	ional		
35			12	32	79								condu	uctors		
50				4	26	65							opti	onal		
63					8	30	108									
80		11 34 121 14 32 14														
100		11 34 121 14 32 13 32														
125		14 32 13 32														
160									11	28						
200		to be s	pecifie	d by						10	24	76				
225		the ma	Inufactu	urer						3	14	30				
250		(includ	ing terr	peratu	re rise t	est)					7	18	38			
315												3	11	22		
400														5	15	45
500															2	9
	488	488	305	184	135	72	60	24	16	16	10	10	0	0	0	0
		max. n	umber	of term	inals de	ependin	g on th	e abov	e menti	oned e	nclosur	e size a	and the	cross s	section	
				resp. r	nax per	missibl	e cond	uctor cr	oss se	ction of	the bui	lt-in ter	minals			



Fitting of the terminal box type 8150/1-0400-0400-210Enclosure size / mm L,B = 400 B,H = 400 H,T = 210

> Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	$/\mathrm{mm}^2$						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	117															
16	40	77	302													
20	16	45	87													
25		21	49	95									addit	ional		
35			14	37	93								cond	uctors		
50	50 5 30 77 optional 63 10 35 126 Image: state of the stat															
63	63 10 35 126															
80						13	39	142								
100							17	37								
125								15	38							
160									13	33						
200		to be s	pecifie	d by						12	29	89				
225		the ma	nufactu	urer						4	16	35				
250		(includ	ing terr	nperatu	re rise t	est)					8	21	44			
315												4	13	26		
400														6	18	53
500															2	10
	488	488	305	184	135	72	60	24	16	16	10	10	0	0	0	0
		max. n	umber	of term	inals de	ependin	ig on th	e abov	e menti	oned e	nclosur	e size a	and the	cross s	section	
				resp. r	nax per	missibl	e cond	uctor cr	oss se	ction of	the bui	lt-in ter	minals			

When applying the values of this table simultaneous factors or load factors to IEC 439 may be considered. Mixed equipment with circuits of different cross sections and currents is possible, if the various values of the table are applied proportionally:

Fitting of the terminal box type 8150/1-0400-0400-215Enclosure size / mm L,B = 400 B,H = 400 H,T = 215

Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current	1t cross section / mm ² 1,5 2,5 4 6 10 16 25 35 50 70 95 120 150 185 240 300 118 1															
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	118															
16	40	78	305													
20	17	46	88													
25		22	50	96									addit	tional		
35			14	38	94								condu	uctors		
50				5	30	78							opti	onal		
63					10	36	128									
80						14	40	143								
100							17	38								
125								15	38							
160									13	34						
200		to be s	specifie	d by						12	29	90				
225		the ma	anufactu	urer						4	17	35				
250		(includ	ling tem	nperatu	re rise t	est)					9	21	45			
315												4	13	29		
400														6	18	53
500															2	10
	488	488	305	184	135	72	60	24	16	16	10	10	0	0	0	0
		max. n	umber	of term	inals de	ependir	ng on th	e abov	e ment	ioned e	nclosu	re size a	and the	cross	section	-
				resp. r	nax per	missibl	e cond	uctor ci	ross se	ction of	the bu	ilt-in ter	minals			



Fitting of the terminal box type 8150/1-0360-0550-230Enclosure size / mm L,B = 550 B,H = 360 H,T = 230

> Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	/ mm ²						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	125															
16	43	83	322													
20	17	48	93													
25		23	53	102									addi	tional		
35			15	40	99								cond	uctors		
50	6 32 82 optional 11 38 135															
63					11	38	135									
80						14	42	151								
100							18	40								
125								16	40							
160									14	35						
200		to be s	pecifie	d by						12	31	95				
225		the ma	anufactu	urer						4	17	37				
250		(includ	ling terr	nperatu	re rise t	test)					9	23	47			
315												4	13	28		
400														6	19	56
500															2	11
	605	605	385	205	160	100	84	42	23	23	9	9	7	7	7	7
		max. n	umber	of term resp. r	inals de nax pei	ependir rmissibl	ig on th e cond	ie abov uctor ci	e menti ross se	ioned e ction of	nclosur the bu	e size a ilt-in ter	and the minals	cross s	section	

When applying the values of this table simultaneous factors or load factors to IEC 439 may be considered. Mixed equipment with circuits of different cross sections and currents is possible, if the various values of the table are applied proportionally:

Fitting of the terminal box type 8150/1-0380-0600-210Enclosure size / mm L,B = 600 B,H = 380 H,T = 210

> Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	$/ \text{mm}^2$						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	123															
16	42	82	318													
20	17	48	92													
25		22	52	100									addit	tional		
35			15	39	98								condu	uctors		
50				5	32	81							opti	onal		
63					10	37	133									
80						14	42	149								
100																
125								16	40							
160									13	35						
200		to be s	specifie	d by						12	30	94				
225		the ma	anufactu	urer						4	17	37				
250		(includ	ling terr	nperatu	re rise t	est)					9	22	47			
315												4	13	28		
400														6	19	56
500															2	11
	696	696	475	284	207	136	92	46	30	25	16	9	7	7	7	7
		max. n	umber	of term	inals de	ependir	ng on th	ie abov	e menti	ioned e	nclosu	e size a	and the	cross :	section	-
				resp. r	nax pe	missibl	le cond	uctor ci	oss se	ction of	the bu	ilt-in ter	minals			



Fitting of the terminal box type 8150/1-0400-0600-150Enclosure size / mm L,B = 600 B,H = 400 H,T = 150

Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	$/ \mathrm{mm}^2$						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	109															
16	37	72	281													
20	15	42	81													
25		20	46	89									addit	tional		
35			13	35	86								cond	uctors		
50				5	28	71							opti	onal		
63					9	33	118									
80			12 37 132 16 35 100													
100																
125		16 35 14 35														
160									12	31						
200		to be s	pecifie	d by						11	27	83				
225		the ma	nufactu	urer						4	15	32				
250		(includ	ing terr	nperatu	re rise t	est)					8	20	41			
315												4	12	24		
400														5	17	49
500															2	9
	760	760	488	284	207	144	92	48	32	25	16	16	8	8	8	8
		max. n	umber	of term	inals de	ependin	g on th	e abov	e menti	oned e	nclosur	e size a	and the	cross s	section	
				resp. r	nax per	missibl	e cond	uctor cr	oss se	ction of	the bui	ilt-in ter	minals			

When applying the values of this table simultaneous factors or load factors to IEC 439 may be considered. Mixed equipment with circuits of different cross sections and currents is possible, if the various values of the table are applied proportionally:

Fitting of the terminal box type 8150/1-0400-0600-210Enclosure size / mm L,B = 600 B,H = 400 H,T = 210

										. 2						
current	_	_	_	_		_		cross	section	/ mm²		_		_		_
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	126															
16	43	83	325													
20	18	49	94													
25		23	53	103									addit	tional		
35			15	40	100								cond	uctors		
50				6	32	83							opti	onal		
63					11	38	136									
80						14	42	152								
100		14 42 152 18 40 10														
125							2	16	41							
160									14	36						
200		to be s	specifie	d by						13	31	96				
225		the ma	anufacti	urer						5	18	37				
250		(includ	ling terr	nperatu	re rise t	est)					9	23	48			
315												4	14	28		
400														6	19	57
500															2	11
	760	760	488	284	207	144	92	48	32	25	16	16	8	8	8	8
		max. n	umber	of term	inals de	pendir	ng on th	ie abov	e menti	ioned e	nclosu	re size a	and the	cross	section	-
				resp. r	nax pei	missibl	e cond	uctor c	ross se	ction of	the bu	ilt-in ter	minals			

Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.



Fitting of the terminal box type 8150/1-0600-0400-210Enclosure size / mm L,B = 400 B,H = 600 H,T = 210

> Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	$/ \text{mm}^2$						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	126															
16	43	83	325													
20	18	49	94													
25		23	53	103									addi	tional		
35			15	40	100								cond	uctors		
50	6 32 83 optional 11 38 136															
63					11	38	136									
80						14	42	152								
100							18	40								
125							2	16	41							
160									14	36						
200		to be s	pecifie	d by						13	31	96				
225		the ma	anufactu	urer						5	18	37				
250		(includ	ling terr	nperatu	re rise t	est)					9	23	48			
315												4	14	28		
400														6	19	57
500															2	11
	760	760	488	284	207	144	92	48	32	25	16	16	8	8	8	8
		max. n	umber	of term	inals de	ependin	ig on th	e abov	e menti	ioned e	nclosur	e size a	and the	cross s	section	
				resp. r	nax per	missibl	e cond	uctor ci	oss se	ction of	the bui	It-in ter	minals			

When applying the values of this table simultaneous factors or load factors to IEC 439 may be considered. Mixed equipment with circuits of different cross sections and currents is possible, if the various values of the table are applied proportionally:

Fitting of the terminal box type $\ 8150/1\mathchar`-0400\mathchar`-0600\mathchar`-215$ Enclosure size / mm $\ L,B=600$ $\ B,H=400$ $\ H,T=215$

Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	/ mm ²						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	127															
16	43	84	328													
20	18	49	95													
25		23	54	104									addi	tional		
35			16	40	101								cond	uctors		
50				6	33	83							opti	onal		
63					11	39	138									
80						15	43	154								
100							18	40								
125							2	16	41							
160									14	36						
200		to be s	specifie	d by						13	31	97				
225		the ma	anufacti	urer						5	18	38				
250		(includ	ling terr	nperatu	re rise t	test)					9	23	48			
315												5	14	29		
400														6	20	58
500															2	11
	760	760	488	284	207	144	92	48	32	25	16	16	8	8	8	8
		max. n	umber	of term	inals de	ependir	ng on th	e abov	e menti	ioned e	nclosu	e size a	and the	cross	section	-
				resp. r	nax pei	missibl	le cond	uctor ci	oss se	ction of	the bu	ilt-in ter	minals			



Fitting of the terminal box type 8150/1-0360-0750-230Enclosure size / mm L,B = 750 B,H = 360 H,T = 230

> Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	$/ \text{mm}^2$						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	127															
16	43	84	328													
20	18	49	95													
25		23	54	104									addi	tional		
35			16	41	101								cond	uctors		
50	6 33 84 optional 11 39 138															
63					11	39	138									
80						15	43	154								
100							18	41								
125							2	16	41							
160									14	36						
200		to be s	specifie	d by						13	31	97				
225		the ma	anufacti	urer						5	18	38				
250		(includ	ling terr	nperatu	re rise t	test)					9	23	48			
315												5	14	29		
400														6	20	58
500															2	11
	840	840	550	328	240	160	118	63	32	32	9	9	7	7	7	7
		max. n	umber	of term resp. r	inals de nax pei	ependir rmissibl	ig on th e cond	ie abov uctor ci	e menti ross se	ioned e ction of	nclosur the bu	e size a ilt-in ter	and the minals	cross :	section	

When applying the values of this table simultaneous factors or load factors to IEC 439 may be considered. Mixed equipment with circuits of different cross sections and currents is possible, if the various values of the table are applied proportionally:

Fitting of the terminal box type 8150/1-0360-0900-230Enclosure size / mm L,B = 900 B,H = 360 H,T = 230

> Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	/ mm ²						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	127															
16	44	85	329													
20	18	49	95													
25		23	54	104									addit	tional		
35			16	41	101								condu	uctors		
50				6	33	84							opti	onal		
63					11	39	138									
80		15 43 155 18 41 1														
100		15 43 155 18 41 10														
125		18 41 18 41 18<														
160									14	36						
200		to be s	pecifie	d by						13	31	97				
225		the ma	nufacti	urer						5	18	38				
250		(includ	ing terr	nperatu	re rise t	test)					9	23	48			
315												5	14	29		
400														6	20	58
500															2	11
	1008	1008	648	369	280	192	142	84	42	39	18	18	14	14	7	7
		max. n	umber	of term	inals de	ependir	ng on th	ie abov	e ment	ioned e	nclosu	e size a	and the	cross	section	
				resp. r	nax pe	rmissib	le cond	uctor ci	ross se	ction of	the bu	ilt-in ter	minals			



Fitting of the terminal box type 8150/1-0600-0600-150Enclosure size / mm L,B = 600 B,H = 600 H,T = 150

> Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	$/ \text{mm}^2$						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	128															
16	44	85	331													
20	18	50	96													
25		23	54	105									addit	tional		
35			16	41	102								cond	uctors		
50				6	33	84							opti	onal		
63					11	39	139									
80						15	43	155								
100							18	41								
125							2	16	41							
160									14	36						
200		to be s	pecifie	d by						13	31	98				
225		the ma	nufactu	urer						5	18	38				
250		(includ	ing tem	nperatu	re rise t	est)					9	23	48			
315												5	14	29		
400														6	20	58
500															3	13
	1140	1140	760	426	276	220	138	74	50	25	16	16	12	12	12	12
		max. n	umber	of term	inals de	ependin	g on th	e abov	e menti	oned e	nclosur	e size a	and the	cross s	section	
				resp. r	nax per	missibl	e cond	uctor cr	oss se	ction of	the bui	lt-in ter	minals			

When applying the values of this table simultaneous factors or load factors to IEC 439 may be considered. Mixed equipment with circuits of different cross sections and currents is possible, if the various values of the table are applied proportionally:

Fitting of the terminal box type 8150/1-0600-0600-210Enclosure size / mm L,B = 600 B,H = 600 H,T = 210

Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current	1,5 2,5 4 6 10 16 25 35 50 70 95 120 150 185 240 300 145															
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	145															
16	50	97	375													
20	20	56	109													
25		27	62	119									addit	tional		
35			18	46	115								condu	uctors		
50				6	37	95							opti	onal		
63					12	44	157									
80						17	49	176								
100							21	46								
125							2	19	47							
160									16	41						
200		to be s	pecifie	d by						15	36	111				
225		the ma	nufacti	urer						5	20	43				
250		(includ	ing terr	nperatu	re rise t	est)					11	26	55			
315												5	16	33		
400														7	22	66
500															3	13
	1140	1140	760	426	276	220	138	74	50	25	16	16	12	12	12	12
		max. n	umber	of term	inals de	ependir	ng on th	e abov	e menti	ioned e	nclosu	e size a	and the	cross	section	
				resp. r	nax pei	missibl	e cond	uctor ci	oss se	ction of	the bu	ilt-in ter	minals			



Fitting of the terminal box type 8150/1-0600-0600-215Enclosure size / mm L,B = 600 B,H = 600 H,T = 215

> Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	$/ \text{mm}^2$						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	147															
16	50	97	379													
20	21	57	110													
25		27	62	120									addit	tional		
35			18	47	116								cond	uctors		
50	7 38 96 optional 13 45 159															
63					13	45	159									
80						17	50	178								
100							21	47								
125							2	19	47							
160									16	42						
200		to be s	pecifie	d by						15	36	112				
225		the ma	nufactu	urer						5	21	44				
250		(includ	ing terr	peratu	re rise t	est)					11	27	56			
315												5	16	33		
400														7	23	66
500															3	13
	1140	1140	760	426	276	220	138	74	50	25	16	16	12	12	12	12
		max. n	umber	of term	inals de	ependin	ig on th	e abov	e menti	ioned e	nclosur	e size a	and the	cross s	section	
				resp. i	пах рег	11155101	e cona		055 56		uie bu	int-int ter	minals			

When applying the values of this table simultaneous factors or load factors to IEC 439 may be considered. Mixed equipment with circuits of different cross sections and currents is possible, if the various values of the table are applied proportionally:

Fitting of the terminal box type 8150/1-0480-0787-230Enclosure size / mm L,B = 787 B,H = 480 H,T = 230

> Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	$/ \text{mm}^2$						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	146															
16	50	97	378													
20	21	57	109													
25		27	62	119									addi	ional		
35			18	47	116								cond	uctors		
50				7	38	96							opti	onal		
63					13	45	158									
80						17	49	177								
100							21	47								
125							2	19	47							
160									16	42						
200		to be s	pecifie	d by						15	36	111				
225		the ma	anufacti	urer						5	21	44				
250		(includ	ling terr	nperatu	re rise t	test)					11	26	55			
315												5	16	33		
400														7	23	66
500															3	13
	1200	1200	825	470	324	222	144	98	40	40	24	21	16	16	16	16
		max. n	umber	of term	inals de	ependir	ng on th	e abov	e menti	ioned e	nclosu	re size a	and the	cross :	section	
				resp. r	nax pei	rmissib	le cond	uctor ci	ross se	ction of	the bu	ilt-in ter	minals			



Fitting of the terminal box type 8150/1-0360-1100-230 Enclosure size / mm L,B = 1100B,H = 360

H,T = 230

Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current							cro	oss sec	tion / m	m ²						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	127															
16	43	85	329													
20	18	49	95													
25		23	54	104									addit	ional		
35			16	41	101								condu	uctors		
50				6	33	84							opti	onal		
63					11	39	138									
80						15	43	154								
100							18	41								
125							2	16	41							
160									14	36						
200		to be s	pecifie	d by						13	31	97				
225		the ma	anufactu	urer						5	18	38				
250		(includ	ing terr	peratu	re rise t	est)					9	23	48			
315												5	14	29		
400														6	20	58
500															2	11
	1246	1246	810	492	320	224	174	105	48	48	18	18	14	14	14	14
		max. n	umber	of term	inals de	ependin	ig on th	e abov	e menti	ioned e	nclosu	e size a	and the	cross :	section	
				resp. r	nax pei	missibl	e cond	uctor cr	oss se	ction of	the bu	ilt-in ter	minals			

When applying the values of this table simultaneous factors or load factors to IEC 439 may be considered. Mixed equipment with circuits of different cross sections and currents is possible, if the various values of the table are applied proportionally:

Fitting of the terminal box type 8150/1-0600-0760-210 Enclosure size / mm L,B = 760 B,H = 600H,T = 210

Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	$/ \text{mm}^2$						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	154															
16	53	103	399													
20	22	60	116													
25		28	65	126									addi	tional		
35			19	49	123								cond	uctors		
50				7	40	101							opti	onal		
63					13	47	167									
80						18	52	187								
100							22	49								
125							2	20	50							
160									17	44						
200		to be s	specifie	d by						16	38	118				
225		the ma	inufacti	urer						6	22	46				
250		(includ	ling tem	peratu	re rise t	est)					11	28	58			
315												6	17	35		
400														7	24	70
500															3	14
	1452	1452	968	568	414	284	184	111	66	50	32	20	16	16	16	16
		max. n	umber	of term	inals de	ependin	ig on th	e abov	e menti	ioned e	nclosu	e size a	and the	cross :	section	
				resp. r	nax per	missibl	e cond	uctor cr	oss se	ction of	the bu	ilt-in ter	minals			



Fitting of the terminal box type 8150/1-0360-1300-230Enclosure size / mm L,B = 1300 B,H = 360 H,T = 230

> Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	$/ \text{mm}^2$						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	127															
16	43	84	328													
20	18	49	95													
25		23	54	104									addit	ional		
35			16	40	101								condu	uctors		
50				6	33	83							opti	onal		
63					11	39	137									
80		11 33 107 15 43 154 18 40 10														
100							18	40								
125							2	16	41							
160									14	36						
200										13	31	97				
225		to be s	pecifie	d by						5	18	38				
250		the ma	nufactu	urer							9	23	48			
315		(includ	ing terr	peratu	re rise t	est)						5	14	29		
400														6	20	57
500															2	11
	1477	1477	972	574	400	256	206	126	57	57	27	27	21	14	14	14
		max. n	umber	of term	inals de	ependin	ig on th	e abov	e menti	oned e	nclosur	e size a	and the	cross s	section	
				resp. r	nax per	missibl	e cond	uctor cr	oss se	ction of	the bui	lt-in ter	minals			

When applying the values of this table simultaneous factors or load factors to IEC 439 may be considered. Mixed equipment with circuits of different cross sections and currents is possible, if the various values of the table are applied proportionally:

Fitting of the terminal box type 8150/1-0787-0600-150

Enclosure size / mm L,B = 600 B,H = 787 H,T = 150 Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor.

Bridges and earthing conductors are not counted.

current								cross	section	/ mm ²						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	138															
16	47	92	358													
20	19	54	104													
25		25	59	113									addit	ional		
35			17	44	110								cond	uctors		
50				6	36	91							opti	onal		
63					12	42	150									
80						16	47	168								
100							20	44								
125							2	18	45							
160									15	39						
200		to be s	specifie	d by						14	34	105				
225		the ma	anufacti	urer						5	19	41				
250		(includ	ling terr	nperatu	re rise t	est)					10	25	52			
315												5	15	31		
400														7	21	63
500															3	12
	1520	1520	1045	568	414	296	186	111	68	50	32	21	16	16	16	16
		max. n	umber	of term	inals de	ependir	ig on th	e abov	e menti	ioned e	nclosu	e size a	and the	cross :	section	-
				resp. r	nax per	missibl	e cond	uctor ci	oss se	ction of	the bu	ilt-in ter	minals			



Fitting of the terminal box type 8150/1-0787-0600-210Enclosure size/ mm L,B = 600 B,H = 787 H,T = 210

> Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	$/ \text{mm}^2$						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	155															
16	53	103	401													
20	22	60	116													
25		28	66	127									addi	tional		
35			19	50	123								cond	uctors		
50				7	40	102							opti	onal		
63					13	47	168									
80		18 53 189 18 22 50 1 1														
100							22	50								
125							2	20	50							
160									17	44						
200		to be s	pecifie	d by						16	38	118				
225		the ma	nufactu	urer						6	22	46				
250		(includ	ing terr	peratu	re rise t	est)					11	28	59			
315												6	17	35		
400														8	24	70
500															3	14
	1520	1520	1045	568	414	296	186	111	68	50	32	21	16	16	16	16
		max. n	umber	of term	inals de	ependin	g on th	e abov	e menti	oned e	nclosur	e size a	and the	cross s	section	
				resp. r	nax per	missibl	e cond	uctor cr	oss se	ction of	the bu	It-in ter	minals			

When applying the values of this table simultaneous factors or load factors to IEC 439 may be considered. Mixed equipment with circuits of different cross sections and currents is possible, if the various values of the table are applied proportionally:

Fitting of the terminal box type 8150/1-0600-0800-150Enclosure size / mm L,B = 800 B,H = 600 H,T = 150

> Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current	t							cross	section	/ mm ²						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	139															
16	47	92	359													
20	20	54	104													
25		25	59	113									addi	tional		
35			17	44	110								cond	uctors		
50				6	36	91							opti	onal		
63					12	42	151									
80						16	47	169								
100							20	44								
125							2	18	45							
160									15	40						
200		to be s	specifie	d by						14	34	106				
225		the ma	anufacti	urer						5	15	31				
250		(incluc	ling terr	nperatu	re rise t	test)					10	25	53			
315												5	15	31		
400														7	21	63
500															3	12
	1536	1536	1034	576	414	300	186	111	68	50	32	32	17	17	17	17
		max. n	umber	of term	inals de	ependir	ng on th	ie abov	e ment	ioned e	nclosu	re size a	and the	cross	section	-
				resp. r	max pei	missib	le cond	uctor ci	ross se	ction of	the bu	ilt-in ter	minals			



Fitting of the terminal box type 8150/1-0600-0800-215Enclosure size / mm L,B = 800 B,H = 600 H,T = 215

Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	$/ \text{mm}^2$						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	157															
16	54	105	406													
20	22	61	118													
25		29	67	128									addi	tional		
35			19	50	125								cond	uctors		
50				7	41	103							opti	onal		
63					14	48	171									
80						18	53	191								
100							23	50								
125							2	20	51							
160									17	45						
200		to be s	pecifie	d by						16	39	120				
225		the ma	Inufactu	urer						6	22	47				
250		(includ	ing terr	peratu	re rise t	est)					12	29	60			
315												6	17	36		
400														8	24	71
500															3	14
	1536	1536	1034	576	414	300	186	111	68	50	32	32	17	17	17	17
		max. n	umber	of term	inals de	ependin	g on th	e abov	e menti	oned e	nclosur	e size a	and the	cross s	section	
				resp. r	nax per	missibl	e cond	uctor cr	oss see	ction of	the bui	lt-in ter	minals			

When applying the values of this table simultaneous factors or load factors to IEC 439 may be considered. Mixed equipment with circuits of different cross sections and currents is possible, if the various values of the table are applied proportionally:

Fitting of the terminal box type 8150/1-0760-0760-300Enclosure size / mm L,B = 760 B,H = 760 H,T = 300

> Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	$/ \text{mm}^2$						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	194															
16	66	129	501													
20	27	75	145													
25		36	82	158									addit	tional		
35			24	62	154								cond	uctors		
50				9	50	127							opti	onal		
63					17	59	210									
80						23	66	235								
100							28	62								
125							3	25	63							
160									21	55						
200		to be s	pecifie	d by						20	48	148				
225		the ma	anufactu	urer						7	27	58				
250		(includ	ling terr	nperatu	re rise t	est)					14	35	74			
315												7	21	44		
400														9	30	88
500															4	17
	1815	1815	1210	728	534	355	236	144	66	66	40	20	16	16	16	16
		max. n	umber	of term	inals de	ependir	ng on th	e abov	e menti	ioned e	nclosu	e size a	and the	cross	section	-
				resp. r	nax pei	missibl	e cond	uctor cr	oss se	ction of	the bu	ilt-in ter	minals			



Fitting of the terminal box type 8150/1-0787-0787-210Enclosure size / mm L,B = 787 B,H = 787 H,T = 210

> Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	/ mm²						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	172															
16	59	114	144													
20	24	67	129													
25		32	73	140									addit	tional		
35			21	55	137								cond	uctors		
50				8	44	113							opti	onal		
63					15	52	186									
80						20	58	209								
100							25	55								
125							2	22	56							
160									19	49						
200		to be s	pecifie	d by						17	42	131				
225		the ma	Inufactu	urer						6	24	51				
250		(includ	ing terr	peratu	re rise t	est)					13	31	65			
315												6	19	39		
400														8	27	78
500															3	15
	2016	2016	1386	752	552	370	248	147	68	68	42	21	16	16	16	16
		max. n	umber	of term	inals de	ependin	ig on th	e abov	e menti	oned e	nclosur	e size a	and the	cross s	section	
				resp. r	nax per	missibl	e cond	uctor cr	oss se	ction of	the bui	ilt-in ter	minals			

When applying the values of this table simultaneous factors or load factors to IEC 439 may be considered. Mixed equipment with circuits of different cross sections and currents is possible, if the various values of the table are applied proportionally:

Fitting of the terminal box type 8150/1-0800-0800-150Enclosure size / mm L,B = 800 B,H = 800 H,T = 150

Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross s	ection	in mm ²						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	157															
16	54	104	405													
20	22	61	117													
25		29	66	128									addit	tional		
35			19	50	124								condu	uctors		
50				7	40	103							opti	onal		
63					13	48	170									
80						18	53	190								
100							23	50								
125							2	20	51							
160									17	45						
200		to be s	pecifie	d by						16	39	119				
225		the ma	nufactu	urer						6	22	47				
250		(includ	ling terr	nperatu	re rise t	est)					12	28	59			
315												6	17	35		
400														8	24	71
500															3	14
	2048	2048	1408	768	558	375	248	150	68	68	42	42	17	17	17	17
		max. n	umber	of term	inals de	ependin	ig on th	e abov	e menti	ioned e	nclosu	e size a	and the	cross s	section	·
				resp. r	nax per	missibl	e cond	uctor cr	oss se	ction of	the bu	ilt-in ter	minals			



Fitting of the terminal box type 8150/1-0800-0800-215Enclosure size / mm L,B = 800 B,H = 800 H,T = 215

Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	$/\rm mm^2$						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	175															
16	60	116	453													
20	25	68	131													
25		32	74	143									addit	ional		
35			22	56	139								condu	uctors		
50				8	45	115							opti	onal		
63					15	53	190									
80			20 59 213													
100			25 56													
125							2	22	57							
160									19	50						
200		to be s	pecifie	d by						18	43	134				
225		the ma	Inufacti	urer						6	25	52				
250		(includ	ing terr	peratu	re rise t	est)					13	32	66			
315												6	19	40		
400														9	27	79
500															4	16
	2048	2048	1408	768	558	375	248	150	68	68	42	42	17	17	17	17
		max. n	umber	of term	inals de	ependin	g on th	e abov	e menti	oned e	nclosur	e size a	and the	cross s	section	
				resp. r	nax per	missibl	e cond	uctor cr	oss se	ction of	the bui	lt-in ter	minals			

When applying the values of this table simultaneous factors or load factors to IEC 439 may be considered. Mixed equipment with circuits of different cross sections and currents is possible, if the various values of the table are applied proportionally:

Fitting of the terminal box type 8150/1-0800-1000-150Enclosure size / mm L,B = 1000 B,H = 800 H,T = 150

> Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	$/ \text{mm}^2$						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	168															
16	58	112	435													
20	24	65	126													
25		31	71	138									addit	tional		
35			21	54	134								cond	uctors		
50				8	44	111							opti	onal		
63					15	51	182									
80						20	57	204								
100							24	54								
125							2	22	54							
160									19	48						
200		to be s	pecifie	d by						17	41	128				
225		the ma	nufactu	urer						6	24	50				
250		(includ	ing tem	peratu	re rise t	est)	_				12	31	64			
315												6	18	38		
400														8	26	76
500															3	15
	2576	2576	1792	968	744	470	372	200	102	102	54	54	34	34	34	34
		max. n	umber	of term	inals de	ependir	ng on th	e abov	e menti	ioned e	nclosu	e size a	and the	cross s	section	
				resp. r	nax pei	missibl	e cond	uctor cr	oss se	ction of	the bu	ilt-in ter	minals			



Fitting of the terminal box type 8150/1-0800-1000-300Enclosure size / mm L,B = 1000 B,H = 800 H,T = 300

> Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	$/ \text{mm}^2$						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	211															
16	72	40	545													
20	30	82	158													
25		39	90	172									addit	tional		
35			26	67	168								cond	uctors		
50				10	55	139							opti	onal		
63					18	64	229									
80						25	71	256								
100							31	67								
125							2	27	68							
160									23	60						
200		to be s	pecifie	d by						21	52	161				
225		the ma	nufactu	urer						8	30	63				
250		(includ	ing tem	peratu	re rise t	est)					16	38	80			
315												8	23	48		
400														10	33	96
500															4	19
	2576	2576	1792	968	744	470	372	200	102	102	54	54	34	34	34	34
		max. n	umber	of term	inals de	ependin	ng on th	e abov	e menti	oned e	nclosui	e size a	and the	cross s	section	
				resp. r	nax per	missibl	e cond	uctor cr	oss se	ction of	the bu	ilt-in ter	minals			

When applying the values of this table simultaneous factors or load factors to IEC 439 may be considered. Mixed equipment with circuits of different cross sections and currents is possible, if the various values of the table are applied proportionally:

Fitting of the terminal box type 8150/1-0800-1200-300Enclosure size / mm L,B = 1200 B,H = 800 H,T = 300

> Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current	:							cross	section	$/ \mathrm{mm}^2$						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	218															
16	75	145	563													
20	31	85	163													
25		40	93	178									addit	tional		
35			27	70	173								condu	uctors		
50				10	56	143							opti	onal		
63					19	67	236									
80						25	74	265								
100							32	70								
125							3	28	71							
160									24	62						
200		to be s	pecifie	d by						22	54	166				
225		the ma	anufacti	urer						8	31	65				
250		(includ	ling terr	nperatu	re rise t	iest)					16	40	83			
315												8	24	49		
400														11	34	99
500															5	19
	3200	3200	2176	1248	852	600	434	250	136	103	66	66	34	34	34	34
		max. n	umber	of term	inals de	ependir	ng on th	ie abov	e menti	ioned e	nclosu	re size a	and the	cross	section	
				resp. r	nax per	missibl	e cond	uctor ci	oss se	ction of	the bu	ilt-in ter	minals			



Fitting of the terminal box type 8150/1-1000-1200-300Enclosure size / mm L,B = 1200 B,H = 1000 H,T = 300

> Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	$/ \mathrm{mm}^2$						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	240															
16	82	160	620													
20	34	93	180													
25		44	102	196									addit	ional		
35			30	77	191								condu	uctors		
50				11	62	158							opti	onal		
63					21	73	260									
80						28	81	291								
100							35	77								
125							3	31	78							
160									27	69						
200										24	59	183				
225		to be s	pecifie	d by						9	34	72				
250		the ma	nufactu	urer							18	44	91			
315		(includ	ling terr	nperatu	re rise t	est)						9	26	54		
400														12	37	109
500		5 21														
	4025 4025 2737 1573 1136 752 570 315 176 159 81 81 50 50 50 50															
		max. n	umber	of term	inals de	ependin	g on th	e abov	e menti	oned e	nclosur	e size a	and the	cross s	section	
				resp. r	nax per	missibl	e cond	uctor cr	oss see	ction of	the bui	lt-in ter	minals			

When applying the values of this table simultaneous factors or load factors to IEC 439 may be considered. Mixed equipment with circuits of different cross sections and currents is possible, if the various values of the table are applied proportionally:

Fitting of the terminal box type 8150/1-0800-1600-300Enclosure size / mm L,B = 1600 B,H = 800 H,T = 300

> Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	/ mm ²						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	225															
16	77	150	582													
20	32	88	169													
25		41	96	184									addi	tional		
35			28	72	179								cond	uctors		
50				10	58	148							opti	onal		
63					20	69	244									
80						26	76	274								
100							33	72								
125							3	29	73							
160									25	64						
200		to be s	specifie	d by						23	56	172				
225		the ma	anufacti	urer						8	32	67				
250		(includ	ling tem	nperatu	re rise t	est)					17	41	86			
315												8	25	51		
400														11	35	102
500															5	20
	4224	4224	2871	1632	1209	765	558	350	170	142	88	88	51	51	51	51
		max. n	umber	of term	inals de	ependir	ng on th	ie abov	e ment	ioned e	nclosu	re size a	and the	cross	section	-
				resp. r	nax per	missib	le cond	uctor ci	ross se	ction of	the bu	ilt-in ter	minals			



Fitting of the terminal box type 8150/1-0116-0176-091Enclosure size / mm L,B = 176,5 B,H = 116,5 H,T = 91

> Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	$/ \text{mm}^2$						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	45															
16	15	30	116													
20	6	17	33													
25		8	19	36									addi	tional		
35			5	14	35								cond	uctors		
50				2	11	29							opti	onal		
63					4	13	48									
80						5	15	54								
100							6	14								
125								5	14							
160									5	12						
200		to be s	pecifie	d by						4	11	34				
225		the ma	nufactu	urer							6	13				
250		(includ	ling tem	nperatu	re rise t	est)					3	8	17			
315													5	10		
400														2	7	20
500																4
	42	42	28	18	10	8	7	0	0	0	0	0	0	0	0	0
		max. n	umber	of term	inals de	ependir	ng on th	e abov	e menti	ioned e	nclosur	e size a	and the	cross s	section	
				resp. r	nax pei	missibl	e cond	uctor ci	oss se	ction of	the bu	ilt-in ter	minals			

When applying the values of this table simultaneous factors or load factors to IEC 439 may be considered. Mixed equipment with circuits of different cross sections and currents is possible, if the various values of the table are applied proportionally:

Fitting of the terminal box type 8150/1-0176-0176-091

Enclosure size / mm L,B = 176,5 B,H = 176,5 H,T = 91

Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor.

Bridges and earthing cond	uctors are not counted
---------------------------	------------------------

current								cross	section	$/ \text{mm}^2$						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	51															
16	17	34	132													
20	7	19	38													
25		9	21	41									addi	tional		
35			6	16	40								cond	uctors		
50				2	13	33							opti	onal		
63					4	15	55									
80						6	17	62								
100							7	16								
125								6	16							
160									5	14						
200		to be s	pecifie	d by						5	12	39				
225		the ma	anufactu	urer						2	7	15				
250		(includ	ing tem	nperatu	re rise t	est)					3	9	19			
315												2	5	11		
400														2	8	23
500																4
	72	72	48	18	17	14	12	0	0	0	0	0	0	0	0	0
		max. n	umber	of term	inals de	ependin	ig on th	e abov	e menti	ioned e	nclosur	e size a	and the	cross s	section	
				resp. r	nax pei	missibl	e cond	uctor cr	oss se	ction of	the bu	It-in ter	minals			



Fitting of the terminal box type 8150/1-0176-0236-091Enclosure size / mm L,B = 236,5 B,H = 176,5 H,T = 91

> Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	$/ \text{mm}^2$							
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300	
6																	
10	54																
16	18	36	140														
20	7	21	40														
25		10	23	44									addit	ional			
35			6	17	43								condu	uctors			
50			2 14 35 optional														
63					4	16	58										
80						6	18	65									
100							7	17									
125								7	17								
160																	
200		to be s	pecifie	d by						5	13	41					
225		the ma	nufactu	urer						2	7	16					
250		(includ	ing terr	peratu	re rise t	est)					4	9	20				
315												2	6	12			
400														2	8	24	
500																4	
	102	102	72	36	25	20	16	9	0	0	0	0	0	0	0	0	
		max. n	umber	of term	inals de	ependin	ig on th	e abov	e menti	oned e	nclosur	e size a	and the	cross s	section		
				resp. r	nax pei	missibl	e cond	uctor cr	oss se	ction of	the bui	lt-in ter	minals				

When applying the values of this table simultaneous factors or load factors to IEC 439 may be considered. Mixed equipment with circuits of different cross sections and currents is possible, if the various values of the table are applied proportionally:

Fitting of the terminal box type 8150/1-0176-0236-150

Enclosure size / mm L,B = 236,5 B,H = 176,5 H,T =150 Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor.

Bridges and earthing conductors are not counted.

current								cross	section	/ mm ²						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	71															
16	24	47	183													
20	10	27	53													
25		13	30	58									addi	ional		
35			8	22	56								cond	uctors		
50				3	18	46							opti	onal		
63					6	21	76									
80						8	24	86								
100							10	22								
125								9	23							
160									8	20						
200		to be s	specifie	d by						7	17	54				
225		the ma	anufacti	urer						2	10	21				
250		(includ	ling terr	nperatu	re rise t	test)					5	13	27			
315												2	7	16		
400														3	11	32
500																6
	102	102	72	36	25	20	16	9	0	0	0	0	0	0	0	0
		max. n	umber	of term	inals de	ependin	ig on th	e abov	e ment	ioned e	nclosu	re size a	and the	cross	section	•
				resp. r	nax pei	rmissibl	e cond	uctor ci	oss se	ction of	the bu	ilt-in ter	minals			



Fitting of the terminal box type 8150/1-0176-0360-091Enclosure size / mm L,B = 360 B,H = 176,5 H,T =91

> Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	$/ \text{mm}^2$						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	56															
16	19	37	146													
20	8	22	42													
25		10	24	46									addit	tional		
35			7	18	45								cond	uctors		
50	50 2 14 37 optional 63 5 17 61 0															
63					5	17	61									
80						6	19	68								
100							8	18								
125								7	18							
160									6	16						
200	o o io io io io i0 to be specified by 5 14 43															
225		the ma	anufactu	urer						2	8	17				
250		(includ	ling terr	peratu	re rise t	test)					4	10	21			
315												2	6	12		
400														2	8	25
500																5
	168	168	110	54	40	32	27	9	0	0	0	0	0	0	0	0
		max. n	umber	of term	inals de	ependin	g on th	e abov	e menti	oned e	nclosur	e size a	and the	cross s	section	
				resp. r	nax per	THISSIDI			055 50		ule bu	int-in ter	minais			لب

When applying the values of this table simultaneous factors or load factors to IEC 439 may be considered. Mixed equipment with circuits of different cross sections and currents is possible, if the various values of the table are applied proportionally:

Fitting of the terminal box type 8150/1-0176-0360-150Enclosure size / mm L,B = 360 B,H = 176,5 H,T =150

Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	$/ mm^2$						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	72															
16	24	48	187													
20	10	28	54													
25		13	30	59									addi	tional		
35			9	23	57								cond	uctors		
50				3	18	47							opti	onal		
63					6	22	78									
80						8	24	88								
100							10	23								
125								9	23							
160									8	20						
200		to be s	specifie	d by						7	18	55				
225		the ma	anufacti	urer						2	10	21				
250		(includ	ling terr	nperatu	re rise t	test)					5	13	27			
315												2	8	16		
400														3	11	33
500																6
	168	168	110	54	40	32	27	9	6	6	0	0	0	0	0	0
		max. n	umber	of term	inals de	ependir	ng on th	e abov	e menti	ioned e	nclosu	re size a	and the	cross	section	
1				resp. r	nax pei	rmissibl	le cond	uctor ci	oss se	ction of	the bu	ilt-in ter	minals			



Fitting of the terminal box type 8150/1-0360-0360-091Enclosure size / mm L,B = 360 B,H = 360 H,T =91

> Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	$/\mathrm{mm}^2$						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	77															
16	26	51	199													
20	11	30	58													
25		14	32	63									addi	tional		
35	9 24 61 conductors 0 3 20 50 optional															
50	3 20 50 optional 6 23 83 1 1															
63					6	23	83									
80						9	26	93								
100							11	24								
125								10	25							
160									8	22						
200	to be specified by 8 19 59															
225		the ma	nufactu	urer						3	11	23				
250		(includ	ing terr	nperatu	re rise t	est)					5	14	29			
315												3	8	17		
400														3	12	35
500																7
	385	385	220	123	80	64	54	21	0	0	0	0	0	0	0	0
		max. n	umber	of term	inals de	ependin	ig on th	e abov	e menti	oned e	nclosur	e size a	and the	cross s	section	
				resp. r	nax per	missibl	e cond	uctor cr	oss se	ction of	the bui	lt-in ter	minals			

When applying the values of this table simultaneous factors or load factors to IEC 439 may be considered. Mixed equipment with circuits of different cross sections and currents is possible, if the various values of the table are applied proportionally:

Fitting of the terminal box type 8150/1-0360-0360-150Enclosure size / mm L,B = 360 B,H = 360 H,T =150

> Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	n mm²						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	94															
16	32	62	243													
20	13	36	70													
25		17	40	77									addit	tional		
35			11	30	74								cond	uctors		
50				4	24	62							opti	onal		
63					8	28	102									
80						11	32	114								
100							13	30								
125								12	30							
160									10	27						
200		to be s	pecifie	d by						9	23	71				
225		the ma	anufacti	urer						3	13	28				
250		(includ	ling tem	nperatu	re rise t	est)					7	17	35			
315												3	10	21		
400														4	14	42
500															2	8
	385	385	220	123	80	64	54	21	15	15	0	0	0	0	0	0
		max. n	umber	of term	inals de	ependir	ig on th	e abov	e menti	ioned e	nclosu	e size a	and the	cross	section	-
				resp. r	nax pei	missibl	e cond	uctor cr	oss se	ction of	the bu	lt-in ter	minals			



Fitting of the terminal box type 8150/1-0360-0360-190Enclosure size / mm L,B = 360 B,H = 360 H,T =190

Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	/ mm ²						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	5															
16	36	70	272													
20	15	41	79													
25		19	45	86									addi	tional		
35			13	33	84								cond	uctors		
50		5 27 69 optional														
63					9	32	114									
80						12	36	128								
100							15	33								
125								13	34							
160									11	30						
200		to be s	specifie	d by						10	26	80				
225		the ma	anufactu	urer						4	15	31				
250		(includ	ling terr	peratu	re rise t	test)					8	19	40			
315												4	11	24		
400														5	16	48
500															2	9
	385	385	220	123	80	64	54	21	15	15	0	0	0	0	0	0
		max. n	umber	of term	inals de	ependir	ig on th	e abov	e ment	ioned e	nclosur	e size a	and the	cross :	section	
				resp. r	nax pei	rmissibl	e cond	uctor ci	ross se	ction of	the bu	ilt-in ter	minals			

When applying the values of this table simultaneous factors or load factors to IEC 439 may be considered. Mixed equipment with circuits of different cross sections and currents is possible, if the various values of the table are applied proportionally:

Fitting of the terminal box type 8150/1-0360-0727-150Enclosure size / mm L,B = 727 B,H = 360 H,T =150

Max. number of conductors depending on cross section and the permissible continuous current: Each incoming conductor and each internal connection wire is counted as a conductor. Bridges and earthing conductors are not counted.

current								cross	section	/ mm ²						
/A	1,5	2,5	4	6	10	16	25	35	50	70	95	120	150	185	240	300
6																
10	105															
16	36	70	272													
20	15	41	79													
25		19	45	86									addit	ional		
35			13	34	84								condu	uctors		
50		5 27 69 optional														
63					9	32	114									
80						12	36	128								
100							15	34								
125								13	34							
160																
200		to be s	pecifie	d by						10	26	80				
225		the ma	nufactu	urer						4	15	31				
250		(includ	ing terr	peratu	re rise t	est)					8	19	40			
315												4	11	24		
400														5	16	48
500															2	9
	812	812	550	287	200	136	114	63	31	31	9	9	7	7	7	7
		max. n	umber	of term	inals de	ependin	ig on th	e abov	e menti	ioned e	nclosur	e size a	and the	cross :	section	
				resp. r	nax pei	missibl	e cond	uctor cr	oss se	ction of	the bui	ilt-in ter	minals			

When applying the values of this table simultaneous factors or load factors to IEC 439 may be considered. Mixed equipment with circuits of different cross sections and currents is possible if the various values of the table are applied proportionally:

