

Product	Device series / class	Status	Can be replaced by	Available	Spare part	Repair	Support
UB03-Z1-RFID-xxxx	Readers	Current Product	-	Yes	Yes	Yes	Yes
UB03-Z2-RFID-xxxx	Readers	Current Product	-	Yes	Yes	Yes	Yes
ET-638-DVI3	KVM	Current Product	-	Yes	Yes	Yes	Yes
ET-698-DVI3	KVM	Current Product	-	Yes	Yes	Yes	Yes
MT-638-DVI3	KVM	Current Product	-	Yes	Yes	Yes	Yes
MT-698-DVI3	KVM	Current Product	-	Yes	Yes	Yes	Yes
ET-538	Thin Client	Current Product	-	Yes	Yes	Yes	Yes
ET-598	Thin Client	Current Product	-	Yes	Yes	Yes	Yes
MT-538	Thin Client	Current Product	-	Yes	Yes	Yes	Yes
MT-598	Thin Client	Current Product	-	Yes	Yes	Yes	Yes
SPSPlusWIN Version 6.xx	Software	Current Product	-	Yes	-	-	Yes
RFID-ADMITTO-USB-MIF-*	Readers	Current Product	-	Yes	Yes	Yes	Yes
ET-208-TX	Operator Interface	Current Product	-	Yes	Yes	Yes	Yes
ET-438-xxxx	Panel PC	Current Product	-	Yes	Yes	Yes	Yes
ET-498-xxxx	Panel PC	Current Product	-	Yes	Yes	Yes	Yes
MT-438-xxxx	Panel PC	Current Product	-	Yes	Yes	Yes	Yes
MT-498-xxxx	Panel PC	Current Product	-	Yes	Yes	Yes	Yes
ET-306-A HW-Rev. 3.xx	Operator Interface	Current Product	-	Yes	Yes	Yes	Yes
ET-316-A HW-Rev. 3.xx	Operator Interface	Current Product	-	Yes	Yes	Yes	Yes
ET-336-A HW-Rev. 3.xx	Operator Interface	Current Product	-	Yes	Yes	Yes	Yes
ET-406-A-xx-BT HW-Rev. 3.xx	Panel PC	Current Product	-	Yes	Yes	Yes	Yes
ET-416-A-xx-BT HW-Rev. 3.xx	Panel PC	Current Product	-	Yes	Yes	Yes	Yes
ET-436-A-xx-BT HW-Rev. 3.xx	Panel PC	Current Product	-	Yes	Yes	Yes	Yes
ET-536-A HW-Rev. 3.xx	Thin Client	Current Product	-	Yes	Yes	Yes	Yes
MT-306-A HW-Rev. 3.xx	Operator Interface	Current Product	-	Yes	Yes	Yes	Yes
MT-316-A HW-Rev. 3.xx	Operator Interface	Current Product	-	Yes	Yes	Yes	Yes
MT-336-A HW-Rev. 3.xx	Operator Interface	Current Product	-	Yes	Yes	Yes	Yes
MT-406-A-xx-BT HW-Rev. 3.xx	Panel PC	Current Product	-	Yes	Yes	Yes	Yes
MT-416-A-xx-BT HW-Rev. 3.xx	Panel PC	Current Product	-	Yes	Yes	Yes	Yes
MT-436-A-xx-BT HW-Rev. 3.xx	Panel PC	Current Product	-	Yes	Yes	Yes	Yes
ET-477-xx-BT	Panel PC	Current Product	-	Yes	Yes	Yes	Yes
ET-487-xx-BT	Panel PC	Current Product	-	Yes	Yes	Yes	Yes
ET-677-DVI3	KVM	Current Product	-	Yes	Yes	Yes	Yes
ET-687-DVI3	KVM	Current Product	-	Yes	Yes	Yes	Yes
IT-477-xx-BT	Panel PC	Current Product	-	Yes	Yes	Yes	Yes
IT-487-xx-BT	Panel PC	Current Product	-	Yes	Yes	Yes	Yes
IT-677-DVI3	KVM	Current Product	-	Yes	Yes	Yes	Yes
IT-687-DVI3	KVM	Current Product	-	Yes	Yes	Yes	Yes
MT-477-xx-BT	Panel PC	Current Product	-	Yes	Yes	Yes	Yes
MT-487-xx-BT	Panel PC	Current Product	-	Yes	Yes	Yes	Yes
MT-536-A HW-Rev. 3.xx	Thin Client	Current Product	-	Yes	Yes	Yes	Yes
MT-677-DVI3	KVM	Current Product	-	Yes	Yes	Yes	Yes
MT-687-DVI3	KVM	Current Product	-	Yes	Yes	Yes	Yes
DSPq-120-24-block	Accessories	Current Product	-	Yes	Yes	Yes	Yes
ReaderBox	Accessories	Current Product	-	Yes	Yes	Yes	Yes
IDM160-ex-b	Readers	Current Product	-	Yes	Yes	Yes	Yes
IDM160-PDF-ex	Readers	Current Product	-	Yes	Yes	Yes	Yes
IDM161-BT-ex	Readers	Current Product	-	Yes	Yes	Yes	Yes
IDM161-PDF-ex	Readers	Current Product	-	Yes	Yes	Yes	Yes
IDM260-ex	Readers	Current Product	-	Yes	Yes	Yes	Yes
IDM261-BT-ex	Readers	Current Product	-	Yes	Yes	Yes	Yes
ET-456-A-xx-BT HW-Rev. 3.xx	Panel PC	Discontinuation in 2019	ET-477-xx-BT	Yes	Yes	Yes	Yes
ET-556-A HW-Rev. 3.xx	Thin Client	Discontinuation in 2019	ET-477-xx-BT	Yes	Yes	Yes	Yes
MT-456-A-xx-BT HW-Rev. 3.xx	Panel PC	Discontinuation in 2019	MT-477-xx-BT	Yes	Yes	Yes	Yes
ET-467-xx-BT	Panel PC	Discontinuation in 2019	ET-477-xx-BT	Yes	Yes	Yes	Yes
ET-667-DVI3	KVM	Discontinuation in 2019	ET-677-xx-DVI3	Yes	Yes	Yes	Yes
IT-467-xx-BT	Panel PC	Discontinuation in 2019	IT-477-xx-BT	Yes	Yes	Yes	Yes
IT-667-DVI3	KVM	Discontinuation in 2019	IT-677-xx-DVI3	Yes	Yes	Yes	Yes
MT-467-xx-BT	Panel PC	Discontinuation in 2019	MT-477-xx-BT	Yes	Yes	Yes	Yes
MT-556-A HW-Rev. 3.xx	Thin Client	Discontinuation in 2019	MT-577-xx-BT	Yes	Yes	Yes	Yes
MT-667-DVI3	KVM	Discontinuation in 2019	MT-677-xx-DVI3	Yes	Yes	Yes	Yes
BCSi-SK-200-RSST	Readers	2014	IDM160/260 + ReaderBox	No	No	Conditional no spare parts	Yes
BCSi-SK-300	Readers	2014	IDM160/260-BT +	No	No	Conditional no spare parts	Yes
ET-567	Thin Client	2018	ET-577-xx-BT	Yes	Yes	Yes	Yes
ET-577	Thin Client	2018	ET-577-xx-BT	Yes	Yes	Yes	Yes
ET-587	Thin Client	2018	ET-587-xx-BT	Yes	Yes	Yes	Yes
IT-567	Thin Client	2018	IT-577-xx-BT	Yes	Yes	Yes	Yes
IT-577	Thin Client	2018	IT-577-xx-BT	Yes	Yes	Yes	Yes
IT-587	Thin Client	2018	IT-587-xx-BT	Yes	Yes	Yes	Yes
MT-567	Thin Client	2018	MT-577-xx-BT	Yes	Yes	Yes	Yes
MT-577	Thin Client	2018	MT-577-xx-BT	Yes	Yes	Yes	Yes
MT-587	Thin Client	2018	MT-587-xx-BT	Yes	Yes	Yes	Yes
RFIDI-RDR-2-MIF-CRYPT/ASC	Readers	2018	UB03-Z1-RFID-xxxx	No	No	Conditional no spare parts	Yes
RFID-RDR-2-MIF-CRYPT/ASC	Readers	2018	UB03-Z2-RFID-xxxx	No	No	Conditional no spare parts	Yes
Oris 100	Readers	2018	-	No	No	Conditional no spare parts	Yes
Oris 300	Readers	2018	-	No	No	Conditional no spare parts	Yes
SK-FB-Cobox	Accessories	2018	-	No	No	Conditional no spare parts	Yes
SPSPlusWIN Version 05.03.05	Software	2017	SPSPlusWIN Version 6.xx	No	-	-	Limited no update
MPI-Box-SSW7-RK512-RS-232	Accessories	2017	-	No	No	Conditional no spare parts	Yes
MPI-Box-SSW7-RK512-RS-422	Accessories	2017	-	No	No	Conditional no spare parts	Yes
9143/10-104-220-xx	Accessories	2017	-	No	End of 2022	End of 2022	End of 2027
9143/10-114-200-xx	Accessories	2017	-	No	End of 2022	End of 2022	End of 2027
9185/11-45-xx	Accessories	2017	-	No	End of 2022	End of 2022	End of 2027
9185/11-46-xx	Accessories	2017	-	No	No	Conditional no spare parts	End of 2027
9185/12-45-xx	Accessories	2017	-	No	End of 2022	End of 2022	End of 2027
9185/12-46-xx	Accessories	2017	-	No	No	Conditional no spare parts	End of 2027
ET-125-B	Operator Interface	2017	ET-208	No	End of 2022	End of 2022	End of 2027
ET-125-B-Rsi	Operator Interface	2017	ET-208 + ReaderBox	No	End of 2022	End of 2022	End of 2027
ET-65-B	Operator Interface	2017	ET-208	No	End of 2022	End of 2022	End of 2027
ET-65-B-RSi	Operator Interface	2017	ET-208 + ReaderBox	No	End of 2022	End of 2022	End of 2027
ET-75-B	Operator Interface	2017	ET-208	No	End of 2022	End of 2022	End of 2027
ET-75-B-RSi	Operator Interface	2017	ET-208 + ReaderBox	No	End of 2022	End of 2022	End of 2027
MT-65	Panel PC	2017	-	No	End of 2022	End of 2022	End of 2027
ET-406-A HW-Rev. 3.xx (N270)	Panel PC	2016	ET-406-A-xx-BT HW-Rev. 3.xx *1	No	End of 2021	End of 2021	End of 2026
ET-416-A HW-Rev. 3.xx (N270)	Panel PC	2016	ET-416-A-xx-BT HW-Rev. 3.xx *1	No	End of 2021	End of 2021	End of 2026
ET-436-A HW-Rev. 3.xx (N270)	Panel PC	2016	ET-436-A-xx-BT HW-Rev. 3.xx *1	No	End of 2021	End of 2021	End of 2026
ET-456-A HW-Rev. 3.xx (N270)	Panel PC	2016	ET-456-A-xx-BT HW-Rev. 3.xx *1	No	End of 2021	End of 2021	End of 2026
ET-467 (N270)	Panel PC	2016	ET-467-xx-BT *1	No	End of 2021	End of 2021	End of 2026
ET-477 (N270)	Panel PC	2016	ET-477-xx-BT *1	No	End of 2021	End of 2021	End of 2026
ET-487 (N270)	Panel PC	2016	ET-487-xx-BT *1	No	End of 2021	End of 2021	End of 2026
IT-467 (N270)	Panel PC	2016	IT-467-xx-BT *1	No	End of 2021	End of 2021	End of 2026
IT-477 (N270)	Panel PC	2016	IT-477-xx-BT *1	No	End of 2021	End of 2021	End of 2026

Product	Device series / class	Status	Can be replaced by	Available	Spare part	Repair	Support
IT-487 (N270)	Panel PC	2016	IT-487-xx-BT *1	No	End of 2021	End of 2021	End of 2026
MT-406-A HW-Rev. 3.xx (N270)	Panel PC	2016	MT-406-A-xx-BT HW-Rev. 3.xx *1	No	End of 2021	End of 2021	End of 2026
MT-416-A HW-Rev. 3.xx (N270)	Panel PC	2016	MT-416-A-xx-BT HW-Rev. 3.xx *1	No	End of 2021	End of 2021	End of 2026
MT-436-A HW-Rev. 3.xx (N270)	Panel PC	2016	MT-436-A-xx-BT HW-Rev. 3.xx *1	No	End of 2021	End of 2021	End of 2026
MT-456-A HW-Rev. 3.xx (N270)	Panel PC	2016	MT-456-A-xx-BT HW-Rev. 3.xx *1	No	End of 2021	End of 2021	End of 2026
MT-467 (N270)	Panel PC	2016	-	No	End of 2021	End of 2021	End of 2026
MT-477 (N270)	Panel PC	2016	-	No	End of 2021	End of 2021	End of 2026
MT-487 (N270)	Panel PC	2016	-	No	End of 2021	End of 2021	End of 2026
SK-KJ1710	Accessories	2016	9721/13-11-14	No	No	Conditional no spare parts	End of 2021
SK-KJ1740	Accessories	2016	9721/13-42-14	No	No	Conditional no spare parts	End of 2021
RealVNC-1-Desktop-Enterprise	Software	2016	siehe Notes *2	No	-	-	Yes
MT-50	Operator Interface	2015	-	No	End of 2020	End of 2020	End of 2025
IDM160-ex	Readers	2015	IDM160-ex-b	No	No	Conditional no spare parts	Yes
IDM160-PDF-ex	Readers	2015	IDM160-PDF-ex-b	No	No	Conditional no spare parts	Yes
IDM160-BT-ex	Readers	2015	IDM161-BT-ex-b	No	No	Conditional no spare parts	Yes
IDM160-BT-PDF-ex	Readers	2015	IDM161-PDF-ex-b	No	No	Conditional no spare parts	Yes
ET-125	Operator Interface	2014	ET-125-B	No	No	Conditional no spare parts	End of 2024
ET-125-A	Operator Interface	2014	ET-125-B	No	No	Conditional no spare parts	End of 2024
ET-75	Operator Interface	2014	ET-75-B	No	No	Conditional no spare parts	End of 2024
ET-457	Panel PC	2013	ET-456-A / ET-467	No	No	Conditional no spare parts	End of 2023
ET-557	Thin Client	2013	ET-556-A / ET-567	No	No	Conditional no spare parts	End of 2023
ET-65	Operator Interface	2013	ET-65-B	No	No	Conditional no spare parts	End of 2024
ET-657	Panel PC	2013	ET-667	No	No	Conditional no spare parts	End of 2023
ET-667-DVI2	KVM	2013	ET-667-DVI3	No	No	Conditional no spare parts	Limited
ET-667-USB	KVM	2013	ET-667-DVI3	No	No	Conditional no spare parts	Limited
ET-677-DVI2	KVM	2013	ET-677-DVI3	No	No	Conditional no spare parts	Limited
ET-687-DVI2	KVM	2013	ET-687-DVI3	No	No	Conditional no spare parts	Limited
IT-457	Panel PC	2013	IT-467	No	No	Conditional no spare parts	End of 2023
IT-557	Thin Client	2013	IT-567	No	No	Conditional no spare parts	End of 2023
IT-657	KVM	2013	IT-667	No	No	Conditional no spare parts	End of 2023
IT-667-DVI2	KVM	2013	IT-667-DVI3	No	No	Conditional no spare parts	Limited
IT-667-USB	KVM	2013	IT-667-DVI3	No	No	Conditional no spare parts	Limited
IT-677-DVI2	KVM	2013	IT-677-DVI3	No	No	Conditional no spare parts	Limited
IT-687-DVI2	KVM	2013	IT-687-DVI3	No	No	Conditional no spare parts	Limited
MCRi-HID-Swipe	Readers	2013	-	No	No	Conditional no spare parts	End of 2023
MT-457	Panel PC	2013	MT-456-A / MT-467	No	No	Conditional no spare parts	End of 2023
MT-557	Thin Client	2013	MT-556-A / MT-567	No	No	Conditional no spare parts	End of 2023
MT-657	KVM	2013	MT-667	No	No	Conditional no spare parts	End of 2023
MT-667-DVI2	KVM	2013	MT-667-DVI3	No	No	Conditional no spare parts	Limited
MT-667-USB	KVM	2013	MT-667-DVI3	No	No	Conditional no spare parts	Limited
MT-677-DVI2	KVM	2013	MT-677-DVI3	No	No	Conditional no spare parts	Limited
MT-687-DVI2	KVM	2013	MT-687-DVI3	No	No	Conditional no spare parts	Limited
ET-306-Fx/Tx HW-Rev. 2.xx	Operator Interface	2012	ET-306-A	No	No	Conditional no spare parts	End of 2022
ET-316-Fx/Tx HW-Rev. 2.xx	Operator Interface	2012	ET-316-A	No	No	Conditional no spare parts	End of 2022
ET-336-Fx/Tx HW-Rev. 2.xx	Operator Interface	2012	ET-336-A	No	No	Conditional no spare parts	End of 2022
ET-406 (ATOM Prozessor)	Panel PC	2012	ET-406-A	No	No	Conditional no spare parts	End of 2022
ET-416 (ATOM Prozessor)	Panel PC	2012	ET-416-A	No	No	Conditional no spare parts	End of 2022
ET-436 (ATOM Prozessor)	Panel PC	2012	ET-436-A	No	No	Conditional no spare parts	End of 2022
ET-456 (ATOM Prozessor)	Panel PC	2012	ET-456-A	No	No	Conditional no spare parts	End of 2022
ET-536-Fx/Tx HW-Rev. 2.xx	Thin Client	2012	ET-536-A	No	No	Conditional no spare parts	End of 2022
ET-556-Fx/Tx HW-Rev. 2.xx	Thin Client	2012	ET-556-A	No	No	Conditional no spare parts	End of 2022
MT-306-Fx/Tx HW-Rev. 2.xx	Operator Interface	2012	MT-306-A	No	No	Conditional no spare parts	End of 2022
MT-316-Fx/Tx HW-Rev. 2.xx	Operator Interface	2012	MT-316-A	No	No	Conditional no spare parts	End of 2022
MT-336-Fx/Tx HW-Rev. 2.xx	Operator Interface	2012	MT-336-A	No	No	Conditional no spare parts	End of 2022
MT-406 (ATOM Prozessor)	Panel PC	2012	MT-406-A	No	No	Conditional no spare parts	End of 2022
MT-416 (ATOM Prozessor)	Panel PC	2012	MT-416-A	No	No	Conditional no spare parts	End of 2022
MT-436 (ATOM Prozessor)	Panel PC	2012	MT-436-A	No	No	Conditional no spare parts	End of 2022
MT-456 (ATOM Prozessor)	Panel PC	2012	MT-456-A	No	No	Conditional no spare parts	End of 2022
MT-536-Fx/Tx HW-Rev. 2.xx	Thin Client	2012	MT-536-A	No	No	Conditional no spare parts	End of 2022
MT-556-Fx/Tx HW-Rev. 2.xx	Thin Client	2012	MT-556-A	No	No	Conditional no spare parts	End of 2022
RFIDi-RDR-1-MIF-CRYPT/ASC	Readers	2012	RFIDi-RDR-2-MIF-CRYPT/ASC	No	No	Conditional no spare parts	End of 2022
RFID-RDR-1-MIF-CRYPT/ASC	Readers	2012	RFID-RDR-2-MIF-CRYPT/ASC	No	No	Conditional no spare parts	End of 2022
MT-125	Operator Interface	2011	MT-65	No	No	Conditional no spare parts	End of 2021
ET-306 HW-Rev. 1.xx	Operator Interface	2010	ET-306-A	No	No	Conditional no spare parts	Limited
ET-316 HW-Rev. 1.xx	Operator Interface	2010	ET-316-A	No	No	Conditional no spare parts	Limited
ET-336 HW-Rev. 1.xx	Operator Interface	2010	ET-336-A	No	No	Conditional no spare parts	Limited
ET-406 (Pentium Prozessor)	Panel PC	2010	ET-406-A	No	No	Conditional no spare parts	Limited

Product	Device series / class	Status	Can be replaced by	Available	Spare part	Repair	Support
ET-416 (Pentium Prozessor)	Panel PC	2010	ET-416-A	No	No	Conditional no spare parts	Limited
ET-436 (Pentium Prozessor)	Panel PC	2010	ET-436-A	No	No	Conditional no spare parts	Limited
ET-456 (Pentium Prozessor)	Panel PC	2010	ET-456-A	No	No	Conditional no spare parts	Limited
MT-306 HW-Rev. 1.xx	Operator Interface	2010	MT-306-A	No	No	Conditional no spare parts	Limited
MT-316 HW-Rev. 1.xx	Operator Interface	2010	MT-316-A	No	No	Conditional no spare parts	Limited
MT-336 HW-Rev. 1.xx	Operator Interface	2010	MT-336-A	No	No	Conditional no spare parts	Limited
MT-406 (Pentium Prozessor)	Panel PC	2010	MT-406-A	No	No	Conditional no spare parts	Limited
MT-416 (Pentium Prozessor)	Panel PC	2010	MT-416-A	No	No	Conditional no spare parts	Limited
MT-436 (Pentium Prozessor)	Panel PC	2010	MT-436-A	No	No	Conditional no spare parts	Limited
MT-456 (Pentium Prozessor)	Panel PC	2010	MT-456-A	No	No	Conditional no spare parts	Limited
SPSPlusWIN Version 05.00.12	Software	2010	SPSPlusWIN Version 05.03.05	Yes	-	-	Limited
ET-515	KVM	2009	MT-667	No	No	Conditional no spare parts	Limited
ET-515i	KVM	2009	ET-667	No	No	Conditional no spare parts	Limited
ET-518	KVM	2009	MT-667	No	No	Conditional no spare parts	Limited
ET-518i	KVM	2009	ET-667	No	No	Conditional no spare parts	Limited
PCRI Mifare	Readers	2009	RFIDi	No	No	Conditional no spare parts	Limited
SPSPlusWIN Version 04.03.07	Software	2008	-	Yes	-	-	Limited
BCS-D101-M	Readers	2007	-	No	No	Conditional no spare parts	No
BCS-D101-R	Readers	2007	-	No	No	Conditional no spare parts	No
ET-8A	Operator Interface	2007	ET-306-A	No	No	Conditional no spare parts	Limited
9143/10-120-200-xx	Accessories	2006	9143/10-114-200-xx	No	No	Conditional no spare parts	End of 2016
MT-316-R	Operator Interface	2006	MT-316-A	No	No	Conditional no spare parts	Limited
MT-336-R	Operator Interface	2006	MT-336-A	No	No	Conditional no spare parts	Limited
BCSi 302	Readers	2005	-	No	No	Conditional no spare parts	No
ET-12	Operator Interface	2005	ET-316-A/ET-336-A	No	No	Conditional no spare parts	No
MT-300	Operator Interface	2005	-	No	No	Conditional no spare parts	No
MT-315	Operator Interface	2005	MT-316-A	No	No	Conditional no spare parts	No
MT-45	Operator Interface	2005	MT-50 *	No	No	Conditional no spare parts	No
SPSPlusWIN Version 03.02.06	Software	2005	SPSPlusWIN Version 04.03.07	No	-	-	No
MT-30A	Operator Interface	2004	-	No	No	Conditional no spare parts	No
9381	Accessories	2003	9143/10-114-200-xx	No	No	Conditional no spare parts	No
9373/21	Accessories	2003	9185/11-45-xx	No	No	Conditional no spare parts	No
ET-3A	Operator Interface	2003	ET-65-B *	No	No	Conditional no spare parts	No
ET-415	Panel PC	2003	ET-436-A	No	No	Conditional no spare parts	No
ET-4A	Operator Interface	2003	ET-65-B *	No	No	Conditional no spare parts	No
ET-4A-BC	Operator Interface	2003	ET-65-B-RSi *	No	No	Conditional no spare parts	No
ET-5A	Operator Interface	2003	ET-75-B *	No	No	Conditional no spare parts	No
ET-5A-BC	Operator Interface	2003	ET-75-B-RSi *	No	No	Conditional no spare parts	No
ET-6	Operator Interface	2003	ET-125-B *	No	No	Conditional no spare parts	No
ET-6-BCL	Operator Interface	2003	-	No	No	Conditional no spare parts	No
ET-6-BCS	Operator Interface	2003	ET-125-B-RSi *	No	No	Conditional no spare parts	No
ET-9752	Operator Interface	2003	ET-75-B *	No	No	Conditional no spare parts	No
ET-9753	Accessories	2003	-	No	No	Conditional no spare parts	No
ET-SV-2	Accessories	2003	-	No	No	Conditional no spare parts	No
ET-SV-3	Accessories	2003	9143/10-114-200-xx und 9185/11-45-xx	No	No	Conditional no spare parts	No
IPC 6100	Panel PC	2003	MT-416-A	No	No	Conditional no spare parts	No
IPC 6120	Panel PC	2003	MT-416-A/MT-436-A	No	No	Conditional no spare parts	No
IPC 6150	Panel PC	2003	MT-436-A	No	No	Conditional no spare parts	No
Magnetkartenleser HNR4	Readers	2003	-	No	No	Conditional no spare parts	No
Magnetkartenleser V3A	Readers	2003	-	No	No	Conditional no spare parts	No
MT-120	Operator Interface	2003	-	No	No	Conditional no spare parts	No
MT-121	Operator Interface	2003	-	No	No	Conditional no spare parts	No
MT-310	Operator Interface	2003	MT-306-A	No	No	Conditional no spare parts	No
MT-60	Operator Interface	2003	MT-65 *	No	No	Conditional no spare parts	No
MT-60-B	Operator Interface	2003	MT-65 *	No	No	Conditional no spare parts	No
MT-80A	Operator Interface	2003	MT-65 *	No	No	Conditional no spare parts	No
MT-80B	Operator Interface	2003	MT-65 *	No	No	Conditional no spare parts	No
MT-80-S	Operator Interface	2003	MT-65 *	No	No	Conditional no spare parts	No
MT-81A	Operator Interface	2003	MT-65 *	No	No	Conditional no spare parts	No
MT-81B	Operator Interface	2003	MT-65 *	No	No	Conditional no spare parts	No
MT-81-S	Operator Interface	2003	MT-65 *	No	No	Conditional no spare parts	No
MT-82	Operator Interface	2003	-	No	No	Conditional no spare parts	No
MT-82A	Operator Interface	2003	-	No	No	Conditional no spare parts	No

