



Operating Instructions

 $\langle \epsilon_x \rangle$

ORCA Device Platform
ORCA01E* / ORCA01M*
Panel-mount devices / Operator Stations
Panel PC / Thin Clients
Direct Monitor



Doc. no.: 2022 41 7000 0

HW-Rev. E/M5xA: 01.01.01 HW-Rev. E/M79A: 01.01.01

Operating Instructions Version: 01.00.06 Issue: 08.04.2024

Article number: 309310

Table of contents

	Description	Dogo
	Description Table of contents	Page
4	Table of contents	2
1	General information	7
1.1	Manufacturer	7
1.2	Legal notice	7
1.2.1	Trademark	7
1.2.2	Disclaimer	7
1.3	About these operating instructions	8
1.3.1	Target group	8
1.3.2	How to use this manual	8
1.3.3	Application	8
1.4	Further documents	8
1.5	Conformity with standards and regulations	9
1.5.1	Certificates	9
1.5.2	Certificates	9
	Europe (CE / ATEX)	9
	Global (IECEx)	9
1.5.3	Summary of applied standards	10
1.5.3.1	ATEX / IECEx	10
1.5.3.2	EMC Directive 2014/30/EU	10
1.5.3.3	Radio equipment directive 2014/53/EU	10
1.5.3.4	Low voltage directive 2014/35/EU	10
1.5.3.5	RoHS Directive 2011/65/EU	10
2	Explanation of symbols	11
2.1	Symbols used in these Operating Instructions	11
2.2	Warning notes	11
2.3	Symbols on the device	12
3	Safety	13
3.1	Intended use	13
3.2	Predictable improper use	14
3.3	Personnel qualification	14
3.4	Special conditions of use	14
3.5	Residual risks	15
3.5.1	Explosion hazard	15
3.5.2	Risk of injury	16
3.5.3	Device damage	17
3.6	Industrial Security	17
4	Function and device design	18
4.1	Features and versions	18
4.1.1	Options	18
4.1.2	Panel-mount device	18
4.1.2.1	D-Box	18
4.1.2.1	E-Box	19
4.1.2.2	Combination options of D-Box and E-Box	19
4.1.2.3	Operator Station	19
4.1.3	Operator Station	19

4.1.3.1	Card reader for access control	20
4.1.4	Accessories	20
4.1.5	Scope of delivery	21
4.1.5.1	Panel-mount device	21
4.1.5.2	Operator Station	21
4.2	Device design	22
4.2.1	Panel-mount device	22
4.3	Type code	23
4.3.1	Family code	23
4.3.2	Type key code field system	24
4.4	Available configuration versions	28
4.5	Dimensions	29
4.5.1	Panel-mount devices	29
4.5.1.1	Front	29
4.5.1.2	Side	29
4.5.1.3	Cutout	30
4.5.2	ORCA-OFR Operator Station	31
4.5.3	ORCA-OFR Operator Station with keyboard	31
4.6	Connection box	32
4.6.1	E-Box Standard	32
4.6.2	E-Box PRO	33
4.7	Operating elements	34
4.7.1	Sensors	35
4.8	LED status display	35
4.9	Markings on the device	36
4.9.1	Position	36
4.9.1.1	Field system label	36
4.9.1.2	Label on E-Boxes	36
4.9.1.3	Label on display boxes	37
4.9.1.4	Warning label	37
4.9.1.5	Safety label	38
4.9.2	Design of label / type plate	38
4.9.2.1	Field system label / type plate	38
4.9.2.2	E-Box Label	39
4.9.2.3	D-Box Label	39
4.9.2.4	Key to E-Box and D-Box labels	40
4.10	Ex marking	40
4.10.1	ATEX / IECEx	40
5	Operating systems and drivers	41
5.1	Windows® 10 IoT Enterprise 2019 / 2021 LTSC operating system	41
5.1.1	Recovery	41
5.1.2	Proprietary Windows installations and drivers	41
5.2	Data back-up	41
5.2.1	Recovery Stick	41
5.2.2	Back-up	42
5.2.3	Switching off / closing down	42
5.2.4	Loss of data	42

E 2	Licence etialier	40		
5.3	License sticker	43		
5.4	UPDD touch driver	43		
6	Transport and storage			
7	Unpacking	44		
8	Mounting and installation	45		
8.1	Note on mounting and installation	45		
8.2	Requirements for site of installation	45		
8.3	Mounting types	46		
8.4	Front installation	46		
8.4.1	Panel-mount – installation	46		
8.5	Installation	49		
8.5.1	General information on electric connection	49		
8.5.2	Connecting device to power supply	50		
8.5.3	Grounding the device	50		
8.5.4	Connecting data cable	50		
8.5.5	Mounting the cover of the connection box	50		
8.5.6	Connecting associated equipment	51		
8.5.7	Cable glands	51		
8.5.8	Electric connections of interfaces X1, X2, X3, X4, X5, X6, X7, X9, X10, X11, X12 and X13	52		
8.6	Using USB interfaces	53		
9	Initial start-up	54		
10	(Re-) Commissioning	54		
11	Operation	55		
11.1	Operating the touch display	55		
11.2	Switching the device on and off	56		
11.2.1	Without optional on/off button	56		
11.2.2	With optional on/off button	56		
11.3	Teaming function	56		
12	Maintenance, overhaul and repair	57		
12.1	Changing the battery	57		
12.2	Servicing	57		
12.3	Maintenance	58		
12.4	Repair	58		
12.4.1	Mounting / dismounting the modules	58		
13	Returning the device	60		
14	Cleaning	60		
15	Disposal	60		
16	Accessories	60		
17	Appendix A	61		
17.1	Technical data E/M5xA	61		
17.1.1	General	61		
17.1.2	Electrical data	61		
17.1.2.1	Electrical data - device protection	63		
17.1.3	Display	64		
17.1.4	Ambient conditions	64		
17.1.5	Mechanical data	65		
17.1.5	Micolialical data	00		

17.2	Technical data E/M79A	66	
17.2.1	General		
17.2.1		66	
17.2.2.1	Electrical data		
17.2.2.1	Electrical data - device protection	66 67	
17.2.3	Display Ambient conditions	67	
17.2.5	Mechanical data	68	
17.3	Cable glands	69	
17.3.1 17.3.2	E-Box Standard E-Box PRO	69 70	
17.3.2	Overview Hardware Revision ORCA01		
		71	
18	Appendix B	72	
18.1	Connection values	72	
18.2	Intrinsically safe interfaces	72	
18.2.1	X9 PB – on/off button (Ex ia)	72	
18.2.2	X5 / X6 – USB 4/5 (Ex ia)	72	
18.2.3 18.3	X7 / X8 – USB 6 (Ex ib)	72 73	
	Optical interfaces		
18.3.1	X15 / X16 – FO 1 / FO 2 type FX	73	
18.3.2	X15 / X16 – FO 1 / FO 2 type SX	73	
18.3.3	X15 / X16 – FO 1 / FO 2 type LX	73	
18.4	Non intrinsically safe interfaces (Ex e)	73	
18.4.1 18.4.2	X1 – Power supply	73	
18.4.3	X2 / X10 – copper1 / copper2 X3 / X11 / X12 / X13 – USB	73 73	
18.4.4	X4 – RSxxx	73	
19	-	74	
19.1	Appendix C Connection overview terminal assignment	74	
19.1.1	E-Box Standard	74	
19.1.1	Ex e terminals	74	
19.1.1.1	Ex i terminals	75	
19.1.1.2	E-Box PRO	76	
19.1.2.1	Ex e terminals	76	
19.1.2.1	Ex i terminals	79	
19.1.2.2	Direct Monitor	80	
19.1.3.1	Ex e terminals	80	
19.1.3.1	Ex i terminals	80	
20	Appendix D	81	
20.1	Variation of operating temperature range	81	
21	Appendix E	83	
21.1	Disposal / restricted substances	83	
21.1.1	Declaration of substances and restricted substances	83	
21.1.1	Declarable substance groups	83	
21.1.1.2	RoHS directive 2011/65/EC	83	
21.1.1.2	IMO Resolution MEPC.269(68)	83	
22	Appendix F	84	
22.1	Material resistance	84	
44. I	ivialti idi itololalilt	04	

22.1.1	Material	84
22.1.1.2	Powder coating	85
22.1.1.3	Front plate seal	85
22.2	Coating compatibility	94
23	Appendix G	95
23.1	Defective pixels	95
23.1.1	Terminology	95
23.1.2	Display specification	96
23.2	Optical specification front glass	97
23.2.1	Test criteria	97
23.3	Optical acceptance of surfaces	99
23.3.1	Optical acceptance glass	99
23.3.2	Optical acceptance printing	100
23.3.3	Optical acceptance, other surfaces	100
24	Appendix H	102
24.1	Control Drawing	102
25	Appendix I	107
25.1	Declarations of conformity	107
25.1.1	EU	107
25.1.1.1	ORCA01E	107
25.1.1.2	ORCA01M	108
25.2	Declaration of conformity for Equipment Compilation	109
26	Appendix J	110
26.1	Release notes	110

1 General information

1.1 Manufacturer

R. STAHL HMI Systems GmbH Adolf-Grimme-Allee 8 50829 Köln Germany

Sales Support

Tel.: +49 221 768 06 – 1200 E-mail: <u>sales.dehm@r-stahl.com</u>

Technical Support

Tel.: +49 221 768 06 – 5000 E-mail: <u>support.dehm@r-stahl.com</u>

General

Fax: +49 221 768 06 - 4200

Internet: <u>r-stahl.com</u>

1.2 Legal notice

1.2.1 Trademark

The terms and names used in this document are registered trademarks and / or products of the companies in question.

1.2.2 Disclaimer

- All rights reserved.
- This document may not be reproduced in whole or in part except with the written consent of the publisher.
- This document may be subject to change without notice.

Any warranty claims are limited to the right to demand amendments. Liability for any damage that might result from the contents of these instructions or all other documentation is limited to clear cases of premeditation.

We reserve the right to amend our products and their specifications at any time, provided it is in the interest of technical progress. The information in the current manual (online or on CD / DVD / USB-stick) or in the operating instructions included in the delivery applies.

1.3 About these operating instructions

1.3.1 Target group

These operating instructions are intended for the following groups of people:

- Project engineers
- Electricians and installers
- Operators
- · Operating staff
- Maintenance staff

1.3.2 How to use this manual

- Read these operating instructions, especially the safety notes, carefully before use.
- Take note of all other applicable documents (see also chapter <u>1.4 Further documents</u>).
- Keep the operating instructions for the entire length of the service life of the device.
- Make the operating instructions accessible to operating and maintenance staff at all times.
- Pass the operating instructions on to each subsequent owner or user of the device.
- Update the operating instructions every time R. STAHL issues an amendment.

1.3.3 Application

Operating Instructions

version: 01.00.06

Hardware revision: ORCA01E*: 01.01.01

ORCA01M*: 01.01.01

The following operating instructions apply to the following systems:

ORCA01E* / ORCA01M* Panel PC / Thin Clients

Direct Monitor

The original instructions are the German edition.

They are legally binding in all legal affairs.

1.4 Further documents

• Certificate compilation ORCA01* (CE ORCA01)



For documents in other languages, see <u>r-stahl.com</u>.

1.5 Conformity with standards and regulations

1.5.1 Certificates



Certificates: r-stahl.com

The devices have IECEx approval. See IECEx homepage: https://www.iecex-certs.com/#/home to view the certificate

1.5.2 Certificates

The following certificates are valid for all devices:

Synonym	Scope of validity	Valid until	Certificate number	Comment
CE	Europe	unlimited		According to directive 2014/30/EU; 2014/35/EU; 2014/53/EU
ATEX	Europe	unlimited	UL 23 ATEX 2902X	
IECEx	Global	unlimited	IECEx UL 23.0007X	

1.5.3 Summary of applied standards

1.5.3.1 ATEX / IECEx

Standard	Classification
IEC 60079-0 : 2018	General requirements
IEC 60079-5 : 2015	Protection by powder filling "q"
IEC 60079-7 : 2015 + A1 : 2018	Protection by increased safety "e"
IEC 60079-11 : 2012	Protection by intrinsic safety "i"
IEC 60079-31 : 2014	Protected by enclosures "t" (dust ignition protection)

1.5.3.2 EMC Directive 2014/30/EU

Standard	Classification
EN 61000-3-2 : 2014	Limiting values for harmonic current emissions
EN 61000-3-3 : 2013	Limiting values for voltage changes
EN 61000-6-2 : 2005 + AC : 2005	Immunity industrial areas
EN 61000-6-3 : 2007 + A1 : 2011 + AC : 2012	Emitted interference residential areas
EN 61000-6-4 : 2007 + A1 : 2011	Emitted interference industrial areas
EN 55035 2017 :	Immunity of multi-media devices
EN 55032 2015 :	Emitted interference of multi-media devices

1.5.3.3 Radio equipment directive 2014/53/EU

Standard	Classification
ETSI EN 300330 V2.1.1 : 2017-02	Short-range devices (SRD)
ETSI EN 301489-1 V2.2.3 : 2019-11	Technical requirements
ETSI EN 301489-3 V2.1.1 : 2019-01	Specific rating for short-range devices (SRD)

1.5.3.4 Low voltage directive 2014/35/EU

Standard	Classification
EN 62368-1 : 2014 + AC : 2015	Devices for audio / video, information and communication technology - safety requirements

1.5.3.5 RoHS Directive 2011/65/EU


Standard	Classification
EN IEC 63000 : 2018	Technical documentation for the assessment of electrical and electronic equipment with regard to the restriction of hazardous substances


2 Explanation of symbols

2.1 Symbols used in these Operating Instructions

Symbol	Meaning
0	Useful hint for making work easier, important note
(3)	Reference to another chapter, another section, another documentation or another web page.

2.2 Warning notes





NOTE Dangerous situation which can result in material damage if the safety measures are not complied with.

Symbol	Meaning
	Heat hazard
*	Laser radiation hazard
	Electrostatic charge hazard

2.3 Symbols on the device

Symbol	Meaning
(Ex)	Device certified for hazardous areas according to ATEX directive.
CE	Device marking according to EU directive
0158	ID number of monitoring body
	Marking according to WEEE directive 2012/19/EU
	Warning - important information
4	Warning of hazardous voltage
	Connection for equipotential bonding

3 Safety

The device has been manufactured according to the state of the art of technology while observing recognised safety-related rules. When using the device, it is nevertheless possible for hazards to occur to life and limb of the user or third parties or for the device, environment or material assets to be compromised.

Only use the device under the following conditions:

- If it is not damaged
- As intended, while remaining aware of safety and hazards
- In accordance with these operating instructions.

3.1 Intended use

The ORCA01 HMIs with the ORCA device platform are Panel-mount devices (PM) and Operator Stations (OS) suitable for industrial production in hazardous areas.

Depending on their version, the devices are certified for the following hazardous areas:

ORCA series	Hazardous area	Directive
Е	Zone 1, 2, 21 and 22 (EPL Gb, Db)	ATEX directive, IEC
М	Zone 2 and 22 (EPL Gc, Dc)	ATEX directive, IEC

The ORCA device platform has been developed for process and machine operation in the pharmaceutical, chemical, food, biotech and life science industries. The device can be used indoors as well as in protected outdoor areas.

The approved operating temperature ranges depend on the version:

Panel-mount device: from -20 °C to +55 °C

Operator Station: from -20 °C to +50 °C

Depending on their configuration, the following versions with the ORCA device platform are available:

- Panel PC Thin Clients
- Direct Monitor

The ORCA device platform consists of a display and an E-Box module that are usually installed together. The display module mostly consists of all display components, whereas the E-Box module mostly consists of the other electronic parts.

For service and repair (replacement) purposes the modules can be supplied separately. The conditions listed in chapter 12.4.1 Mounting / dismounting the modules apply.

The ORCA device platform communicates with automation systems and distributed control systems via Ethernet or a serial interface, and has additional USB interfaces for peripherals such as keyboards, pointing devices, RFID readers, barcode readers for material inventory or an EM-STOP button.

A connection box with separate compartments for Ex e and Ex ia circuits is used for the connection of all external cables.

The devices can be mounted into the cut-out of enclosures with IP65 according to IEC 60079-0 or into enclosures with protection type Ex eb or ec, Ex tb or tc, or Ex p. They meet the requirements of each of these enclosures.

"Intended use" includes complying with these operating instructions and other applicable documents, e.g. the data sheet. All other uses are only considered to be intended after being approved by R. STAHL.

3.2 Predictable improper use

The device may only be installed and connected by qualified or specifically trained personnel.

3.3 Personnel qualification

Qualified specialist personnel is required to perform the activities described in these operating instructions. This primarily applies to work in the following areas:

- Product selection and project engineering
- Mounting / dismounting the device
- Installation
- Commissioning
- Maintenance, cleaning

Specialists who perform these tasks must have a level of knowledge that meets applicable national or equivalent country-specific standards and regulations. Additional knowledge is required for any activity in hazardous areas!

R. STAHL recommends having a level of knowledge equal to that described in the following standards:

- IEC/EN 60079-14 (Electrical installations design, selection and erection)
- IEC/EN 60079-17 (Inspection and maintenance of electrical installations)
- IEC/EN 60079-19 (Equipment repair, overhaul and reclamation)

3.4 Special conditions of use

The intrinsically safe circuits are earthed.

The devices (including their connection cables) may only be installed in areas where there are absolutely no intensive electrostatic charge processes.

For ORCA01M* only:

The devices are intended for installation in areas with degree of pollution of at least 2 according to IEC 60664-1.

An overvoltage protector must be fitted that is set to a value of no more than 140 % of the peak value of the nominal voltage at the supply connections of the device.



Please refer to the certificates for more special conditions.

3.5 Residual risks

3.5.1 Explosion hazard

Despite the device's state-of-the-art design, explosion hazards cannot be entirely eliminated in hazardous areas.

Perform all tasks in hazardous areas with the utmost care at all times!

Possible hazards ("residual risks") can be categorised according to the following causes:

Mechanical damage

The device may become damaged during transport, mounting or commissioning. This kind of damage may, for example, render the device's explosion protection partially or completely ineffective. This may result in explosions causing serious or even fatal injury.

- Do not commission a damaged device.
- Only transport the device in special transport packaging that reliably protects the device from external influences. Take ambient conditions into account when selecting the transport packaging (see chapter <a href="https://doi.org/10.1007/journal.org/10.1007/journ
- Do not place any loads on the device.
- Check the packaging and the device for damage. Immediately report any damage to R. STAHL.
- Store the device ideally in its original packaging in a dry place (with no condensation) and make sure that it is stable and protected against the effects of vibrations and knocks.
- Do not damage the device or seals during its installation.

Excessive heating or electrostatic charge

- Operate the device only within the prescribed operating conditions (see chapters 4.9 Markings on the device and 17.1 Technical data).
- Mount and install the device in such a way that it is always operated within the permissible temperature range.
- Do not use the device in strong charge-generating environments.
- Avoid friction and flow of particle streams.
- R. STAHL recommends you equip devices used outdoors or exposed to the elements with a protective roof or wall.
- Regularly inspect the device for a material change. If you spot any changes, test or replace the device.
- Do not paint or repaint the device yourself. Do not have the paintwork touched up by anyone other than the manufacturer.
- Comply with the area specification of EN/IEC 60079-0 when fitting additional plastic adhesive labels.
- Clean the device with a damp cloth only.
- Do not cover the display with protective foil.

Improper mounting, installation, commissioning, maintenance or cleaning

Basic work such as installation, commissioning, maintenance or cleaning of the device must always be performed in accordance with the applicable national regulations of the country of use and only by qualified persons. Otherwise, the explosion protection may be rendered ineffective. This may result in explosions causing serious or even fatal injury.

- Have the assembly, installation, commissioning and maintenance work performed by qualified and authorised persons only (see chapter <u>3.3 Personnel qualification</u>).
- Prior to commissioning, check the device is correctly mounted (see chapter <u>8 Mounting and installation</u>).
- Electrical circuits with Ex i type of protection may no longer be operated as electrical circuits
 with this type of protection after being operated with electrical circuits with other types of
 protection.
- Even when used in Zones 2 and 22, intrinsically safe devices of Zones 0, 1, 20 and 21 can be connected to the intrinsically safe signal circuits.
- Only connect the device to equipment which does not carry voltages higher than 250 VAC (50 - 60 Hz).
- Connect Ex i devices only to intrinsically safe terminals.
- In hazardous areas, always switch the electrical circuits and devices to a de-energised state before disconnecting or connecting and when mounting / dismounting.
- Do not change or modify the device.
- Any repair on the device is to be performed by R. STAHL only.
- Gently clean the device with a damp cloth only do not use scratching, abrasive or aggressive cleaning agents or solutions.
- Never clean the device with a strong water jet, such as a pressure washer!
- The device protection may be compromised if the device is being used outside of its intended purpose as specified by the manufacturer.

3.5.2 Risk of injury

Falling devices or components

The heavy device or components can fall during transport and mounting, causing severe injury to persons in the form of bruises and contusions.

- Use transporting and lifting equipment suitable for the size and weight of the device when transporting and mounting it.
- Observe the weight and the maximum load-bearing capacity of the device; see specifications on the shipping label or on the packaging.
- Use suitable mounting materials for mounting.

Electric shock

During operation and maintenance, high voltage is at times applied to the device. Because of this, the device must be de-energised during installation. Persons coming into contact with electrical lines carrying excessively high voltage can suffer severe electric shocks and, consequently, injuries.

• Only connect electrical circuits to suitable terminals.

3.5.3 Device damage

As a result of unsuitable operating conditions or careless handling the device or individual components may be damaged so significantly that the device does not operate correctly or fails completely.

- Do not subject the device to external heat sources or direct sunshine. Ensure that the maximum ambient temperature is never exceeded.
- Do not open the enclosure. The enclosure has been sealed permanently.

3.6 Industrial Security

Our products with Industrial Security functions support the secure operation of facilities, systems and equipment. Protection against cyber threats requires an all-encompassing Industrial Security concept. The key to a successful concept is integrated implementation, continuous maintenance and state-of-the-art technology. This is the responsibility of the facility operator.

The following are key issues for effective industrial security concepts:


- Prevention of unauthorised access to facilities, systems, equipment and networks
- Systems, equipment and components should only be connected to the company intranet or the internet if and when required
- Employ protective measures such as firewalls and network segmentation
- Only use the latest software product versions
- Carry out software updates as soon as new updates are available
- Use standard user accounts for regular operation
- Use secure passwords
- Appropriate safeguarding of administrator accounts
- Application of security guidelines
- Other measures to be taken as required
- R. STAHL uses Windows 10 for its products. The company does not develop any cryptographic functions. Neither does the company create any system configuration / system hardening software, provide security guidelines for these, nor does it refer to any such guidelines. Moreover, R. STAHL is constantly working on enhancing its products, thereby contributing to system security and to minimizing the risk of cyber threats.

4 Function and device design

4.1 Features and versions

4.1.1 Options

The HMIs with the ORCA device platform are Panel-mount devices (PM) and Operator Stations (OS) that have been developed for process and machine operation in the pharmaceutical, chemical, food, biotech and life science industries.



Depending on their technology, the devices perform the following tasks:

Technology	Task
Panel PC / Thin Client	Industrial PC with computer and monitor or Thin Client for remote control of PCs or virtual workstations, for example via Ethernet and WiFi.
Direct Monitor (USB) (only 22" display)	Extension of the primary screen for a dual-screen solution via a USB connection, requiring driver support at the main device.

4.1.2 Panel-mount device

The Panel-mount devices consist of a display box (D-Box) and an electronics box module (E-Box) that are installed together. The display box module mostly consists of all display components, whereas the E-Box module mostly consists of the other electronic parts.

4.1.2.1 D-Box

The ORCA device platform is available with the following types of display:

- Size: 12", 15" or 22"
- Multi-touch function
- Dimmable (via the operating system and, for the 22" model, also via sensor keys)

Optional components:

Integrated PC/SC card reader (only 22" display)

4.1.2.2 E-Box

Available E-Boxes are:

· E-Box Standard, with

DC supply, Intel® ATOM™ processor, copper Ethernet interface

• E-Box PRO, with

AC or DC supply, Intel® ATOM™ or Intel® Core i5™ processor, optional with two copper / fibre optic Ethernet interfaces

4.1.2.3 Combination options of D-Box and E-Box

Display size D-Box	E-Box Standard	E-Box PRO
12"	X	-
15"	X	X
22"	X	X
22" (Direct Monitor)	-	Х

4.1.3 Operator Station

The 22" Operator Stations are specifically intended for the process industry. This means both the installation in production areas where there is a lot of dirt and pollution, and the installation in class C cleanrooms.

All Operator Stations have a 22" display box and either the E-Box Standard or the E-Box PRO. These Panel-mount devices are installed in a type ORCA-OFR enclosure with GMP-compliant design.

These Operator Stations can be installed as single as well as dual-screen solutions.

Further features of the enclosure:

- Waterproof and dust-tight IP66
- V2A or V4A stainless steel enclosure
- Easily accessible via front door with GMP gasket

Optional components:

- Intrinsically safe KB2 keyboard with trackball, touchpad or joystick
- Prepared for operation of Barcode scanner (pre-wired) (Barcode scanner to be ordered separately)
- On / off button

4.1.3.1 Card reader for access control

As an option, the 22" ORCA01* devices can be fitted with an integrated card reader. This card reader is a proximity reader that can read the corresponding transponder media without direct contact and transfer the data to operating devices or any other systems.

In addition, all ORCA01* devices can be fitted with STAHL's proprietary UB03 card reader via USB. For this, the PM devices have to be installed inside an enclosure.

Three versions of RFID reader are available for different types of data transfer between reader and a corresponding software.

Internal card readers (in D-Box):

 PC/SC - version C8: PC/SC is a platform and manufacturer-independent standard for card readers with access to smartcards. PC/SC stands for "personal computer / smart card". Internally, the module is connected via a USB interface.

External UB03 card reader as accessory (at Operator Station):

- CRYPT version C5: data is transferred via an encrypted bidirectional protocol. This protocol can also be used to describe the transponder media. The connected device must be able to support the data encryption via a suitable application. The protocol description can be provided once a confidentiality agreement has been signed.
- ASCII version C6: when the transponder medium approaches the reader or is removed from it, the reader actively sends the pre-parameterised content of the medium in the form of characters transformed byte-wise from hex code to ASCII. Applications such as PM Logon from Siemens or LogOnPlus from i.p.a.s. support this protocol.

4.1.4 Accessories

Peripherals:

- Barcode scanner
- UB03 Card reader
- Attached KB2 keyboard and pointing device (trackball, joystick or touchpad (Ex ia))
- On / off button

The accessories are connected in the connection box (see chapter 4.6 Connection box).



For associated Operating Instructions see r-stahl.com.

4.1.5 Scope of delivery

4.1.5.1 Panel-mount device

- ORCA01* Panel-mount device according to ordered configuration
- Mounting frame including pre-assembled screws
- Cable glands as a set for E-Box Standard or E-Box PRO (depending on Panel-mount device configuration)
- Touch pen
- USB stick (with documentation and image) cannot be used in hazardous areas
- USB adapter board (for commissioning purposes) cannot be used in hazardous areas



Operating Instructions

4.1.5.2 Operator Station

- ORCA01* Operator Station according to ordered configuration, completely wired and ready for operation
- Cable glands as a set for E-Box Standard or E-Box PRO (depending on Operator Station configuration)
- Touch pen
- USB stick (with documentation and image) cannot be used in hazardous areas
- USB adapter board (for commissioning purposes) cannot be used in hazardous areas




Operating Instructions

4.2 Device design

4.2.1 Panel-mount device

Taking the 15" device with E-Box Standard as an example:




Item	Designation	
1	ORCA01* 15" device with E-Box Standard	
2	15" display box (D-Box)	
3	E-Box Standard	

4.3 Type code

4.3.1 Family code

The family code contains all information relevant for certification.



Family code digit	Possible value	Description			
ORCA	ORCA	Family designation			
01	01	Family hardware revision			
	E	Devices for Zone 1, Zone 21, EPL Gb, Db			
а	M	Devices for Zone 2, Zone 22, EPL Gc, Dc			
	I	Devices for safe areas, Non-Ex			
	00	No technology			
bb	TC	Thin Client / Panel PC			
	DM	Direct Monitor			
	0	no E-Box			
С	S	E-Box Standard			
	Р	E-Box PRO			
	0	no display			
d	3	Display size 3 (12")			
u	4	Display size 4 (15")			
	6	Display size 6 (22")			
	00	no power supply			
ee	AC	AC power supply			
	DC	DC power supply			
	00	no fibre optic			
ff	MM	multi-mode fibre optic			
	SM	single mode fibre optic			
aa	00	no card reader			
99	C8	RFID PC-SC card reader			

4.3.2 Type key code field system

Field systems	Field systems				
Definition Field systems	A field system consists of at least one HMI unit and its integrated software. If the HMI unit is mounted inside an enclosure, this enclosure as well as all other accessories mounted inside it are part of the field system. To facilitate the order-process for a field system, a product code was developed that can reproduce all possible combinations of device, software, enclosure and accessories. This product code consists of alpha-numerical characters and may look as follows: E59A10T02-C50C3000000221-10120000000000Y This example is valid for a Panel PC / Thin Client system; the product codes for all other field systems are built in the same way.				
	It is decoded as fo	llows:			
Decoding	E59A10T02	-	C50C3000000221	-	10120000000000Y
Meaning	Device version Hyphen extended Hyphen Enclosure and device version accessories				
	For an exact definition of each individual character please refer to the type code for field systems on the following pages.				
	A field system can only be ordered with a valid and plausible product code. For this, all digits of the product code must be filled with a valid character. Please also note that for technical reasons not all theoretically possible product codes and thus field systems can actually be realised. Should you have any questions in this regard, please contact R. STAHL HMI Systems GmbH.				

Position in type key	Meaning	Possible value	Description
1	Application range	Е	Devices for Zone 1, Zone 21, EPL Gb, Db
	(zone)	М	Devices for Zone 2, Zone 22, EPL Gc, Dc
2	Technology	0	Display-Box (stand-alone)
		5	Thin Client / Panel PC
		7	Direct Monitor
3	Display size	0	no display, only E-Box (stand-alone)
		2	12" / 30.8 cm display, 1280 x 800 pixels
		4	15" / 39.5 cm display, 1920 x 1080 pixels
		9	22" / 55 cm display, 1920 x 1080 pixels
4	Platform	Α	ORCA platform
5	Hardware revision	1	Hardware revision 01.01.01
6	Basic option 1	0	no option
7	Interface medium	0	no interface
		T	1x 1000Base-TX Copper Ethernet
		F	1x 100Base-FX FO Ethernet, multi-mode
		S	1x 1000Base-SX FO Ethernet, multi-mode
		L	1x 1000Base-LX FO Ethernet, single mode
		Е	Ethernet extender
8	Interface medium 2	0	no interface
		F	1x 100Base-FX FO Ethernet, multi-mode
		S	1x 1000Base-SX FO Ethernet, multi-mode
		L	1x 1000Base-LX FO Ethernet, single mode
		U	Additional USBe interface

	T E D O (;)		
9	E-Box Option	0	no E-Box
	_	1	E-Box Standard
	-	2	E-Box PRO
		3	E-Box PRO, Direct Monitor
10	Hyphen	-	Hyphen
11	Processor type	0	no processor
		В	Intel® ATOM™ E3940
		С	Intel® Core i5™ 8365UE
12	Main memory	0	no main memory
	(RAM)	3	4 GB (ATOM)
		4	8 GB (ATOM)
		5	16 GB (i5)
		6	32 GB (planned for future)
13	Display type	0	Standard TFT
		1	Sunlight readable (planned for future)
14	Data memory	0	no data memory
		Α	64 GB SSD (ATOM)
		9	128 GB SSD (ATOM)
		С	256 GB SSD (i5)
		Е	480 GB SSD (planned for future)
15	Touchscreen	0	no touch screen
		3	Projected capacitive (PCAP), multi-touch
16	Power supply	N	no power supply
		0	DC power supply 24 VDC
		1	AC power supply 85 - 250 VAC
17	Optional Interfaces 1 (WiFi, Bluetooth)	0	no WiFi, no Bluetooth
18	Optional Interfaces	0	no card reader
	2 (internal card reader)	8	RFID card reader PC-SC
19	Optional Interfaces	0	no audio
	3	1	USBe interface
	(Audio)	5	Audio amplifier output
20	Additional options	0	no additional option
	·	1	Direct Monitor
		2	Standard (Thin Client / Panel PC)
21	Front design	0	Standard
22	Front plate special	0	no front plate
	version	1	neutral
		2	STAHL
L	1		1

23	1			
2 WIN10 IoT Enterprise 2019 LTSC 64Bit 3 PXE-Boot (for ThinManager) 4 IGEL OS 11 (does not include license) 8 WIN10 IoT Enterprise 2021 LTSC 64Bit 10 10 10 10 10 10 10 1	23	Operating system	0	No operating system
3 PXE-Boot (for ThinManager)			1	WIN10 IoT Enterprise 2019 LTSC 32Bit
4 IGEL OS 11 (does not include license) 8 WIN10 IoT Enterprise 2021 LTSC 64Bit 1 OS STAHL 3 Remote V6 STAHL 5 Movicon Power HMI 2048 6 IGEL OS 11 8 Remote V7 STAHL 1 ORCA-OFR Operator Station 2 ORCA FR Operator Station 2 ORCA STR Operator Station 2 ORCA STR Operator Station 2 ORCA STR Operator Station 3 ORCA CFR Operator Station 4 SL (Slim) enclosure (reduced enclosure depth – for 12" and 15" devices only) 2 ORCA STR Operator Station 2 ORCA STR Operator Station 3 ORCA CFR Operator Station 4 V2A SS304 stainless steel 5 V2A SS304 stainless steel 6 V2A SS304 stainless steel 7 V2A SS304 stainless steel 8 Denclosure mounting 9 Outdoor Installation 1 Wall mounting 1 Wall mounting 2 Mounted on stand or elbow below 3 Mounted at ceiling or elbow on top 30 Outdoor Installation 4 Neyboard in keyboard enclosure with keyboard layout German - DE (QWERTY) 5 Keyboard in keyboard enclosure with keyboard layout American - US (QWERTY) 6 Keyboard in keyboard enclosure with keyboard layout Swiss German - CH 7 Keyboard in keyboard enclosure with keyboard layout Swiss German - CH 8 Keyboard in keyboard enclosure with keyboard layout Swiss German - CH 8 Keyboard in keyboard enclosure with keyboard layout Swiss German - CH 8 Keyboard in keyboard enclosure with keyboard layout Swiss German - CH 8 Keyboard in keyboard enclosure with keyboard layout Spanish - ES 1 Keyboard in keyboard enclosure with keyboard layout Spanish - ES 1 Keyboard in keyboard enclosure with keyboard layout Spanish - ES			2	WIN10 IoT Enterprise 2019 LTSC 64Bit
Section Section			3	PXE-Boot (for ThinManager)
24 Image 1 OS STAHL 3 Remote V6 STAHL 5 Movicon Power HMI 2048 6 IGEL OS 11 8 Remote V7 STAHL 25 Hyphen 26 Enclosure version 1 ORCA-OFR Operator Station (22" device only) 2 ORCA FR Operator Station 3 ORCA CFR Operator Station 3 ORCA CFR Operator Station 27 Enclosure option 28 Enclosure material 1 SL (Slim) enclosure (reduced enclosure depth – for 12" and 15" devices only) 29 Enclosure material 1 V2A SS304 stainless steel 29 Enclosure 29 Enclosure 30 Mounted on stand or elbow below 31 Mounted at ceiling or elbow on top 30 Outdoor Installation 30 Outdoor Installation 31 Keyboard (layout) 4 Keyboard in keyboard enclosure with keyboard layout Swiss German - CH 4 Keyboard in keyboard enclosure with keyboard layout Swiss German - CH 5 Keyboard in keyboard enclosure with keyboard layout Slovenian - SL 8 Keyboard in keyboard enclosure with keyboard layout Swiss German - CH 8 Keyboard in keyboard enclosure with keyboard layout Swiss German - CH 8 Keyboard in keyboard enclosure with keyboard layout Swiss German - CH 8 Keyboard in keyboard enclosure with keyboard layout Swiss German - CH 8 Keyboard in keyboard enclosure with keyboard layout Swiss German - CH 8 Keyboard in keyboard enclosure with keyboard layout Swiss German - CH 8 Keyboard in keyboard enclosure with keyboard layout Swiss German - CH 8 Keyboard in keyboard enclosure with keyboard layout Swiss German - CH 8 Keyboard in keyboard enclosure with keyboard layout Swiss German - CH 9 Keyboard in keyboard enclosure with keyboard layout Swiss German - CH 1 Keyboard in keyboard enclosure with keyboard layout Swiss German - CH 1 Keyboard in keyboard enclosure with keyboard layout Swiss German - CH 1 Keyboard in keyboard enclosure with keyboard layout Spanish - ES 1 Keyboard in keyboard enclosure with keyboard layout Slovenian - SL 1 Keyboard in keyboard enclosure with keyboard layout Slovenian - SL			4	IGEL OS 11 (does not include license)
1 OS STAHL 3 Remote V6 STAHL 5 Movicon Power HMI 2048 6 IGEL OS 11 8 Remote V7 STAHL 25 Hyphen - Hyphen 26 Enclosure version 1 ORCA-OFR Operator Station (22" device only) 2 ORCA FR Operator Station 3 ORCA CFR Operator Station 3 ORCA CFR Operator Station 3 ORCA CFR Operator Station 4 SL (Slim) enclosure (reduced enclosure depth for 12" and 15" devices only) 28 Enclosure material 4 V2A SS304 stainless steel 5 V4A SS316L stainless steel 6 V4A SS316L stainless steel 7 Val mounting type 8 Mounted on stand or elbow below 9 Mounted at ceiling or elbow on top 9 Outdoor Installation 9 No enclosure mounting 1 Wall mounting 1 Wall mounting 2 Mounted on stand or elbow below 3 Mounted at ceiling or elbow on top 4 No exploard, no keyboard enclosure with keyboard layout American - US (QWERTZ) 4 Keyboard in keyboard enclosure with keyboard layout American - US (QWERTY) 5 Keyboard in keyboard enclosure with keyboard layout Swiss German - CH 6 Keyboard in keyboard enclosure with keyboard layout Swiss German - CH 7 Keyboard in keyboard enclosure with keyboard layout Swiss German - CH 8 Keyboard in keyboard enclosure with keyboard layout Swiss German - CH 8 Keyboard in keyboard enclosure with keyboard layout Swiss German - CH 8 Keyboard in keyboard enclosure with keyboard layout Swiss German - CH 8 Keyboard in keyboard enclosure with keyboard layout Spanish - ES 9 Keyboard in keyboard enclosure with keyboard layout Spanish - ES 1 Keyboard in keyboard enclosure with keyboard layout Spanish - ES			8	WIN10 IoT Enterprise 2021 LTSC 64Bit
3 Remote V6 STAHL 5 Movicon Power HMI 2048 6 IGEL OS 11 8 Remote V7 STAHL 25 Hyphen - Hyphen 26 Enclosure version 0 no enclosure, no options 1 ORCA-OFR Operator Station (22" device only) 2 ORCA FR Operator Station (22" device only) 2 ORCA FR Operator Station 3 ORCA CFR Operator Station 3 ORCA CFR Operator Station 1 SL (Slim) enclosure (reduced enclosure depth – for 12" and 15" devices only) 28 Enclosure material 1 V2A SS304 stainless steel 2 V4A SS316L stainless steel 2 V4A SS316L stainless steel 2 V4A SS316L stainless steel 3 Mounted at ceiling or elbow on top 30 Outdoor Installation 3 Nounted at ceiling or elbow on top 30 Outdoor Installation 4 Nounted at ceiling or elbow enclosure 5 Neyboard in keyboard enclosure with keyboard layout American - US (QWERTY) 5 Keyboard in keyboard enclosure with keyboard layout Fernch - FR (AZERTY) 6 Keyboard in keyboard enclosure with keyboard layout Swiss German - CH 6 Neyboard in keyboard enclosure with keyboard layout Swiss German - CH 7 Neyboard in keyboard enclosure with keyboard layout Swiss German - CH 8 Neyboard in keyboard enclosure with keyboard layout Swiss German - CB 8 Neyboard in keyboard enclosure with keyboard layout Swiss German - CH 8 Neyboard in keyboard enclosure with keyboard layout Swiss German - CB 9 Neyboard in keyboard enclosure with keyboard layout Spanish - ES 9 Neyboard in keyboard enclosure with keyboard layout Spanish - ES 1 Neyboard in keyboard enclosure with keyboard layout Spanish - ES 1 Neyboard in keyboard enclosure with keyboard layout Spanish - ES	24	Image	0	no image
S			1	OS STAHL
Bernote V7 STAHL			3	Remote V6 STAHL
8 Remote V7 STAHL 25 Hyphen - Hyphen 26 Enclosure version 27 ORCA-OFR Operator Station (22" device only) 28 Enclosure material 29 Enclosure material 29 Enclosure mounting type 30 Outdoor Installation 30 Outdoor Installation 31 Keyboard (layout) 31 Keyboard in keyboard enclosure with keyboard layout Spanish - ES 4 Keyboard in keyboard enclosure with keyboard layout Slovenian - SL 4 Keyboard in keyboard enclosure with keyboard layout Slovenian - SL 5 Keyboard in keyboard enclosure with keyboard layout Slovenian - SL 6 Keyboard in keyboard enclosure with keyboard layout Slovenian - SL 7 Keyboard in keyboard enclosure with keyboard layout Slovenian - SL 8 Keyboard in keyboard enclosure with keyboard layout Slovenian - SL 8 Keyboard in keyboard enclosure with keyboard layout Slovenian - SL 8 Keyboard in keyboard enclosure with keyboard layout Slovenian - SL 8 Keyboard in keyboard enclosure with keyboard layout Slovenian - SL 8 Keyboard in keyboard enclosure with keyboard layout Slovenian - SL 8 Keyboard in keyboard enclosure with keyboard layout Slovenian - SL 8 Keyboard in keyboard enclosure with keyboard layout Slovenian - SL 8 Keyboard in keyboard enclosure with keyboard layout Slovenian - SL 8 Keyboard in keyboard enclosure with keyboard layout Slovenian - SL 8 Keyboard in keyboard enclosure with keyboard layout Slovenian - SL 9 Keyboard in keyboard enclosure with keyboard layout Slovenian - SL			5	Movicon Power HMI 2048
25			6	IGEL OS 11
Enclosure version			8	Remote V7 STAHL
1 ORCA-OFR Operator Station (22" device only) 2 ORCA FR Operator Station 3 ORCA CFR Operator Station 3 ORCA CFR Operator Station 1 SL (Slim) enclosure (reduced enclosure depth – for 12" and 15" devices only) 28 Enclosure material 29 Enclosure mounting type 29 Enclosure mounting type 20 Enclosure mounting type 20 Enclosure mounting type 21 Wall mounting 22 Mounted on stand or elbow below 33 Mounted at ceiling or elbow on top 30 Outdoor Installation 31 Keyboard (layout) 31 Keyboard (layout) 4 Keyboard in keyboard enclosure with keyboard layout Spranish - ES 4 Keyboard in keyboard enclosure with keyboard layout Spanish - ES 4 Keyboard in keyboard enclosure with keyboard layout Spanish - ES 5 I Keyboard in keyboard enclosure with keyboard layout Spoard in keyboard enclosure with keyboard layout Spoard in keyboard enclosure with keyboard layout Spanish - ES 5 I Keyboard in keyboard enclosure with keyboard layout Spoard in keyboard enclosure with keyboard layout Spanish - ES 5 I Keyboard in keyboard enclosure with keyboard layout Spoard in keyboard enclosure with keyboard layout Spanish - ES 6 I Keyboard in keyboard enclosure with keyboard layout Spoard in keyboard enclosure with keyboard layout Spoard in keyboard enclosure with keyboard layout Spoard in keyboard enclosure with keyboard layout Spanish - ES 6 I Keyboard in keyboard enclosure with keyboard layout Spoard enclosure with keyboard layout Spoard enclosure with keyboard	25	Hyphen	-	Hyphen
2 ORCA FR Operator Station 3 ORCA CFR Operator Station 1 ORCA CFR Operator Station 1 SL (Slim) enclosure (reduced enclosure depth – for 12" and 15" devices only) 28 Enclosure material 29 Enclosure mounting type 29 Enclosure mounting type 20 Enclosure mounting type 20 Enclosure mounting type 21 Wall mounting 22 Mounted on stand or elbow below 33 Mounted at ceiling or elbow on top 30 Outdoor Installation 31 Keyboard (layout) 31 Keyboard (layout) 4 Keyboard in keyboard enclosure with keyboard layout Spenish - ES 4 Keyboard in keyboard enclosure with keyboard layout Spenish - ES 4 I Keyboard in keyboard enclosure with keyboard layout Spenish - ES 5 I Keyboard in keyboard enclosure with keyboard layout Spoard in keyboard enclosure with keyboard layout Spoard in keyboard enclosure with keyboard layout Spenish - ES 5 I Keyboard in keyboard enclosure with keyboard layout Spoard in keyboard enclosure with keyboard layout Spoard in keyboard enclosure with keyboard layout Spenish - ES 5 I Keyboard in keyboard enclosure with keyboard layout Spoard enclosure with keyboard layout Spoard enclos	26	Enclosure version	0	no enclosure, no options
27 Enclosure option 28 Enclosure material 29 Enclosure mounting type 20 Tench mounting type 30 Outdoor Installation 31 Keyboard (layout) 32 Keyboard in keyboard enclosure with keyboard layout Slovenian - SL 30 Keyboard in keyboard enclosure with keyboard layout Slovenian - SL 40 Keyboard in keyboard enclosure with keyboard layout Slovenian - SL 40 VAC FR Operator Station 41 V2 (Slim) enclosure (reduced enclosure depth - for 12" and 15" devices only) 41 V2A SS304 stainless steel 42 V4A SS316L stainless steel 43 V2A SS316L stainless steel 44 VAI SS316L stainless steel 45 VAI SS316L stainless steel 46 VAI SS316L stainless steel 47 VAI SS316L stainless steel 48 VAI SS316L stainless steel 49 Enclosure mounting 40 no enclosure mounting 40 VAI SS304 stainless steel 40 VAI SS316L stainless steel 41 V2A SS304 stainless steel 41 V2A SS304 stainless steel 40 VAI SS316L stainless steel 40 VAI SS316L stainless steel 40 VAI SS316L stainless steel 40 VAI SS304 stainless ste			1	ORCA-OFR Operator Station (22" device only)
27 Enclosure option 1			2	ORCA FR Operator Station
1 SL (Slim) enclosure (reduced enclosure depth – for 12" and 15" devices only) 28 Enclosure material 20 no enclosure material 1 V2A SS304 stainless steel 2 V4A SS316L stainless steel 2 W4A SS316L stainless steel 2 Mounting type 1 Wall mounting 2 Mounted on stand or elbow below 3 Mounted at ceiling or elbow on top 30 Outdoor Installation 3 Protected outdoor area (breather available) 31 Keyboard (layout) 3 Protected outdoor area (breather available) 4 Keyboard in keyboard enclosure with keyboard layout German - DE (QWERTZ) 5 Keyboard in keyboard enclosure with keyboard layout American - US (QWERTY) 6 Keyboard in keyboard enclosure with keyboard layout Swiss German - CH 6 Keyboard in keyboard enclosure with keyboard layout Swiss German - CH 7 Keyboard in keyboard enclosure with keyboard layout Spanish - ES 8 Keyboard in keyboard enclosure with keyboard layout Spanish - ES 8 Keyboard in keyboard enclosure with keyboard layout Spanish - ES 8 Keyboard in keyboard enclosure with keyboard layout Spanish - ES 8 Keyboard in keyboard enclosure with keyboard layout Spanish - ES 9 Keyboard in keyboard enclosure with keyboard layout Spanish - ES 1 Keyboard in keyboard enclosure with keyboard layout Slovenian - SL 1 Keyboard in keyboard enclosure with keyboard layout Slovenian - SL			3	ORCA CFR Operator Station
for 12" and 15" devices only) 28	27	Enclosure option	0	no enclosure option - standard
1 V2A SS304 stainless steel 2 V4A SS316L stainless steel 2 1 V4A SS316L stainless steel 2 1 V4A SS316L stainless steel 2 1 V4A SS316L stainless steel 3 1 Vall mounting 2 2 Mounted on stand or elbow below 3 Mounted at ceiling or elbow on top 3 1 Nounted at ceiling or elbow on top 3 1 Protected outdoor area (breather available) 3 1 Keyboard (layout) 4 Nounted at ceiling or elbow on top 5 Nounted at ceiling or elbow on top 6 Nounted at ceiling or elbow on top 7 Nounted at ceiling or elbow on top 8 Nounted at ceiling or elbow on top 9 Nounted at ceiling or elbow or e			1	
29 Enclosure mounting type Enclosure mounting type 1 Wall mounting 2 Mounted on stand or elbow below 3 Mounted at ceiling or elbow on top 30 Outdoor Installation 3 Protected outdoor area (breather available) 31 Keyboard (layout) Stephoard (layout) E Keyboard in keyboard enclosure with keyboard layout German - DE (QWERTZ) E Keyboard in keyboard enclosure with keyboard layout American - US (QWERTY) F Keyboard in keyboard enclosure with keyboard layout French - FR (AZERTY) G Keyboard in keyboard enclosure with keyboard layout Swiss German - CH H Keyboard in keyboard enclosure with keyboard layout Syanish - ES I Keyboard in keyboard enclosure with keyboard layout Spanish - ES I Keyboard in keyboard enclosure with keyboard layout Slovenian - SL J Keyboard in keyboard enclosure with keyboard layout Slovenian - SL	28	Enclosure material	0	no enclosure material
Enclosure mounting type 1			1	V2A SS304 stainless steel
mounting type 1 Wall mounting 2 Mounted on stand or elbow below 3 Mounted at ceiling or elbow on top 30 Outdoor Installation 0 no outdoor installation – indoor only 3 Protected outdoor area (breather available) 31 Keyboard (layout) 0 no keyboard, no keyboard enclosure D Keyboard in keyboard enclosure with keyboard layout German - DE (QWERTZ) E Keyboard in keyboard enclosure with keyboard layout American - US (QWERTY) F Keyboard in keyboard enclosure with keyboard layout French - FR (AZERTY) G Keyboard in keyboard enclosure with keyboard layout Swiss German - CH H Keyboard in keyboard enclosure with keyboard layout Spanish - ES I Keyboard in keyboard enclosure with keyboard layout Slovenian - SL J Keyboard in keyboard enclosure with keyboard			2	V4A SS316L stainless steel
2 Mounted on stand or elbow below 3 Mounted at ceiling or elbow on top 30 Outdoor Installation 0 no outdoor installation – indoor only 3 Protected outdoor area (breather available) 31 Keyboard (layout) 0 no keyboard, no keyboard enclosure D Keyboard in keyboard enclosure with keyboard layout German - DE (QWERTZ) E Keyboard in keyboard enclosure with keyboard layout American - US (QWERTY) F Keyboard in keyboard enclosure with keyboard layout French - FR (AZERTY) G Keyboard in keyboard enclosure with keyboard layout Swiss German - CH H Keyboard in keyboard enclosure with keyboard layout Spanish - ES I Keyboard in keyboard enclosure with keyboard layout Spanish - ES J Keyboard in keyboard enclosure with keyboard layout Slovenian - SL J Keyboard in keyboard enclosure with keyboard	29	Enclosure	0	no enclosure mounting
3 Mounted at ceiling or elbow on top 30 Outdoor Installation 0 no outdoor installation – indoor only 3 Protected outdoor area (breather available) 31 Keyboard (layout) 0 no keyboard, no keyboard enclosure D Keyboard in keyboard enclosure with keyboard layout German - DE (QWERTZ) E Keyboard in keyboard enclosure with keyboard layout American - US (QWERTY) F Keyboard in keyboard enclosure with keyboard layout French - FR (AZERTY) G Keyboard in keyboard enclosure with keyboard layout Swiss German - CH H Keyboard in keyboard enclosure with keyboard layout Spanish - ES I Keyboard in keyboard enclosure with keyboard layout Slovenian - SL J Keyboard in keyboard enclosure with keyboard		mounting type	1	Wall mounting
Outdoor Installation One outdoor installation — indoor only Reyboard (layout) Neyboard, no keyboard enclosure Exploard in keyboard enclosure with keyboard layout German - DE (QWERTZ) Exploard in keyboard enclosure with keyboard layout American - US (QWERTY) Fxeyboard in keyboard enclosure with keyboard layout French - FR (AZERTY) Gxeyboard in keyboard enclosure with keyboard layout Swiss German - CH Hxeyboard in keyboard enclosure with keyboard layout Spanish - ES Ixeyboard in keyboard enclosure with keyboard layout Spanish - ES Ixeyboard in keyboard enclosure with keyboard layout Slovenian - SL Jxeyboard in keyboard enclosure with keyboard layout Slovenian - SL			2	Mounted on stand or elbow below
3 Protected outdoor area (breather available) 31 Keyboard (layout) 0 no keyboard, no keyboard enclosure D Keyboard in keyboard enclosure with keyboard layout German - DE (QWERTZ) E Keyboard in keyboard enclosure with keyboard layout American - US (QWERTY) F Keyboard in keyboard enclosure with keyboard layout French - FR (AZERTY) G Keyboard in keyboard enclosure with keyboard layout Swiss German - CH H Keyboard in keyboard enclosure with keyboard layout Spanish - ES I Keyboard in keyboard enclosure with keyboard layout Slovenian - SL J Keyboard in keyboard enclosure with keyboard			3	Mounted at ceiling or elbow on top
Steyboard (layout) D	30	Outdoor Installation	0	no outdoor installation – indoor only
D Keyboard in keyboard enclosure with keyboard layout German - DE (QWERTZ) E Keyboard in keyboard enclosure with keyboard layout American - US (QWERTY) F Keyboard in keyboard enclosure with keyboard layout French - FR (AZERTY) G Keyboard in keyboard enclosure with keyboard layout Swiss German - CH H Keyboard in keyboard enclosure with keyboard layout Spanish - ES I Keyboard in keyboard enclosure with keyboard layout Slovenian - SL J Keyboard in keyboard enclosure with keyboard			3	Protected outdoor area (breather available)
layout German - DE (QWERTZ) E Keyboard in keyboard enclosure with keyboard layout American - US (QWERTY) F Keyboard in keyboard enclosure with keyboard layout French - FR (AZERTY) G Keyboard in keyboard enclosure with keyboard layout Swiss German - CH H Keyboard in keyboard enclosure with keyboard layout Spanish - ES I Keyboard in keyboard enclosure with keyboard layout Slovenian - SL J Keyboard in keyboard enclosure with keyboard	31	Keyboard (layout)	0	no keyboard, no keyboard enclosure
Iayout American - US (QWERTY) F Keyboard in keyboard enclosure with keyboard layout French - FR (AZERTY) G Keyboard in keyboard enclosure with keyboard layout Swiss German - CH H Keyboard in keyboard enclosure with keyboard layout Spanish - ES I Keyboard in keyboard enclosure with keyboard layout Slovenian - SL J Keyboard in keyboard enclosure with keyboard			D	
layout French - FR (AZERTY) G Keyboard in keyboard enclosure with keyboard layout Swiss German - CH H Keyboard in keyboard enclosure with keyboard layout Spanish - ES I Keyboard in keyboard enclosure with keyboard layout Slovenian - SL J Keyboard in keyboard enclosure with keyboard			E	
Iayout Swiss German - CH H Keyboard in keyboard enclosure with keyboard layout Spanish - ES I Keyboard in keyboard enclosure with keyboard layout Slovenian - SL J Keyboard in keyboard enclosure with keyboard			F	
I layout Spanish - ES I Keyboard in keyboard enclosure with keyboard layout Slovenian - SL J Keyboard in keyboard enclosure with keyboard			G	
J Keyboard in keyboard enclosure with keyboard			Н	
			I	
			J	

	L/	Kayboard in kayboard analogura with kayboard
	n	Keyboard in keyboard enclosure with keyboard layout Nordic (Swedish, Finnish, Norwegian, Danish)
	U	Keyboard in keyboard enclosure with keyboard layout Hungarian - HU
	В	Keyboard matrix
Integrated pointing device	0	no integrated pointing device in keyboard enclosure
	1	IP68 trackball in keyboard enclosure
	4	Touchpad in keyboard enclosure
	5	Joystick in keyboard enclosure
Optionale devices 1	0	no optional devices
Readers 1	0	no reader 1
(versions)	5	UB03-xxx-C05-USB (CRYPT) card reader
	6	UB03-xxx-C06-USB (ASCII) card reader
Readers 1	0	no reader 1
(position)	1	Reader in enclosure, right-hand side
	2	Reader in enclosure, left-hand side
	3	Reader at keyboard enclosure, right-hand side
Control devices	0	no control device
	1	EM-STOP in enclosure, right-hand side
	2	EM-STOP in enclosure, left-hand side
	3	EM-STOP in enclosure, front side, middle, bottom
Readers 2	0	no reader 2
(versions)	1	Wired barcode scanner (BCR-IDM x6x) (with VM125-ex power supply)
	2	Bluetooth barcode scanner (BCR-IDMBT x6x) (with VM125-ex power supply)
	3	Wired 2D barcode scanner (BCR-IDM 26x) (with VM125-ex power supply)
	4	Bluetooth 2D barcode scanner (BCR-IDM 26x) (with VM125-ex power supply)
Readers 2	0	no reader 2
(position)	1	Reader at enclosure, right-hand side
	2	Reader at enclosure, left-hand side
	3	Reader at keyboard enclosure
Further options	0	no further options inside enclosure
(inside enclosure)	1	Y-Purged with barrier (FR, CFR enclosures)
	2	USB Plug downwards (FR, CFR enclosure)
	3	USB Plug front side right
Other markings	Υ	Marking for new field system code
	L	Marking for loan device
	Z	Marking for field system with document drawing number
	S	Marking for field system fitted with replacement parts
	Optionale devices 1 Readers 1 (versions) Readers 1 (position) Control devices Readers 2 (versions) Readers 2 (versions)	B Integrated pointing device


4.4 Available configuration versions

Variant	E-Box	Power supply	Processor type	Main memory	Data memory	Ethernet / Data
E52A M52A	Standard	24 VDC	ATOM E3940	up to 16 GB	up to 256 GB	10/100/1000Base-TX
	Standard	24 VDC	ATOM E3940	up to 16 GB	up to 256 GB	10/100/1000Base-TX
						10/100/1000Base-TX
E54A			ATOM E3940			2x 10/100/1000Base-TX
M54A	PRO	24 VDC or 230 VAC	or	up to 16 GB	up to 256 GB	10/100/1000Base-TX + 1x 100Base-FX
			Intel Core i5			10/100/1000Base-TX + 2x 1000Base-SX
						10/100/1000Base-TX + 2x 1000Base-LX
	Standard	24 VDC	ATOM E3940	up to 16 GB	up to 256 GB	10/100/1000Base-TX
						10/100/1000Base-TX
E59A	PRO 24 VDC or 230 VAC		ATOM E3940 or Intel Core i5	up to 16 GB	up to 256 GB	2x 10/100/1000Base-TX
M59A						10/100/1000Base-TX + 1x 100Base-FX
						10/100/1000Base-TX + 2x 1000Base-SX
						10/100/1000Base-TX + 2x 1000Base-LX
E79A M79A	PRO	24 VDC or 230 VAC	-	-	-	-

4.5 Dimensions


4.5.1 Panel-mount devices

4.5.1.1 Front




	Dimensions (mm)		
Item	E/Mx2A	E/Mx4A	E/Mx9A
Α	330	415	565
В	241	310	400


4.5.1.2 Side



	Dimensions (mm)		
Item	E/Mx2A	E/Mx4A / E/Mx9A with E-Box Standard	E/Mx4A / E/Mx9A with E-Box PRO
С	101	108	117


4.5.1.3 Cutout






			Dimensions (mm)	
Item	E/Mx2A	E/Mx4A with E-Box Standard	E/Mx4A with E-Box PRO	E/Mx9A with E-Box Standard	E/Mx9A with E-Box PRO
Α	310	396		547	
В	221	291		382	
С	92	98 108		99	108
	Cut-out tolerances [mm]				
	+1.0 mm / -0.5 mm			+-0.5	mm


4.5.2 ORCA-OFR Operator Station






Dimensions (mm)		
A B C		
708	524	176

4.5.3 ORCA-OFR Operator Station with keyboard






Dimensions (mm)					
Α	В	С	D	Е	F
708	794	404	52°	18°	5°

4.6 Connection box

4.6.1 E-Box Standard




Item	Designation
1	Cover of connection box (removed in picture, circled in green)
2	Ex i Connection terminals (circled in orange)
3	Ex e Connection terminals (circled in blue)
4	Screws plugs (picture shows delivery status)
5	M4 Ground connections



Cable glands (number, size, etc.) see 17.3 Cable glands

4.6.2 E-Box PRO




Item	Designation	
1	Cover of connection box (removed in picture, circled in green)	
2	Ex i Connection terminals (circled in orange)	
3	Ex e Connection terminals (circled in blue)	
4	Fibre optic connectors (optional) (circled in red)	
5	Cable glands (picture shows delivery status)	
6	M5 Ground connections	



Cable glands (number, size, etc.) see 17.3 Cable glands

4.7 Operating elements



Item	Designation	
1	LEDs	
2	Display	
3	Sensors 1 to 4	
4	RFID card reader (optional)	

4.7.1 Sensors

Pictogram	Meaning	Description
	Disable touch	Disables the touch function of the device. Press key for 2 seconds. Key lights up orange when touch is deactivated.
☆	Brightness adjustment	"Darker" key to reduce the backlight brightness
	Brightness adjustment	"Brighter" key to increase the backlight brightness
Fn	Function key	Freely assignable function key. Set as F8 as standard.



The keys briefly light up when pressed.

4.8 LED status display

Pictogram	LED colour	Status	Meaning
(')	orange	lit	Device is live. Internal power supply ok. Device switched off.
	white		HMI device in operation.
0	white	flashing	Accessing system disk (Solid State, HDD)
80	white *	off	no connection / no activity at Ethernet port
or		lit	Existing connection at Ethernet port
1		flashing	Activity at Ethernet port




If the device contains both FO interfaces (modules), the LEDs will show the activity at the FO Ethernet ports.

There will be no display for the onboard copper interface.

4.9 Markings on the device


4.9.1 Position

4.9.1.1 Field system label




Item	Designation
1	Two-part PM field system type plate on E-Box Standard
2	Three-part PM field system type plate on E-Box PRO

4.9.1.2 Label on E-Boxes




lt	em	Designation
	1	Label on inside of E-Box Standard
	2	Label on inside of E-Box PRO

4.9.1.3 Label on display boxes



Item	Designation	
1	Label on back of 12" display box	
2	Label on back of 15" display box	
3	Label on back of 22" display box	

4.9.1.4 Warning label



Item	Designation		
1	Warning label on E-Box Standard, both sides, multilingual		
2	Warning label on E-Box PRO, both sides, multilingual		




Text of warning label for DE and EN:

Nicht öffnen. Dieses Gehäuse wurde dauerhaft verschlossen und kann nicht repariert werden. Warnhinweis – nicht in einem Bereich öffnen, warten oder Instand setzen, in dem eine explosionsfähige Atmosphäre vorhanden sein kann.

Do not open. This container has been permanently sealed and cannot be repaired. Warning – Do not open, maintain or service in an area where an explosive atmosphere may be present.

4.9.1.5 Safety label



Item	Designation		
1	Safety label across E-Box and display box for 12" device with E-Box Standard		
2	Safety label across E-Box and display box for 15" device with E-Box Standard		
3	Safety label across E-Box and display box for 15" device with E-Box PRO		
4	Safety label across E-Box and display box for 22" device with E-Box Standard		
5	Safety label across E-Box and display box for 22" device with E-Box PRO		

4.9.2 Design of label / type plate

4.9.2.1 Field system label / type plate


View of E-Box Standard label as an example



View of E-Box PRO label as an example




Type plate section:



Item	Designation		
1	Area of E-Box label		
2	Area of D-Box label		
3	Data of field system with serial and article number of E-Box and date of manufacture		
4	Address of manufacturer		
5	Warning notes		
6	Temperature range and IP		
7	Other information and reference to documentation		
8	QR code		
9	CE marking		
10	Marking according to WEEE directive 2012/19/EU		
11	Space for further markings		

4.9.2.2 **E-Box Label**

Example view of an E-Box label




4.9.2.3 **D-Box Label**

Example view of a D-Box label:

Label for D-Box on type plate Label on D-Box ORCA01E0003000000 ORCA01E0003000000 STAHL E02A10000-00003N00000200-000000000000000 Article-No. D-Box: 294338 Article-No. D-Box: Date: HW-Rev: R. STAHL HMI Serial-No. D-Box:: 294338 01.01.01 02.23 Systems GmbH X47110815X Serial-No. D-Box: Checked: 50829 Cologne Date: X47110815X Made in Germany Name 02.23 www.r-stahl.com

E-Box and D-Box labels"

4.9.2.4 Key to E-Box and D-Box labels



Item	Designation		
1	Box family code		
2	Box type key code		
3	Box article number		
4	Box serial number		
5	Box manufacture date and hardware revision		
6	Name of testing body		
7	Address of manufacturer		
8	QR code		
9	Rated values on E-Box label on type plate		

4.10 Ex marking

4.10.1 ATEX / IECEx

Ex marking ATEX / IECEx according to IEC 60079-0 and ATEX directive 2014/34/EU.

ORCA01E* HMI series

Version	2014/34/EU prefix	Ex marking	
Gas		Ex eb ib qb [ib] [ia Ga] IIC T4 Gb	
Dust		Ex tb [ib] [ia Da] IIIC T115°C Db	

ORCA01M*HMI series

Version 2014/34/EU prefix		2014/34/EU prefix	Ex marking	
	Gas		Ex ec ib qb [ib Gb] [ia Ga] IIC T4 Gc	
Dust 🔯 II 3(1) D			Ex tc [ib Db] [ia Da] IIIC T115°C Dc	

5 Operating systems and drivers

5.1 Windows® 10 IoT Enterprise 2019 / 2021 LTSC operating system

The operating system is based on Windows 10 for PC platforms with 64 bit x86 processors. For the LTSC (Long-Time-Service-Channel) versions, Microsoft guarantees 10 years of security updates and new builds with feature updates only every 2-3 years, with these being optional. The LTSC versions are ideal for industrial applications and feature additional security components such as write filters (UWF) and HORM (start of a system snapshot from the RAM plus write protection).



* The HORM function is currently not supported in 2021 LTSC!

From 2016 LTSB onwards, Microsoft has tied its licensing model to the processor performance:

ENTRY for AMD® GX and ATOM™

VALUE for Intel® Core i5™ HIGH for Intel® Core i7™

The license for the Windows 10 IoT Enterprise 2019 / 2021 LTSC operating system is included in the image. When delivered, the devices have already been registered and activated.

The EOL (End of Life) date for Windows 10 IoT Enterprise 2019 LTSC for support and updates has been set by Microsoft to 09.01.2029 and for 2021 LTSC to 13.01.2032.

5.1.1 Recovery



If a Panel PC is reset to the factory state (recovered) it will remain registered and will have to be reactivated.

This requires an active internet connection to a Microsoft server.

5.1.2 Proprietary Windows installations and drivers



The Windows 10 IoT license key is tied to STAHL images. The installation of own Windows 10 operating systems requires a separate license key. All necessary drivers are provided by R. STAHL HMI Systems GmbH. Please contact our Support department.

5.2 Data back-up

5.2.1 Recovery Stick



A recovery stick is required to restore the Panel PC devices to their factory state. This recovery stick (USB-drive, also available as an intrinsically safe version) contains the factory image, with which the system can be restored to delivery status within a very short time.

You can restore the HMI devices to their factory state only with the aid of this recovery stick. As an option, the recovery stick can also contain a backup software, with which you can back up your own device configuration.

5.2.2 Back-up

It is the sole responsibility of the operator to generate a back-up of the HMI devices and their overall function.

 Any back-ups generated of the HMI devices must always be stored on external storage media.

5.2.3 Switching off / closing down



The Microsoft Windows operating system stores key data in the main memory, regardless of the application, and has to store this data on the hard disk before the HMI device is switched off.

It is therefore important for the safe and correct operation that the HMI device is "shut down" properly and not simply switched off.

Otherwise the existing image of the HMI device may be damaged, rendering the device non-functioning. After the data has been stored, Windows informs the user that the HMI device can now be switched off.


5.2.4 Loss of data

- In the case of applications that require constant writing into memory, R. STAHL HMI Systems GmbH recommends you use external storage media (USB sticks, network servers) for these write processes.
- Avoid cyclical writes (log files, databases, etc.) to the SSD.

The endurance of an SSD depends on the number of write cycles (TBW / terabytes written). Writing to the SSD with a simultaneous drop in voltage is most likely going to result in data loss.

5.3 License sticker

The license sticker for the Windows 10 Ultimate operating system is located on the side of the E-Box.



5.4 UPDD touch driver

The UPDD touch driver is a copyrighted, licensed software for the exclusive use with R. STAHL HMI Systems GmbH touch systems.

• Do not load this driver on or use with other devices.

6 Transport and storage

NOTE

Missing or damaged packaging during transport and storage If the device is transported or stored without packaging, shocks, vibrations, pressure and humidity can directly impact the device. Damaged packaging indicates that the device has been subjected to and possibly been damaged by outside influences. This may result in faulty functionality.

- Check the state of the packaging.
- Report any damage sustained in transport to the haulier responsible and have it confirmed.
- Transport and store the device in undamaged packaging, ideally the original packaging.
- Transport and store the device carefully and in accordance with the safety notes (see chapter <u>3 Safety</u>).
- Transport and store the device in undamaged packaging, ideally the original packaging.
- Ensure specified storage temperature range is not exceeded (see chapter <u>17.1.4 Ambient conditions</u>).
- Store the device in a dry place free of vibrations.
- Do not drop the device.

7 Unpacking

- Unpack the device at its final destination.
- Check against the delivery note that the contents are complete and undamaged.
- Contact the manufacturer if the contents are incomplete, damaged or not what you have ordered.
- Dispose of the packaging materials according to local regulations.

8 Mounting and installation

8.1 Note on mounting and installation

Observing the following points will ensure a professional and safe assembly and installation

- Only use threads or holes already present in the enclosure.
- Mount the device carefully and strictly in accordance with the safety notes (see chapter <u>3 Safety</u>).
- Study the installation conditions and assembly instructions in these operating instructions carefully and follow them to the letter.
- Completely close the ORCA-OFR enclosure (to the second stop) to ensure IP tightness (seal)!
- The devices may only be installed and operated in an undamaged, dry and clean condition! Any damage may compromise the explosion protection!
- National assembly and installation rules and the generally accepted rules of technology must be observed. The device and its accessories must be installed and operated according to applicable standards, directives and installation guidelines.
- Only use suitable tools for the installation.
- Do not open the connection box when live.
- Disconnect the device from supply before separating E-Box and D-Box for servicing.
- Tightening torque for connection box screws: 3.5 to 3.7 Nm. Tightening torque for mounting of E-Box and D-Box (for servicing): 3.5 to 3.7 Nm.
- Installation according to Control Drawing 10608602.
- The devices are delivered with screw plugs. Before installation, mount the required cable glands on the device.
- The PA / earth connection of the DC device variants is internally connected to terminals X1-3 and X1-4 of the power supply connection.

8.2 Requirements for site of installation



Mount and install the device in such a way that it is always operated within the permissible temperature range.

- Observe the stipulated hazardous zones: ORCA01M* devices may only be installed in Zone 2 and Zone 22.
- The site of installation must be stable and suitable for the dimensions of the device, and able to bear the load of its weight and that of any necessary attachments.
- Ambient temperature: -20 °C ≤ Ta ≤ +55 °C (for Panel-mount device, at OFR +50 °C) at place of installation. Relative humidity 90 % at +40 °C, non-condensing. Outdoor installation permitted up to a height of 2,000 m. Ex-enclosure protection type IP65. The device may be installed and operated in any position.
- Electric parameters of a maximum of 250 V / 17 A must be guaranteed at the place of location.
- In the case of AC models: install an easily accessible disconnection mechanism outside of the device, which can be used to interrupt all conducting wires but not the protective conductor.

- Avoid touch screen contamination by saltwater: conductive liquids on the touch display can result in incorrect or phantom operations. This applies in particular to salt water.
- Protect the device against rain, snow and splashes: excessive amounts of standing or running water will disrupt operation and may cause erratic cursor movement. This protection can be achieved by using a canopy or some other protective roof-type construction. Offshore, strong winds, saltwater and rain will have to also be taken into consideration.

8.3 Mounting types

The device may be installed and operated in any position. R. STAHL recommends the following types of mounting:

Panel mount, wall mounting, mounting on stand / elbow.

8.4 Front installation


The ORCA device platform Panel-mount devices can be mounted inside an enclosure with suitable cut-out with the aid of a fixing frame. This type of mounting is approved for installation in Ex e, Ex p or Ex tb enclosures.


A 20 mbar excess pressure was tested for Ex p applications.

The fixing frame is used to fix the device inside the cover cut-out of the enclosure. It is mounted from the back.

Tightening torque		
Fixing frame screws	3.5 to 3.7 Nm	


8.4.1 Panel-mount – installation









The devices are delivered with screw plugs. Before installation, mount the required cable glands on the device.









For dimensions of mounting cut-out of enclosure, see chapter 4.5.1.3 cutout




- Assembly of mounting frame
 - consisting of 2 identical L-shaped frame parts
 - all M4 screws (Torx TX20) pre-mounted and secured with captive washers (x2A and x4A frame with 16 screws, x9A frame with 26 screws)



• Slide the fixing frame over the back of the device



- Tighten all fixing frame screws with 3.5 to 3.7 Nm.
- Observe the order in which screws should be tightened (x4A and x9A frames accordingly)



8.5 Installation



Explosion hazard due to improper installation!

Non-compliance may result in fatal or serious injuries.

- Ensure the atmosphere is non-explosive.
- Make sure that the device is not damaged.
- If the device is connected to the mains:
 - Disconnect the device from the power supply.
 - Isolate all circuits and wait 20 minutes before opening the connection box!



Explosion hazard due to electrostatic charge!

Non-compliance may result in fatal or serious injuries.

Do not apply protective foil to the touch display.



Danger of laser radiation at emitting diode (TD-A, TD-B) or at the end of the fibre optic cable.

Eye injury

The laser diodes in the operating devices, media converters and switches emit invisible laser radiation:

100Base-FX - 1300 nm FO-MM / 1000Base-SX - 770 ... 860 nm FO-SM / 1000Base-LX - 1270 ... 1355 nm

According to EN 60825-1, the laser diode is assigned to the laser class 1.

• Do not view the laser radiation directly (within a distance of 100 mm) with optical instruments (e.g. magnifiers, microscopes).

8.5.1 General information on electric connection


- Connect cables carefully.
- Do not screw down on the cable insulation.
- Do not switch cables.
- Observe code of practice when connecting cables.
- Firmly screw down wires.
- Pay attention to the voltage specified on the device:
 - o Connect DC devices to 24 VDC only.
 - Connect AC devices to 85 to 250 VAC only.
 - The PA / earth connection of the DC device variants is internally connected to terminals X1-3 and X1-4 of the power supply connection.
- Pay attention to specified torques for screws to avoid damage to threads.
- Suitable measures against electrical surge during lightning strike may be necessary.
- Ensure cable shields are firmly secured on all sides. We recommend using suitable cable clips or EMC connections.

8.5.2 Connecting device to power supply

- 1. Open the cover of the connection box (see chapter 4.4 Connection box).
- Connect cable to X1 POWER terminal (see chapter 19.1 Connection overview terminal assignment). Ensure correct polarity and power supply (AC or DC).

8.5.3 Grounding the device

- Ground the devices with a core cross section of at least 4 mm² or in line with applicable standards, or connect to the equipotential bonding conductor of the hazardous area.
- Preferably use earth connection at the side closest to the power supply terminals.



Tighten earth connection screws with a torque of 3.5 to 3.7 Nm.



Fastening material for the earth connection is located at the device.

The PA / earth connection of the DC device variants is internally connected to terminals X1-3 and X1-4 of the power supply connection.

8.5.4 Connecting data cable

• Connect the data cables according to the terminal diagram (for copper connections) or connect them to the sockets (for FO connections).

8.5.5 Mounting the cover of the connection box

Tightening torque		
connection box cover screws	3.5 Nm to 3.7 Nm	

8.5.6 Connecting associated equipment

The connection box includes mounting options for associated equipment such as cable glands, cable connectors, buttons.

Cable glands or other accessories used in the threads of the connection box must be suitable and certified for the area of installation and might have to be adapted. The applicable Ex requirements and IP65 or above must be met. Potential changes to the ambient parameters such as temperature must be taken into account.

- Observe the specific requirements of the associated equipment used (e.g. permitted cable diameter for cable glands, tightening torques, cable clamps).
- Observe country-specific regulations, in particular any ambient parameters that may be different (e.g. ambient temperature range).
- Attach an easily accessible disconnection mechanism to interrupt the power supply on the outside of the device.
- Close unused openings with a blind plug.
- Cable glands with parallel threads must have the following characteristics:
 - o Tolerance class 6H or higher
 - o additional seal

8.5.7 Cable glands

In their factory state, the devices are equipped with cable glands or screw plugs. They have been chosen to comply with all relevant certifications of the device. The device's ex-relevant markings also cover the bushings, which are not necessarily separately marked when included in the delivery.

- Seal unused cable glands with certified screw plugs.
- Close any open enclosure holes without cable glands with a certified screw plug. Such
 certified screw plugs must be approved for the following areas or higher:
 - Certified zone
 - Permitted temperature range
 - o Country approval (e.g. ATEX for Europe) of the device
- Alternative, similar and certified cable glands may be used provided they have an equal or higher area of certification (zone) and permitted temperature range, and the same country approval (e.g. ATEX for Europe) as the HMI device.
- Use cable glands with cap nut and without strain relief clamp for permanently installed cables and electrical lines only.
- Install the device in such a way that there is no mechanical impact (tensile force) on the cables. Fix the cable and effectively protect against damage.
- Observe recommended tightening torques. Too low or too high tightening torques might have a negative impact on the type of protection, sealing or strain relief.
- Before commissioning, check any screws that are already mounted and tighten them if necessary.
- Pre-mounted cable glands are designed for non-armoured cables.

Thread sizes

E-Box PRO: 1x M25x1.5; 3x M20x1.5; 7x M16x1.5

E-Box Standard: 2x M20x1.5; 5x M16x1.5

Optional, pre-mounted cable glands suitable for cable diameters ranging from

M25 = 14...18 mm, M20 = 6...12 mm, M16 = 4...8 mm.

Cable glands

M25 = 14...18mm (Hummel AG part no.: 1.640.2500.50)

M20 = 6...12 mm (Hummel AG part no.: 1.640.2000.50)

M16 = 5...10mm (for keyboard KB2) (Hummel AG part no.: 1.640.1611.50)

M16 = 4...8mm (Hummel AG part no.: 1.610.1600.30)

Screw plugs:

M25 (Hummel AG part no.: 1.640.2500.50) M20 (Hummel AG part no.: 1.640.2000.50) M16 (Hummel AG part no.: 1.640.1611.50)



The documentation from the manufacturer for the cable glands and screw plugs must be taken into account.

Tightening torque		
Cable glands	Depending on cables used: • Individually determine and apply required tightening torques.	
Cable glands (installed exfactory)	In the case of factory-supplied systems, all components are installed correctly and in accordance with applicable standards.	

8.5.8 Electric connections of interfaces X1, X2, X3, X4, X5, X6, X7, X9, X10, X11, X12 and X13

Stripping length	9	mm
Mounting torque	0.5 0.6	Nm

Connectable conductor cross section			
Rigid	0.2 2.5 (24 14)	mm² (AWG)	
flexible	0.2 2.5 (24 14)	mm² (AWG)	
Multi-conductor connection (flexible with core end sleeve with or without plastic sleeve) (two conductors with the same cross section and conductor type)			
• rigid	0.2 0.75 (24 18)	mm² (AWG)	
flexible	0.25 1.5 (24 16)	mm² (AWG)	

Notes on screw connectors:

- Ensure that the following maximum rated current values are not exceeded:
 - The maximum rated current value for every contact of the X1 screw connector is 17 A.
- Values that must not be exceeded at the place of installation:

Voltage: max. 250 V

o Short-circuit current: max. 1500 A

- Only use copper wires and cable glands with the following characteristics for connections to the device:
 - o For -20 °C < Ta ≤ +30 °C: copper wires / cable glands approved for at least 70 °C
 - o For +30 °C < Ta ≤ +55 °C: copper wires / cable glands approved for at least 95 °C



Observe and apply tightening torques recommended for connection terminals.

8.6 Using USB interfaces

Hardware and co	Hardware and connection					
	in	intrinsically safe USB devices non-intrinsically		sically safe equipment		
Connection to	safe area	Hazardous areas	Device	safe area	Hazardous areas	
X5 (Ex i)	x	e.g. x KB2-*-HSG-*- keyboard cable		_	_	
X6 (Ex i)	x	e.g. KB2-*-HSG-*- pointing device - cable		-	_	
X7 / X8 (Ex i)	x	x	e.g. USBi Drive	-	_	
X3 (Ex e)	_			any USB device	explosion-protected but non-intrinsically safe devices	
at E-Box PRO				only for "b	ous powered / passive devices"	
X11 (Ex e)	-			any USB device	explosion-protected but non-intrinsically safe devices	
at E-Box PRO		E-Box PRO			module is equipped ous powered / passive devices"	
X12, X13 (Ex e)	X12, X13 (Ex e)			any USB device	explosion-protected but non-intrinsically safe devices	



See also notes on interfaces in chapter <u>19.1. Connection overview terminal assignment</u>.

9 Initial start-up

Conditions:

The device has been installed correctly.

The device has been connected to the equipotential bonding.

- 1. Since factors such as storage or temperature can have an impact on the cables and cable glands, check the following connections:
 - o Connection terminals
 - o Existing screw connections
- 2. Switch on power supply.
 - o The device will start up in its standard configuration.
- 3. Follow the instructions on the screen.

10 (Re-) Commissioning

- 1. Check the device is correctly installed:
 - Connection terminals
 - Existing screw connections
- 2. Check the device for visible damage.
 - Only commission the device if there is no visible damage and if it has been correctly installed.
- 3. Switch on power supply.
 - o The device will start up with the configuration saved last.
 - If the connected systems can be reached, communication will be established within the existing parameters.

11 Operation



Explosion hazard due to damaged device!

Non-compliance may result in fatal or serious injuries.

In case of damage or changes to the factory state (for example if the device is leaking small glass beads):

- Decommission device immediately.
- Contact manufacturer.



Explosion hazard due to electrostatic charge!


Non-compliance may result in fatal or serious injuries.

• Do not apply protective foil to the touch display.



Hot surfaces!

Non-compliance may result in minor burns.



• Do not touch the device.

NOTE

Display damage due to permanent display of identical pattern Non-compliance will result in screen burn-in.

• Use screen savers or regularly move the screen pointer if a specific pattern is displayed permanently.

11.1 Operating the touch display

NOTE

Touching the touch screen with pointed or sharp items

Non-compliance may result in damage to the touch display, shorter life-span or total breakdown!

 Only operate the touchscreen with your finger or thin / special gloves.

NOTE

Preventing malfunction and functional impairment

Non-compliance will result in malfunction and functional impairment of the touch display!

- Device must be integrated into the facility's functional earth.
- The functional earth is used to suppress electromagnetic disturbance.

Incorrect operation of the touch display may result in accidental functions and errors. The device will then be unable to execute orders, may execute them incorrectly or in a way not intended.

- Do not realise safety-relevant functions via the touch display.
- Avoid accidental multiple touches.
- Do not touch the touch display across a large section.
- Only use fingers, thin gloves or special gloves for operation.
- Before operating the device, thoroughly acquaint yourself with the multi-touch functions of the operating system and the application.
- Avoid contamination of the touch display with salt water.

11.2 Switching the device on and off

11.2.1 Without optional on/off button

The device is switched on and off via the power supply.

R. STAHL recommend you switch off the ORCA platform devices via the respective Windows / Remote Image function.

11.2.2 With optional on/off button

The device is switched on and off with an optionally available on/off button. The button function is defined via the operating system and functions like power button of a notebook.

R. STAHL recommend you switch off the ORCA platform devices via the respective Windows / Remote Image function.

11.3 Teaming function

Teaming function						
E-Box	Standard	PRO				
		Interface				
Processor	1TX	2TX				
ATOM	no	yes yes yes yes				
Intel Core i5	-	yes	yes	yes	yes	

- Providing redundancy due to automatic switch to a different network adapter.
- Using the Ethernet adapters in the team as standby adapters, realising redundancy, making the system more fail-safe.
- Bundle the speed of the Ethernet adapters in order to increase performance.



For a description of the function and its settings refer to the Remote HMI V6 software manual (industrial-grade Thin Client firmware).

12 Maintenance, overhaul and repair



Explosion hazard due to damaged seal or leaking of filling material!

Non-compliance may result in fatal or serious injuries!

- In case of damage or changes to the factory state immediately decommission the device.
 - If the device leaks filling material (small glass beads) it must be decommissioned immediately.
- Contact manufacturer.



Explosion hazard due to incorrect maintenance or repair!


Non-compliance may result in fatal or serious injuries!

- Ensure the atmosphere is non-explosive.
- Make sure that the device is not damaged.
- Do not open the enclosure.
- If the device is connected to the mains:
 - Disconnect the device from the power supply.
 - Isolate supply and all circuits and wait 20 minutes before opening the terminal boxes.



Hot surfaces!

Non-compliance may result in minor burns!



• Do not touch the device.

Additional for ORCA01M* HMIs:

Do not open, service or repair in an area where an explosive atmosphere may be present.

12.1 Changing the battery

The internal battery may only be replaced by the manufacturer.

12.2 Servicing

The enclosure is sealed and cannot be opened.

When servicing the device, check the following points in addition to those stipulated in the national regulations:

- Damage to seals: cracks or other visible damage to the device enclosure / front glass and / or the protective enclosure.
- All cables and conductors securely connected: cables tightly clamped
- All cables and conductors undamaged
- Compliance with permitted temperature range
- Mounting fits securely, all screws tightened fast
- Ensure the device is used as intended

12.3 Maintenance

The devices are maintenance-free across their entire lifespan.

- Focus on the following during system maintenance:
 - Seal wear, front screen / glass damage
 - o screws properly tightened
 - o all cables and conductors correctly connected and undamaged

12.4 Repair

The display and E-Box modules cannot be repaired by the customer.


- Any repair on the device is to be performed by R. STAHL only.
- The modules may be sent back separately.
- The modules must be dismounted by qualified staff only (see chapter <u>3.3 Personnel qualification</u>).

12.4.1 Mounting / dismounting the modules

The ORCA series HMIs consist of a display box module and an E-Box module which are mounted together. These modules can be replaced for repair purposes.

Dismounting modules:

- Disconnect all circuits from the power supply and wait for 20 minutes.
- Remove the connection box cover.
- Disconnect cables and external earthing.
- Unscrew the E-Box screws (see markings).



Rear view E-Box Standard

Rear view E-Box PRO

- Lift the E-Box vertically and evenly.
- Do not damage seal.
- Protect plug connector board.



Explosion hazard due to damaged seal!

Non-compliance may result in fatal or serious injuries.

- Ensure the atmosphere is non-explosive.
- Ensure seal is undamaged.
- Ensure seal is correctly positioned.
- Replace damaged seal immediately.

NOTE



Possible mechanical or electric damage to the plug connector board.

If the plug connector board is not protected with a cover and suitable ESD measures it may be damaged and the modules' function may be impaired.

The plug connector board is a device interface which has been constructed to contain limited ESD protective measures and which can be serviced by trained personnel.

To prevent any damage to the components, suitable mechanical and ESD protective measures must be taken.

- Carry out ESD protective measures before dismounting.
- Once dismounted, protect plug connector board.

Mounting modules:

The steps for mounting the modules are those described in "Dismounting modules" in reverse.

- After removal and installation of the module, the device must correspond to the delivery condition again.
- The chapter on residual risks must be observed. In case of non-observance the explosion protection can be cancelled.
- Where applicable, re-install plug connector board.
- Seal positioned correctly and undamaged.
- Position the E-Box with its 3 lateral fins vertically and in parallel in the corresponding recesses of the D-Box.
- Grease screw connections between E-Box and D-Box.
- Tighten by hand one screw on the right-hand side and one on the left-hand side of the E-Box.
- Insert and tighten all remaining screws crosswise and with the correct torque.

Tightening torque	
Screws connecting the display and the E-Box	3.5 to 3.7 Nm

- Connect cables and external earthing.
- Close connection box cover.
- Operate device.

13 Returning the device

Only return or package the devices after consulting R. STAHL. Contact the responsible representative from R. STAHL. R. STAHL's customer service is available to handle returns if repair or service is required.

Contact customer service via E-mail or telephone:

- E: service.dehm@r-stahl.com
- T: +49 221 76806 3000

Requesting a RMA ticked via our website:

- Go to <u>r-stahl.com</u>.
- Under "Support" > "RMA" > select "RMA-REQUEST".
- · Fill out the form and send it in.
- You will automatically receive and E-mail with an RMA ticket.
- Print out the RMA ticket.
- Clearly copy the RMA number onto the outside of the package.
- Send the device with the RMA ticket included in the package to R. STAHL HMI Systems GmbH (see chapter 1.1 Manufacturer for the address).

14 Cleaning

- Check the device for damage before and after cleaning it. Decommission damaged devices immediately.
- Devices located in hazardous areas may only be cleaned with a damp cloth to avoid electrostatic charge.
- When cleaning with a damp cloth, use water or mild, non-abrasive, non-scratching cleaning agents.
- Do not use abrasive cleaning agents or solvents.
- Never clean the device with a strong water jet, such as a pressure washer.

15 Disposal

- Observe national, local and statutory regulations regarding disposal.
- Separate materials for recycling.
- Ensure environmentally friendly disposal of all components according to statutory regulations.

16 Accessories

NOTE	Malfunction or damage to the device due to the use of non- original components.
	Non-compliance may result in material damage. Only use original accessories by the manufacturer.

17 Appendix A

17.1 Technical data E/M5xA

17.1.1 General

Function / Equipment	PM E52A PM M52A	PM E54A PM M54A	PM E59A PM M59A	OS E59A OS M59A		
Technology		Panel PCs / Thin Clients				
E-Box	Standard	Standard Standard or PRO				
HMI-type	P	Panel-mount device Operator Station				
Enclosure type		-	ORCA OS enclosure OFR			

17.1.2 Electrical data

Function / Equipment	E52A M52A	E54A M54A	E59A M59A		
Power supply	24 VDC	24 VDC or 230 VAC			
AC rated operational voltage	-	230 V			
Voltage range AC	-	100 V - 24	0 V (+4.1 % / -15 %)		
DC rated operational voltage	24 V		24 V		
Voltage range DC	24 V (+30 % / -20 %)	24 V ((+30 % / -20 %)		
Power consumption AC	-		1 A		
Current consumption DC	3 A		3 A		
Frequency range	-	4	17 – 63 Hz		
Rated operational power	27 – 60 W	2	27 – 60 W		
internal fuses AC	-		2 A		
internal fuses DC	4 A		6.3 A		
Terminal box	Power supply direct in	wer supply direct in integrated connection box (separate Ex e and Ex i compartments)			
Connections		via screw terminals,	green		
Conductor type	Flexible conductors 0.2 to 2.5 mm² (AWG24 to AWG12) rigid conductors 0.2 to 2.5 mm² (AWG24 to AWG12) (details see chapter 8.5.8 Electric connections of interfaces X1, X2, X3, X4, X5, X6, X7, X9, X10, X11, X12 and X13)				
max. operating voltage Um		250 VAC			
Processor type	Intel® ATOM™ E3940	Intel® ATOM™ E3940 Intel® Core i5™ 8365UE			
Processor details	1.6 / 1.8 GHz Quad Core		1.8 GHz, Quad Core 1 GHz, Quad Core		
Graphics controller	Intel® HD-Graphics 500		el® HD-Graphics 500 UHD-Graphics 620		
Main memory	4 GB / 8 GB		M: 4 GB / 8 GB i5: 16 GB		
Data memory		64 GB - 256 GB	}		
Operating system	none none / PXE Boot Windows™ 10 2019 LTSC / Windows™ 10 2021 LTSC IGEL OS				
Note on operating system	IGEL OS: pre-installed without licence				
Image	Windows™ 10 2019 LTSC 64- bit Windows™ 10 2019 LTSC 64- bit Remote HMI Firmware V6 Windows™ 10 2019 LTSC 64- bit Movicon 11 Windows™ 10 2021 LTSC 64- Bit Remote HMI Firmware V7 IGEL OS				

Ethernet note	TX	Optionally:			
		E-Box Standard with 1TX	-		
			X or 1TX and 1FX or 1TX and or 1TX and		
Ethernet / Data	10/100/1000BaseTX	E-Box Standard 10/100/1000BaseTX	-		
		1x 10/100/1000E 1x 10/100/1000B	x 10/100/1000BaseTX, BaseTX + 1 x 100BaseFX, aseTX + 2 x 1000BaseSX, baseTX + 2 x 1000BaseLX		
Data cable	CAT5 / 7 AWG23	FX / SX: FO cable	AT5 / 7 AWG23 50/125 μm or 62.5/125 μm cable 9/125 μm		
Length of data cable	100 m	TX: 100 m FX / SX 50 µm: 500 m FX / SX 62.5 µm: 300 m LX: 10 km			
Interface medium	CAT5 / 7 data transmission	TX: CAT5 / 7 data transmission FX / SX: Multi-mode optical cable LX: Single mode optical cable			
Note on data cable	Ex e Screw terminals	TX: Ex e	e Screw terminals		
Plug version FO	-	LC duplex socket			
USB interface	E-Box PRO: 2x USE	2x USB Ex ia (for keyboard, pointing device) 1x USB Ex ib (for USBi drive) 1x USB Ex e (LS/FS/HS 500 mA)			
Plug version USB X8		1x USB-A connec	tor		
USB standard		USB 2.0, 480 Mbi	t/s		
Note on USB interfaces	The USB interfaces are based on the USB 2.0 standard. Ex-protection measures may result in a deviation from the standard (transfer rate or supply current).				
Serial interface	1x RS	S-232 / RS-422 / RS-48	5 switchable		
Further connections		Terminals for on/off b	putton		
Status displays	LED's - device is live / power supply OK (orange) - device in operation (white) - access to system disk (white) - Ethernet link established / activity (white)				



When using the fibre optic interfaces of ORCA devices, they must be connected and safely operated with other devices that comply with the limit values of Class 1 according to IEC 60825-1 or are classified as inherently safe optical radiation "op is" according to IEC 60079-28.

Battery	> 5 years				
Capacitor buffer	approx. 4 days				
RFID reader	-	optionally integrated C8			
RFID reader chip type	-	NXP CLRC663			
RFID operating frequency	-	13.56 MHz (HF)			
RFID reading distance	-	<= 50 mm (depending on transponder)			
Supported transponder media	Standard	Transponder media			
	ISO 14443 A and compatible	MIFARE® Classic Mini / 1K /4K MIFARE Ultralight®, MIFARE Ultralight® C MIFARE® DESFire®EV1, MIFARE® Smart MX MIFARE® Plus S / X MIFARE® Pro X NTAG 21x			
	ISO 14443 B and compatible	SRI4K SRIX4K AT88RF020 66CL160S SR176			
	ISO 15693 and compatible	EM4135 EM4043 EM4x33 EM4x35 I-Code SLI / SLIX M24LR16/64 TI Tag-it HF-I SRF55Vxx (my-d vicinity)			
	ISO 18000-3M3	I-Code ILT-M			



Battery

- The self-discharge of the battery at room temperature is very low (<1%) but doubles for each additional 10 °C (25 °C = 1%/a >> 35 °C = 2%/a >> 45 °C = 4%/a ... 65 °C = 16%/a).
- In the case of permanently high temperatures, this self-discharge needs to be taken into account for any life cycle considerations.
- The cumulative time for which a battery is operated at 70 °C across its entire life cycle should not exceed 10 days.

17.1.2.1 Electrical data - device protection



Fuse

• For the external fuse protection of the ORCA device supply, R. STAHL HMI Systems GmbH recommends fuses with the following characteristic values.

Function / Equipment	E-Box Standard	E-Box PRO DC	E-Box PRO AC	
Rated Current	2.5 A	4 A	1.25 A	
Rated Voltage (minimum)	32 VDC	32 VDC	250 VAC	
Breaking capacitiy	1500 A			
Melting integral (I ² t)	≥ 2 A²s	≥ 10 A ² s	≥ 0.8 A ² s	

17.1.3 Display

Function / Equipment	E52A M52A	E54A M54A	E59A M59A		
Display-Version	TFT colour display				
Display version 2	16.7 million colours	16.2 million colours	16.7 million colours		
Display size inch	12.1	15.6	21.5		
Display size cm	30.7	39.6	54.6		
Display resolution (supported)	1280 x 800 (native) 800 x 600 800 x 480 640 x 480	1280	80 (native) k 1080 k 1024 x 768		
Display dimensions	16:10	16	3:9		
Display brightness	400 cd/m ²	450 cd/m ²	350 cd/m ²		
Display contrast	1:800	1:1	000		
Backlight	LED technology				
Life expectancy backlight		50,000 h at +25 °C			
Sensors	- 4				
Touchscreen	yes				
Touch screen technology	projected, capacitive (PCAP), multi-touch				
Touchscreen activation	Touch, no activation pressure required				
Touchscreen input method	Fin	gers, thin glove or special (glove		
Touch screen durability		very good			
Touchscreen resistance to scratching MoHS scale		>5			
Touchscreen resistance to scratching pencil hardness test ISO 15184	9H				
Touchscreen transmissivity / optics	very good				
Touchscreen surface contaminants	unaffected (however, can be affected by conductive fluids such as saltwater)				
Touchscreen abrasion resistance	no abrasion by finger or rubber				
Front plate	Glas, polyester on powder-coated aluminium				
Glass pane	hardened, impact-resistant				
Glass pane impact energy	4 J from a height of 40 cm				

17.1.4 Ambient conditions

Function / Equipment	PM E52A PM M52A	PM E54A PM M54A	PM E59A PM M59A	OS E59A OS M59A	
Operating temperature range	-20 °C +55 °C -20 °C +50				
Storage temperature	-40 °C +60 °C				
Relative humidity	10 to 90% at +40°C [+104 °F], non-condensing				
Heat dissipation	corresponds to the rated operating power of 27 - 60 W (92 - 205 BTU)				
Vibration (sinusoidal)	5 to 13.2 Hz: ±1 mm 13.2 to 100 Hz: ±0.7 g X, Y, Z axes				
Shock	15 g / 11 ms				
Pressurised operation	< = 20 mbar				
Altitude	for use up to 2000 m above sea level				

17.1.5 Mechanical data

Function / Equipment	PM E52A PM M52A	PM E54A PM M54A	PM E59A PM M59A	OS E59A OS M59A	
Dimensions (W x H)	330 mm x 241 mm	415 mm x 310 mm 565 mm x 400 mm		708 mm x 524 mm	
Total depth (D)	101 mm	with E-Box Star	ndard:108 mm	176 mm	
		with E-Box Pf	RO: 117 mm		
Wall cut-out (W x H)	310 mm x 221 mm	396 mm x 291 mm	547 mm x 382 mm	-	
Cut-out tolerances	+1.0 mm	/ -0.5 mm	+-0.5 mm		
Depth of cut-out (D)	92 mm	with E-Box	Standard:	-	
		98 mm	99 mm	-	
		with E-Box Pf	RO: 108 mm	-	
Dimensions with keyboard (W x H x D)		-		708 mm x 794 mm x 404 mm	
Enclosure design		-		Cleanroom suitability	
Weight					
with E-Box Standard	ET = 10 kg $MT = 7 kg$	ET = 15 kg MT = 9 kg	ET = 21 kg MT = 15 kg	ET = 41.5 kg MT = 35.5 kg	
with E-Box PRO	-	ET = 19 kg MT = 11 kg	ET = 25 kg MT = 17 kg	ET = 45.5 kg MT = 37.5 kg	
Material (front)	Glas, polyester on powder-coated aluminium			Stainless steel, glass and polyester on powder-coated aluminium	
Material (back)		Aluminium		Stainless steel	
Degree of protection (IP)		IP66, Ex-enclosure	protection type IP65		
Front enclosure protection type (IP)		IP66, Ex-enclosure	protection type IP65		
Enclosure back protection type (IP)	IP66, Ex-enclosure protection type IP65				
Mounting option	Panel mount			Wall-mounting or mounted on stand / elbow	
Mounting orientation		-			
Wall thickness of installation wall	1.5 – 12 mm			-	

17.2 Technical data E/M79A

17.2.1 General

Function / Equipment	PM E79A PM M79A	OS E79A OS M79A		
Technology	Direct Monitor			
E-Box	PRO			
HMI-type	Panel-mount device Operator Station			
Enclosure type	- ORCA OS enclosure OF			

17.2.2 Electrical data

Function / Equipment	E79A M79A		
Power supply	24 VDC or 230 VAC		
AC rated operational voltage	230 V		
Voltage range AC	100 V - 240 V (+4.1 % / -15 %)		
DC rated operational voltage	24 V		
Voltage range DC	24 V (+30 % / -20 %)		
Power consumption AC	1 A		
Current consumption DC	3 A		
Frequency range	47 – 63 Hz		
Rated operational power	27 – 60 W		
internal fuses AC	2 A		
internal fuses DC	6.3 A		
Terminal box	Power supply direct in integrated connection box (separate Ex e and Ex i compartments)		
Connections	via screw terminals, green		
Conductor type	Flexible conductors 0.2 to 2.5 mm² (AWG24 to AWG12) rigid conductors 0.2 to 2.5 mm² (AWG24 to AWG12) (details see chapter 8.5.8 Electric connections of interfaces X1, X2, X3, X4, X5, X6, X7, X9, X10, X11, X12 and X13)		
max. operating voltage Um	250 V AC		
Status displays	LED's - device is live / power supply OK (orange) - device in operation (white)		

17.2.2.1 Electrical data - device protection



Fuse

• For the external fuse protection of the ORCA device supply, R. STAHL HMI Systems GmbH recommends fuses with the following characteristic values.

Function / Equipment	E-Box PRO DC	E-Box PRO AC
Rated Current	4 A	1.25 A
Rated Voltage (minimum)	32 VDC	250 VAC
Breaking capacitiy	150	00 A
Melting integral (I2t)	≥ 10 A²s	≥ 0.8 A²s

17.2.3 Display

Function / Equipment	E79A M79A		
Display-Version	TFT colour display		
Display version 2	16.7 million colours		
Display size inch	21.5		
Display size cm	54.6		
Display resolution	1920 x 1080 (native)		
Display dimensions	16:9		
Display brightness	350 cd/m ²		
Display contrast	1:1000		
Backlight	LED technology		
Life expectancy backlight	50,000 h at +25 °C		
Sensors	4		
Touchscreen	yes		
Touch screen technology	projected, capacitive (PCAP), multi-touch		
Touchscreen activation	Touch, no activation pressure required		
Touchscreen input method	Fingers, thin glove or special glove		
Touch screen durability	very good		
Touchscreen resistance to scratching MoHS scale	>5		
Touchscreen resistance to scratching pencil hardness test ISO 15184	9H		
Touchscreen transmissivity / optics	very good		
Touchscreen surface contaminants	unaffected (however, can be affected by conductive fluids such as saltwater)		
Touchscreen abrasion resistance	no abrasion by finger or rubber		
Front plate	Glas, polyester on powder-coated aluminium		
Glass pane	hardened, impact-resistant		
Glass pane impact energy	4 J from a height of 40 cm		

17.2.4 Ambient conditions

Function / Equipment	PM E79A PM M79A	OS E79A OS M79A		
Operating temperature range	-20 °C +55 °C	-20 °C +50 °C		
Storage temperature	-40 °C	. +60 °C		
Relative humidity	10 to 90% at +40°C [+1	10 to 90% at +40°C [+104 °F], non-condensing		
Heat dissipation	corresponds to the rated operating power of 27 - 60 W (92 - 205 BTU)			
Vibration (sinusoidal)	5 to 13.2 Hz: ±1 mm 13.2 to 100 Hz: ±0.7 g X, Y, Z axes			
Shock	15 g / 11 ms			
Pressurised operation	< = 20 mbar			
Altitude	for use up to 2000 m above sea level			

17.2.5 Mechanical data

Function / Equipment	PM E79A PM M79A		OS E79A OS M79A			
Dimensions (W x H)	56	65 mm x 400	mm	565 mm x 400 mm		
Total depth (D)		117 mm			176 mm	
Wall cut-out (W x H)	54	7 mm x 382	mm	-		
Cut-out tolerances		+-0.5 mm				
Depth of cut-out (D)		108 mm			-	
Dimensions with keyboard (W x H x D)	-		708 mm x 794 mm x 404 mm			
Enclosure design	-		Cleanroom suitability		ability	
Weight [kg]	ET MT	= =	25 kg 17 kg	ET MT	=	45.5 kg 37.5 kg
Material (front)	Glas, polyester on powder-coated aluminium Stainless steel, glass and polyester on powder-coated aluminium			and polyester aluminium		
Material (back)	Aluminium Stainless steel			eel		
Degree of protection (IP)		IP66,	Ex-enclosure	protection typ	oe IP65	
Front enclosure protection type (IP)		IP66,	Ex-enclosure	protection typ	oe IP65	
Enclosure back protection type (IP)	IP66, Ex-enclosure protection type IP65					
Mounting option	Panel mount		Wall-mounting or mounted on stand / elbow		ted on stand /	
Mounting orientation	any		-			
Wall thickness of installation wall		1.5 – 12 mm	า	-		

17.3 Cable glands

17.3.1 E-Box Standard


Cable gland	Туре	HSK-M-Ex
Manufacturer		Hummel AG
	Number	2x M16 / 1x M20
	Thread size	M16 x 1.5 / M20 x 1.5
	Clamping range	1x M16 = 4 8 mm / 1x M16 = 5 10 mm / M20 = 6 12 mm
	Width across flats	M16 = SW 17 or SW 19 / M20 = SW 22
Tightening torqu		6 Nm / 5 Nm / 8 Nm
Screw plug	Туре	V-Ms-VMQ-Ex
	Manufacturer	Hummel AG
	Number	5x M16 / 2x M20
	Width across flats	M16 = SW 19 / M20 = SW 22
	Tightening torque	6 Nm / 8 Nm



The documentation from the manufacturer for the cable glands and screw plugs must be taken into account.

The E-Box is fully equipped with screw plugs.

There are 2x M16 / 1x M20 cable glands included as a set.



Item	Designation	
1	Screw plug M20	
2	Screw plug M16	
3	Screw plug M16, space for cable gland 5 10 mm for KB2 keyboard	



Additional cable glands can be ordered as a set (SAP 310903 - Supplemental cable glands kit E-Box STD)

17.3.2 E-Box PRO


Cable gland	Туре	HSK-M-Ex
	Manufacturer	Hummel AG
	Number	6x M16 / 1x M20 / 1x M25
	Thread size	M16 x 1.5 / M20 x 1.5 / M25 x 1.5
	Clamping range	5x M16 = 4 8 mm / 1x M16 = 5 10 mm / M20 = 6 12 mm / M25 = 1418 mm
	Width across flats	5x M16 = SW 17 or SW 19 / M20 = SW 22 / M25 = SW 30
	Tightening torque	6 Nm / 5 Nm / 8 Nm / 12 Nm
Screw plug Type		V-Ms-VMQ-Ex
	Manufacturer	Hummel AG
	Number	7x M16 / 3x M20 / 1x M25
	Width across flats	M16 = SW 19 / M20 = SW 22 / M25 = SW 30
	Tightening torque	6 Nm / 8 Nm / 12 Nm



The documentation from the manufacturer for the cable glands and screw plugs must be taken into account.

The E-Box is fully equipped with screw plugs.

There are 6x M16 / 1x M20 / 1x M25 cable glands included as a set.



Item	Designation
1	Screw plug M25
2	Screw plug M16
3	Screw plug M20
4	Screw plug M16, space for cable gland 5 10 mm for KB2 keyboard



Additional cable glands can be ordered as a set (SAP 310902 - Supplemental cable glands kit E-Box PRO) $\,$

17.4 Overview Hardware Revision ORCA01

HW-Rev.	Device type	Technical modifications	Modification date Hardware	BA version	BA date
01.01.01	ORCA01E* ORCA01M*	Initial	-	01.00.04	17.05.2023

18 Appendix B

18.1 Connection values

Nominal voltage	Input voltage range	Rated frequency	max. power consumption
230 VAC	85 – 250 VAC	47 – 63 Hz	1 A
24 VDC	19.2 – 31.2 VDC	_	3 A

18.2 Intrinsically safe interfaces

18.2.1 X9 PB – on/off button (Ex ia)

X9: PB, on/off button (X9-1), GND (X9-2):

Max. output voltage	Uo	=	5.36	VDC			
Max. output current	lo	=	45	mA			
Max. output power	Po	=	0.061	W			
Trapezoidal output characteristics							
Max. external capacitance	Co	=	64	20	μF		
Max. external inductance	Lo	=	0.89	3.89	μH		

 C_{\circ} and L_{\circ} pairs directly above / underneath each other may be used. For the connection of passive devices only.

18.2.2 X5 / X6 – USB 4/5 (Ex ia)

X5 / X6 – USB 4/5 terminals VBUS (X5/6-1), D- (X5/6-2), D+ (X5/6-3), GND (X5/6-4):

Max. output voltage	Uo	=	5.36	VDC				
Max. output current	lo	=	249	mA				
Max. output power	Po	=	0.55	W				
Trapezoidal output characteristics								
Max. external capacitance	Co	=	65	46	32	25	21	μF
Max. external inductance	Lo	=	1	2	3	4	5	μΗ

 C_{\circ} and L_{\circ} pairs directly above / underneath each other may be used. For the connection of intrinsically safe passive devices only.

18.2.3 X7 / X8 – USB 6 (Ex ib)

X7 – USB terminals VBUS (X7-1), D- (X7-2), D+ (X7-3), GND (X7-4):

Max. output voltage	Uo	=	5.54	VDC				
Max. output current	Ιο	=	0.757	Α				
Max. output power	Po	=	3.9	W				
Trapezoidal output characteristics								
Max. external capacitance	Co	Ш	48.6	33.6	21.6	15.6	11.6	μF
Max. external inductance	Lo	=	1	2	3	4	5	μΗ

 C_{\circ} and L_{\circ} pairs directly above / underneath each other may be used. For the connection of intrinsically safe passive devices only.

X8 – USB A fixed socket

18.3 Optical interfaces

18.3.1 X15 / X16 – FO 1 / FO 2 type FX

Wavelength	=	1310	nm
1			

Optical radiation sources are used in EPL Gb or Gc and Db or Dc, which comply with the Class 1 limiting values according to IEC 60825-1.

18.3.2 X15 / X16 – FO 1 / FO 2 type SX

Wavelength	=	850	nm
Wavelength		000	

Optical radiation sources are used in EPL Gb or Gc and Db or Dc, which comply with the Class 1 limiting values according to IEC 60825-1.

18.3.3 X15 / X16 – FO 1 / FO 2 type LX

Wavelength	=	1310	nm
Wavelength	_	1010	

Optical radiation sources are used in EPL Gb or Gc and Db or Dc, which comply with the Class 1 limiting values according to IEC 60825-1.

18.4 Non intrinsically safe interfaces (Ex e)

18.4.1 X1 – Power supply

Nominal voltage							
Device version AC		=	85 250	VAC			
Device version DC		=	19.2 31.2	VDC			
Nominal current	Nominal current						
Device version AC		=	max. 2	Α			
Device version DC		=	max. 6.3	Α			
Nominal power		=	16 - 60	W			
Max. input voltage	Um	=	250	VAC			
Frequency for AC		=	47 – 63	Hz			

18.4.2 X2 / X10 - copper1 / copper2

Nominal voltage		=	5	VAC / VDC
Max. input voltage	U _m	=	250	VAC
			30	VDC

18.4.3 X3 / X11 / X12 / X13 – USB

Nominal voltage			5	VAC / VDC
Max. input voltage	U _m	=	30	VAC

X11 / X12 / X13: for the connection of passive devices only

18.4.4 X4 – RSxxx

Nominal voltage	II	±12	VAC / VDC	
Max. input voltage	U _m	=	30	VAC

19 Appendix C

19.1 Connection overview terminal assignment

19.1.1 E-Box Standard

19.1.1.1 Ex e terminals

Terminal	Pin	Design	ation	(PC	B) / view	Typical colour coding / plug type	Connection / function
X1	1	+24 V				Red	Power supply of the HMI
POWER	2	+24 V				Red	device DC
	3	0 V				Black	
	4	0 V				Black	
X2		1000Base	e-TX	100	Base-TX		Data cable
LAN 0	1	MDI0+		TX+	-	Orange / White	Copper connection 1
	2	MDI0-		TX-		Orange	
	3	MDI1+		RX+	+	Green / White	
	4	MDI1-		RX-		Green	
	5	MDI2+				White / Blue	
	6	MDI2-				Blue	
	7	MDI3+				White / Brown	
	8	MDI3-				Brown	
Х3	1	VBUS				Red	USB connection
USB 0	2	D -				White	
	3	D +				Green	
	4	GND				Black	
X4		RS-232	RS-4	22	RS-485		Serial interface
SERIAL	1	RTS	TxD-l	A A			(COM) RS-232 / RS-422 / RS-
	2	TxD	TxD-/				485
	3	RxD	RxD-				
	4	CTS	RxD-	A			
	5	GND					

NOTE Connection of components with excessive voltages to X3 USB 0

Non-compliance will trigger internal fuses and lead to failure of the USB interface!

 A self-powered or bus-powered / passive device may be connected.

The voltage at this interface must not exceed the value specified according to USB 2.0. Higher voltage will trigger the fuses!

NOTE

Connection of components with excessive voltage to X4 SERIAL

Non-compliance will trigger internal fuses and lead to failure of the serial interface!

• The voltage at this interface must not go outside the range of -12 V ... +12 V. Higher or lower voltages will trigger the fuses!

19.1.1.2 Ex i terminals

Terminal	Pin	Designation (PCB) / view	Typical coding / p		Connection / function
			General	Cable from KB2	
X5	1	VBUS	Red	White	USB connection for KB2
USB 4	2	D -	White	Green	max. 50 mA
	3	D +	Green	Yellow	
	4	GND	Black	Brown	
X6	1	VBUS	Red	Red	USB connection for KB2
USB 5	2	D -	White	Grey	max. 50 mA
	3	D +	Green	Pink	
	4	GND	Black	Blue	
X7 / X8	1	VBUS	Red		USB connection
USB 6	2	D -	White		(Terminals or sockets)
	3	D+	Green		
	4	GND	Black		
			USB socket Type A		
Х9	1	PWRBTN			On / off button connection
PB	2	PWRBTN RETURN			

NOTE

Short circuit of the terminal connection at X7 / X8 USB 6

Non-compliance will trigger internal fuses and lead to failure of the USB interface !

- You may only connect a bus-powered / passive device that is supplied by the ORCA device via the bus.
- Connect such a device via terminal X7 or the X8 USB terminal.
- Prevent short circuiting of the VBUS and D+ as well as the VBUS and D- terminals. Short-circuiting will trigger the fuses!
- When connected to X7: Ex ib only applies for use in Zone 1/2!



X9 PB terminals

Only connect a passive button.

19.1.2 E-Box PRO

19.1.2.1 Ex e terminals

Terminal	Pin	Designation (PCB) / view		Typical colour coding / plug type	Connection / function	
X1	0	Earth		Green-Yellow	Power supply of the HMI	
POWER	1	+24 V / L		Red / Black	device (either AC or DC)	
	2	+24 V / L		Red / Black	(1	
	3	0V / N		Black / Blue		
	4	0V / N		Black / Blue		
X2 *		1000Base-TX	100Base-TX		Data cable	
LAN 0	1	MDI0+	TX+	Orange / White	Copper connection 1	
	2	MDI0-	TX-	Orange		
	3	MDI1+	RX+	Green / White		
	4	MDI1-	RX-	Green		
	5	MDI2+		White / Blue		
	6	MDI2-		Blue		
	7	MDI3+		White / Brown		
	8	MDI3-		Brown		
X10 *		1000Base-TX	100Base-TX		Data cable	
LAN 1	1	MDI0+	TX+	Orange / White	Copper connection 2	
	2	MDI0-	TX-	Orange		
	3	MDI1+	RX+	Green / White		
	4	MDI1-	RX-	Green		
	5	MDI2+		White / Blue		
	6	MDI2-		Blue		
	7	MDI3+		White / Brown		
	8	MDI3-		Brown		
X15 * FO 1			TX RX	LC duplex connector	Data cable FO connection 1 Type FX (100Base-FX) Type SX (1000Base-SX) Type LX (1000Base-LX)	
X16 * FO 2		TX RX		LC duplex connector	Data cable FO connection 2 Type FX (100Base-FX) Type SX (1000Base-SX) Type LX (1000Base-LX)	

		1			1	
Х3	1	VBUS		Red	USB connection	
USB 0	2	D -		White		
	3	D +		Green		
	4	GND	GND		Black	
X11	1	VBUS			Red	USB connection
USB 3	2	D -			White	(optional - assembly version)
	3	D +			Green	voision,
	4	GND			Black	
X13	1	VBUS			Red	USB connection
USB 1	2	D -			White	
	3	D +			Green	
	4	GND		Black		
X4		RS-232	RS-422	RS-485		Serial interface
SERIAL	1	RTS	TxD-B	В		(COM) RS-232 / RS-422 / RS-
	2	TxD	TxD-A	А		485
	3	RxD	RxD-B			
	4	CTS	RxD-A			
	5	GND				
X12	1	VBUS		•	Red	USB connection
USB 2/A	2	D -			White	(optional - assembly version)
	3	D +	D+		Green	VCISION)
	4	GND		Black		
X12	1	SPK+				Audio connection
USB 2/A	2	-				(optional - assembly version)
	3	-				(for ATOM processor
	4	SPK-				only)



* The Ethernet connection depends on the version ordered.

The LC duplex slots are only available in the FO version.

When using the fibre optic interfaces of MANTA devices, they must be connected and safely operated with other devices that comply with the limit values of Class 1 according to IEC 60825-1 or are classified as inherently safe optical radiation "op is" according to IEC 60079-28.

The board is always fitted with all terminals, but they only have a function if required by the assembly version.

The X12 terminal is always optional and either a USB or an audio connection.



Terminals X13 USB 1 and X11 USB 3

 You may only connect a bus-powered / passive device that is supplied by the ORCA device via the bus.

Terminals X12 USB 2/A

- If fitted with USB module: you may only connect a bus-powered / passive device that is supplied by the ORCA device via the bus.
- If fitted with audio module: you may only connect a passive speaker.

NOTE

Connection of components with excessive voltages to X3 USB 0

Non-compliance will trigger internal fuses and lead to failure of the USB interface!

 A self-powered or bus-powered / passive device may be connected.

The voltage at this interface must not exceed the value specified according to USB 2.0. Higher voltage will trigger the fuses.

NOTE

Connection of components with excessive voltage to X4 SERIAL

Non-compliance will trigger internal fuses and lead to failure of the serial interface!

• The voltage at this interface must not go outside the range of -12 V ... +12 V. Higher or lower voltages will trigger the fuses.

19.1.2.2 Ex i terminals

Terminal	Pin	Designation (PCB) / view	Typical coding / p		Connection / function
			General	Cable from KB2	
X5	1	VBUS	Red	White	USB connection for KB2
USB 4	2	D -	White	Green	max. 50 mA
	3	D +	Green	Yellow	
	4	GND	Black	Brown	
X6	1	VBUS	Red	Red	USB connection for KB2
USB 5	2	D -	White	Grey	max. 50 mA
	3	D+	Green	Pink	
	4	GND	Black	Blue	
X7 / X8	1	VBUS	Red		USB connection
USB 6	2	D -	White		(Terminals or sockets)
	3	D+	Green		
	4	GND	Black		
			USB socket Type A		
Х9	1	PWRBTN			On / off button connection
PB	2	PWRBTN RETURN			

NOTE

Short circuit of the terminal connection at X7 / X8 USB 6

Non-compliance will trigger internal fuses and lead to failure of the USB interface!

- You may only connect a bus-powered / passive device that is supplied by the ORCA device via the bus.
- Connect such a device via terminal X7 or the X8 USB terminal.
- Prevent short circuiting of the VBUS and D+ as well as the VBUS and D- terminals. Short-circuiting will trigger the fuses!
- When connected to X7: Ex ib only applies for use in Zone 1/2!



X9 PB terminals

• Only connect a passive button.

19.1.3 Direct Monitor

19.1.3.1 Ex e terminals

Terminal	Pin	Designation (PCB) / view	Typical colour coding / plug type	Connection / function
X1	0	Earth	Green-Yellow	Power supply of the HMI
POWER	1	+24 V / L	Red / Black	device (either AC or DC)
	2	+24 V / L	Red / Black	(charer 7 to or 2 c)
	3	0V / N	Black / Blue	
	4	0V / N	Black / Blue	
Х3	1	N.C.	Red	USB monitor connection
USB 0	2	D -	White	
	3	D +	Green	
	4	GND	Black	
X2		LAN 0		no function
X4		SERIAL		no function
X10		LAN 1		no function
X11		USB 3		no function
X12		USB 2/A		no function
X13		USB 1		no function



All terminals are located on the board but only terminal X3 is functionally present for the connection of the monitor.

19.1.3.2 Ex i terminals

Terminal	Pin	Designation (PCB) / view	Typical colour coding / plug type	Connection / function
X5		USB 4		no function
X6		USB 5		no function
X7 / X8		USB 6		no function
X9		РВ		no function



All terminals are located on the board but have no function.

20 Appendix D

20.1 Variation of operating temperature range

The devices' operating temperature range is impacted by how they are mounted. The minimum and maximum permitted operating temperature may vary depending on their mounting type.

These values are listed in the table below.

NO	ΤΕ
----	----

Exposure to direct sunlight might contribute to further heating up the device and may result in a further reduction of the maximum permitted operating temperature.

We recommend you protect the device from direct sunlight.

Wind may cool down the device and thus have an impact on the minimum operating temperature.



The storage temperature is not impacted by the type of installation.

The following values apply:

LTC = lower ambient temperature in °C

-20 °C

LTF = lower ambient temperature in °F

+14 °F

HTC = highest permissible ambient temperature in °CHTF = highest permissible ambient temperature in °F

Screen position Inclination		Description	Highest permissible ambient temperature
11A		Landscape, horizontal 90° free standing	HTC = +55 °C HTF = +131 °F
# • • • • •		Landscape, horizontal 45° free standing	HTC = +55 °C HTF = +131 °F
		Landscape, horizontal 0° free standing Minimum distance 10 cm below device	HTC = 55 °C HTF = +131 °F
		Portrait vertical 90°, free standing	HTC = +55 °C HTF = +131 °F

Screen position	Inclination	Description	Highest permissible ambient temperature
		Portrait vertical 45°, free standing	HTC = +55 °C HTF = +131 °F
1120 \$ 0 0 0		Landscape, horizontal Mounted in enclosure any degree of inclination	HTC = +50 °C HTF = +122 °F
		Portrait, horizontal Mounted in enclosure any degree of inclination	HTC = +50 °C HTF = +122 °F

21 Appendix E

21.1 Disposal / restricted substances

Disposal of old electric and electronic devices, packaging and used parts is subject to regulations valid in whichever country the device has been installed.

For countries under the jurisdiction of the EU the corresponding WEEE directive applies.

The devices are classified according to the table below:

Directive	WEEE II Directive 2012/19/EU		
Valid	from 15.08.2018		
Category	SG2 screens, monitors, devices with monitors >100 cm ²		

R. STAHL HMI Systems GmbH meets the requirements of directive 2012/19/EU (WEEE) and is registered under the number DE 15180083.

We shall take back our devices according to our General Terms and Conditions.

21.1.1 Declaration of substances and restricted substances

This declaration is based on the procedure described in the international standard and directives as listed in the table below:

- IEC 62474 : 2018 (DIN EN IEC 62474 : 2019-09)
- (EG) Nr. 1907/2006 (REACH)
- Directive 2011/65/EU (RoHS)
- Resolution MEPC.269(68) "International Maritime Organization" (IMO); particularly "2015 Guidelines for the Development of the Inventory of the Hazardous Materials" (IHM)

21.1.1.1 Declarable substance groups

ECHA Legal Entity UUID of the R. STAHL HMI Systems GmbH: ECHA-a4dd94d5-bcd2-405d-8fdd-010a535d7e87

SCIP number:

Component	Designation	Mass (g)	Declarable Substance Groups and Substances (IEC 62474 database)	CAS No.	Mass %	Exemption (acc. to directive)
CR2032 MFR	Lithium button cell battery	2.8	1,2 Dimethoxyethane (DME) EINECS 203-794-9	110-71-4	over 0.1 by weight	-

21.1.1.2 RoHS directive 2011/65/EC

The devices meet the requirements of RoHS Directive 2011/65/EU.

21.1.1.3 IMO Resolution MEPC.269(68)

The devices meet the requirements of the MEPC.269(68) Resolution of the "International Maritime Organization" (IMO), in particular the "2015 Guidelines for the Development of the Inventory of the Hazardous Materials" (IHM).

22 Appendix F


22.1 Material resistance

This section lists the material resistance to chemicals of ORCA components that may come into contact with the external environment.

The selection of the individual chemicals listed does not claim to be complete.

22.1.1 Material

Item	Designation	Material
1	1 Front plate Aluminium	
2	2 Powder coating Tiger Drylac Series 29	
3	3 Enclosure Aluminium	
4	4 Front plate seal Silicone VMQ	
5	5 Front plate foil MacDermid Autotex XE Polyester	
6	6 Front glass Glass, thermally toughened	



22.1.1.1 Aluminium

Aluminium is relatively corrosion-resistant and very durable in air and water. In air, aluminium forms an oxide layer that protects against corrosion.

There are various lists on the Internet for resistance to chemicals, so that a list can be dispensed with at this point.

22.1.1.2 Powder coating

Chemicals			Resis	stance		
	7 days	1 month	3 months	6 months	9 months	12 months
Ammonia 10 %	moderate	moderate	-	-	-	-
Sodium hydroxide solution 10 %	yes	yes	moderate	-	-	-
Soda 10 %	yes	yes	yes	yes	yes	yes
Acetic acid 10 %	yes	yes	moderate	-	-	-
Lactic acid 10 %	yes	yes	yes	yes	yes	yes
Phosphoric acid 10 %	yes	yes	yes	yes	yes	yes
Nitric acid 10 %	yes	yes	moderate	moderate	-	-
Hydrochloric acid 10 %	yes	yes	yes	moderate	moderate	moderate
Sulfuric acid 32 %	yes	yes	moderate	moderate	moderate	-
Ethanol 96 %	yes	yes	yes	yes	yes	yes
Isopropyl alcohol	yes	yes	yes	yes	yes	yes
Ethyl acetate	no	-	-	-	-	-
Toluene	no	-	ı	-	-	-
Xylene	no	-	ı	-	-	-
Diesel	yes	yes	yes	yes	yes	yes
FAM-Testing fuel	moderate	moderate	moderate	no	no	no
Petrol	yes	yes	yes	yes	yes	yes
Seewater	yes	yes	yes	yes	yes	yes

22.1.1.3 Front plate seal

The VMQ material has very good weathering and ageing resistance, excellent rubber elastic properties and outstanding temperature resistance.

The tables contain an evaluation of the chemical resistance of VMQ to the respective chemical. Unless otherwise stated, the data refer to room temperature.

1	No to little change in properties						
Aluminium phosphate (aqueous solution)	Aluminium sulhate (aqueous solution)	Ammonia (gaseous, hot)					
Ammonia (gaseous, cold)	Ammonium hydroxide (concentrated)	Ammonium phosphate (aqueous solution)					
Arsenic acid	Barium chloride (aqueous solution)	Barium hydroxide (aqueous solution)					
Barium sulphate (aqueous solution)	Barium sulphide (aqueous solution)	Cottonseed oil					
Beer	Boric acid	Calcium chloride (aqueous solution)					
Calcium hydrogen sulphite (aqueous solution)	Calcium hydroxide (aqueous solution)	Dimethyl ether (methyl ether)					
Developing fluid (photography)	Natural gas	Peanut oil					
Vinegar	Acetic acid, 30%	Ethyl alcohol (ethanol)					
Ethylenediamine	Ethylene glycol	Fish oil					

Fluorolube	Freon T-P35	Fyrquel (Cellulube)
Gelatine	Glucose (dextrose)	Glycerine (Glycerol, oil sweet; E422)
Glycol (1,2-diol)	Green sulphate broth	Blast furnace gas
Isobutyl alcohol (isobutanol)	Isopropyl alcohol (isopropanol)	Potassium chloride (aqueous solution)
Potassium cyanide (aqueous solution)	Potassium dichromate (aqueous solution)	Potassium copper cyanide (aqueous solution)
Potassium nitrate (aqueous solution)	Potassium sulphate (aqueous solution)	Lime-Sulphur Solution
Carbon dioxide	Carbon monoxide	Coconut oil
Copper chloride (aqueous solution)	Copper cyanide (aqueous solution)	Copper sulphate (aqueous solution)
Glue (DIN 16920)	Linseed oil	Magnesium chloride (aqueous solution)
Magnesium sulphate (aqueous solution)	Maize oil	Methyl alcohol (methanol)
Methyl ether (dimethyl ether)	Milk	Lactic acid (cold)
Monomethyl ether	Sodium borate (aqueous solution)	
Sodium bicarbonate	Sodium bisulphite	Sodium chloride
(aqueous solution)	(aqueous solution)	(aqueous solution)
Sodium cyanide	Sodium sulphate	Sodium thiosulphate
(aqueous solution)	(aqueous solution)	(aqueous solution)
Nickel chloride (aqueous solution)	Nickel sulphate (aqueous solution)	Ozone
Propyl alcohol (propanol)	Castor oil	Cane sugar liquid
Beet sugar liquid	Sacharose solution (cane sugar)	Salt water
Oxygen (cold)	Soap solution	Mustard gas
Silver nitrate	Soda ash, free of water of crystallisation	Soya oil (soybean oil)
Spirit	Nitrogen	Water
Tartaric acid	Whiskey and wine	Zinc chloride (aqueous solution)
Zinc sulphate (aqueous solution)	Citric acid	

Minor to moderate change in properties					
Waste water (according to DIN 4045)	Acetaldehyde	Acetamide (acetic acid amide)			
Acetylene (ethyne)	Acrylic acid ethyl ester	Aluminium chloride (aqueous solution)			
Aluminium chloride (aqueous solution)	Aluminium fluoride (aqueous solution)	Aluminium nitrate (aqueous solution)			
Formic acid (methanoic acid)	Ammonium nitrite (aqueous solution)	Malic acid			
Benzaldehyde (artificial bitter almond oil)	Benzyl alcohol	Bleach solution			
Lead nitrate (aqueous solution)	Lead sulphamate (aqueous solution)	Borax solution (disodium tetraborate)			
Bordeaux blend	Bunker oil	Butter (animal fat)			
Butyl alcohol (butanol)	Calcium hypochlorite (aqueous solution)	Calcium nitrate (aqueous solution)			
Calcium sulphide (aqueous solution)	Carbitol (ethyl diglycol)	Chlorox (sodium hypochlorite)			
Decan	Diacetone alcohol (Diacetol)	Dibutyl phthalate (DBP)			
Dibutyl sebacate (DBS)	Diethylamine	Diethylene glycol (digol)			
Diethylsebacate	Dimethylformamide (DMF)	Iron(III) chloride (aqueous solution)			
Iron(III) sulphate (aqueous solution)	Acetic acid, glacial acetic acid	Ethanolamine (aminoethanol) (MEA)			
Ethyl acetate (ethyl acetate)	Ethyl acetoacetate	Formaldehyde (RT) (methanal)			
Fumaric acid	Generator gas	Tannic acid (tannin)			
n-Hexaldehyde	Hexanol	Cod liver oil			
Lime bleach	Cobalt dichloride (aqueous solution)	Carbon dioxide			
Coke oven gas	Lard (animal fat)	Lye (alkali lye)			
Linoleic acid	Lactic acid (hot)	Mineral oil			
Monoethanolamine	Sodium hydroxide (aqueous solution)	Sodium hypochlorite (aqueous solution)			
Sodium perborate (aqueous solution)	Octyl alcohol (octanol)	Oxalic acid (ethanedioic acid, clover acid)			
Petroleum (< 121°C)	Vegetable oil	Phosphoric acid (20%)			
Pyrrole	Salmiak (ammonium chloride)	Nitric acid (diluted)			
Oxygen (93 - 204 °C)	Sulphur dioxide (liquid under pressure)	Sulphur dioxide (wet)			
Sulphur dioxide (dry)	Sulphur hexafluoride	Sulphur trioxide			
Stearic acid (octadecanoic acid)	Tar, Bituminous	Animal fats			
/		1			

Tin dichloride	Tin tetrachloride
(aqueous solution)	(aqueous solution)

Moderate to strong change of properties				
Acetone	Acetyl chloride (acetic acid chloride)	Ammonia, anhydrous		
Aniline dye	Benzoic acid (E 210)	Hydrogen cyanide		
Chromic acid	Dibenzyl sebacate	Dibutylamine		
Dioctyl phthalate (DOP)	Dioctyl sebacate (DOS)	Diphenyl oxide		
Dowtherm oil	Iron(III) nitrate (aqueous solution)	Acetic anhydride		
Ethyl cellulose	Ethylene chlorohydrin	Ethyl mercaptan (ethanethiol)		
Fatty acids	Freon TA	Freon TMC		
Hydraulic oils (mineral oil based)	Hydrazine (diamide, diazane)	Potassium hydroxide (aqueous solution)		
Lindol (hydraulic fluid)	Methyl butyl ketone (propylacetone)	Olive oil		
Petroleum gas, liquid (LPG)	Phosphoric acid (45%)	Propyl acetone (methyl butyl ketone)		
Hydrochloric acid (cold) 37	Sulphur	Sulphur chloride (aqueous solution)		
Hydrogen sulphide (wet, cold)	Hydrogen sulphide (wet, hot)	Silicone grease		
Radiation	Tricresyl phosphate (TCP)	Trioctyl phosphate		
Water vapour (< 149 °C)	Hydrogen gas			

Not recommended				
Acetophenone	Acrylonitrile	Aluminium acetate (aqueous solution)		
Amylacetate (acetic acid amyl ester)	Amyl alcohol (pentanol)	Amylchloronaphthalene		
Amylnaphthalene	Aniline (aminobenzene)	Aniline hydrochloride		
Asphalt	Banana oil (amyl acetate)	Pickling solution		
Petrol (nitrobenzene, ligroine)	Benzene	Benzenesulfonic acid		
Benzyl chloride	Biphenyl (diphenyl, phenylbenzene)	Lead acetate (aqueous solution)		
Bromine, anhydrous	Bromobenzene	Bromine trifluoride		
Bromine water	Hydrobromic acid	Hydrobromic acid (40%)		
Butadiene	Butane	Butyl acetate (acetic acid butyl ester)		
Butylamine	Butylene (Buten)	Butylethyldiglycol (CARBITOL)		
Butyraldehyde (Butanal)	Calcium acetate (aqueous solution)	Carbolic acid (phenol)		
Cellosolve (ethylene glycol ether)	Cellosolve acetate (glycol acetate)	China Wood Oil (China Tung Oil)		

Chlorine, wet	Chlorine, dry	1-Chloro-1-nitroethane	
Chloroacetone	Chlorobenzene	Bromochloromethane	
Chlordodecane	o-Chlornaphthalene	Chloroform (trichloromethane)	
Chloroprene (chlorobutadiene)	Chlorosulphuric acid (chlorosulphonic acid)	Chlorotoluene	
Chlorine trifluoride	Cumene (Isopropylbenzene)	Cyclohexane (hexamethylene)	
Cyclohexanol (hexahydrophenol, anol)	Cyclohexanone (Pimelin Ketone, Anon)	p-Cymene (Cymol)	
Decalin (decahydronaphthalene)	Diacetone	Dibromoethylbenzene	
Dibutyl ether	o-Dichlorobenzene	Dichloroisopropyl ether	
Diesel oil	Diethylbenzene	Diisobutylene (Isooctene)	
Diisopropyl ketone	Diisopropylidene acetone (Phoron)	Dimethylaniline (xylidine, aminoxylol)	
Dinitrotoluene (DNT)	Dioxane	Dioxolan (glycol methyl ether)	
Dipentene (paint solvent)	Diphenyl (biphenyl, phenylbenzene)	Epichlorohydrin	
Ethan	Ethyl benzoate	Ethylbenzene	
Ethyl cellosolve (glycol diethyl ether)	Ethyl chlorocarbonate	Ethyl chloroformate	
Ethyl chloride (chloroethane)	Ethylene chloride	Ethylene dichloride (1,2-dichloroethane)	
Ethylene oxide (oxirane, epoxy)	Ethylene trichloride	Ethyl ether (diethyl ether)	
Ethyl oxalate	Ethylpentachlorobenzene	Fluorine (liquid)	
Fluorobenzene	Hydrofluoric acid, conc. (cold)	Hydrofluoric acid, conc. (hot)	
Hydrofluoric acid, anhydrous	Freon 11 (trichlorofluoromethane)	Freon 12 (dichlorodifluoromethane)	
Freon 13 (chlorotrifluoromethane)	Freon 13B1	Freon 21 (dichlorofluoromethane)	
Freon 22 (chlorodifluoromethane)	Freon 112	Freon 113 (trichlorotrifluoroethane)	
Freon 114 (dichlorotetrafluoroethane)	Freon 114B2	Freon BF	
Freon MF	Freon TC	Freon TF	
Freon T-WD602	Furfural (Furfurol)	Electroplating solution for chrome	
Galvanising solution for other metals	Halowax oil	Hexafluorosilicic acid	
Hexane	n witches-1	lodine pentafluoride	
Isooctane	Isophorone	Isopropyl acetate	
Isopropyl chloride	Isopropyl ether	Potassium acetate (aqueous solution)	

Paraffin (illuminating petroleum; DIN 51636)	Carbon disulphide (carbon disulphide)	Carbon tetrachloride	
Coal tar (creosote)	Aqua regia	Creole acid	
Creosote coal tar	Kresol (methylphenol)	Copper acetate (aqueous solution)	
Lacquer	Lacquer (cellulose lacquer)	Lacquer (solvent)	
Lavender oil	Ligroin (nitrobenzene)	Mesityl oxide	
Methane	Methyl acetate (methyl acetate)	Methyl acrylate	
Methyl cellosolve (methylene glycol ether)	Methyl chloride (monochloromethane)	Methylene chloride (dichloromethane)	
Methyl ethyl ketone (MEK)	Methyl isobutyl ketone (MIBK)	Methyl methacrylate (MMA)	
Methylpentane	Monochlorobenzene	Naphtha	
Naphthalene (naphthalene)	Naphthenic acid	Sodium acetate (aqueous solution)	
Sodium nitrate (aqueous solution)	Sodium peroxide (aqueous solution)	Sodium phosphate (aqueous solution)	
Neville Winther Acid	Nickel acetate (aqueous solution)	Nitrobenzene	
Nitrobenzene (petroleum ether)	Nitroethane	Nitromethane	
Octachlorotoluene	Octadecan	n-octane	
Oleic acid	Palmitic acid (n-hexadecanoic acid)	Paraffin oil (white oil)	
Perchloric acid	Petroleum (> 121°C)	Phenol (carbolic acid)	
Phenylbenzene	Phenylethylether	Phoron (diisopropylidene acetone)	
Picric acid (2,4,6-trinitrophenol)	Pinen	Piperidine (hexahydropyridine)	
Propane	i-Propyl acetate	n-Propyl acetate (acetic acid propyl ester)	
Propyl nitrate	Propylene (propene)	Propylene oxide	
Pyridine	Rapeseed oil	RJ-1 (Mil-F-25558B)	
RP-1 (Mil-R-25576C)	Nitric acid (concentrated)	Nitric acid (red, fuming)	
Hydrochloric acid (hot) 37	Lubricating oil, petroleum	Sulphuric acid (20% oleum)	
Sulphuric acid (diluted)	Sulphuric acid (concentrated)	sulphurous acid	
Silicate ester	Nitrogen tetroxide	Styrene, monomer (phenylethylene)	
Sulphite lye	Turpentine	Tetrabromoethane	
Tetrabromomethane (carbon tetrabromide)	Tetrachloroethylene (Per)	Tetrahydrofuran (THF)	
Tetralin (tetrahydronaphthalene)	Titanium tetrachloride	Toluene diisocyanate (TDI)	

Toluene (methylbenzene)	Fuel oil	Tributyl mercaptan
Tributyl phosphate (TBP)	Trichloroethane	Trichloroethylene (Trichloroethene, Tri) (TCE)
Tung oil (China wood oil)	Turbine oil	Unsymmetrical dimethylhydrazine (UDMH)
Water vapour (> 149 °C)	Xylene (xylene, dimethylbenzene)	Xylidine (aminoxylene, dimethylaniline)
Zinc acetate (aqueous solution)		

Other properties

Property	Typical value	Test method
Hardness	Shore A 50 ± 5	ASTM D 2240
Compression set (24 h / 175 °C)	18%	ASTM D 395/B
Operating temperature (air)	-50 °C to +190 °C	
Flame class	V-0	UL 94 / IEC 60695-11-10

22.1.1.4 Front plate foil

The front plate foil contains a UV-absorbing chemical that greatly increases resistance to yellowing and premature embrittlement in outdoor applications.

With continuous contact with chemicals, some chemicals begin to remove the UV absorber, reducing its UV resistance.

The front plate foil will withstand exposure to the following chemicals for 5 hours without significant visible change or loss of UV resistance. For longer durations, both the visual appearance (colour) and UV resistance may be affected.

	Resistance of 5 hours				
Diesel	Ammonia 2 % *	Acetic acid 5 %	Cutting oil	Hydraulic oil	
Glycerine	Sodium hydroxide *	Hydrochloric acid 10 %	Paraffin oil	Salt water	
White spirit *	Potassium carbonate solution *	Nitric acid 10 %	Pure turpentine	Water	
SBP 60/95 *	Potassium ferricyanide	Phosphoric acid ≥30 %	Linseed oil		
Spirit	Sodium carbonate solution *	Sulphuric acid 10 %	Castor oil		

^{*} Extremely faint texture sheen was noted on contact with these chemicals.

Contact with the following chemicals under the above conditions will result in a slight sheen to the texture and a reduction in the UV resistance of the product.

Chemicals			
1.1.1. trichloroethane *	Ethyl acetate	Methanol	
Acetaldehyde	Formaldehyde solution	Methyl ethyl ketone	
Acetone	Formic acid 50 %	Toluene *	
Cyclohexanol	Glycol	Xylene *	
Cyclohexanone	Industrial methylated spirit		
Ether	Isopropyl		

^{*} A white stain was observed on the film surface upon contact with these chemicals.

The front panel film withstands exposure to the following household chemicals for 5 hours at 50 °C.

Chemicals			
Bleach / Toilet Cleaner	Cleaner for hard surfaces	Cleaning fluid	
Cream cleanser	Washing powder solutions	Window cleaner	
Fabric softener	Washing-up liquid	Tomato ketchup	

The front panel film is **NOT** resistant to the following chemicals:

Chemicals		
Benzyl alcohol	Concentrated mineral acids	High pressure steam above 100 °C
concentrated lye	Methylene chloride	

More features

Property	Typical value	Test method
Haze:		ASTM D1003
Fine	58% ± 5%	
Velvety	71% ± 5%	
Total light transmittance	92% ± 2%	ASTM D1003
Gloss level (60°):		ASTM D2457
Fine	7 ± 1.5 GU	(modified
Velvety	4.5 ± 1 GU	according to test method 022)
Yellowness index	< 5	ASTM E313
Adhesion of the hard coating	passed	Test method 080
Lifetime	> 5 million operations	Test method 003
Tensile strength at break	172 – 190 N/mm²	ASTM D882
Breakdown voltage:		ASTM D149
150 µm	16 - 18 kV	
200 μm	18 - 20 kV	
Dimensional stability	0.2% maximum shrinkage MD at 120 °C	Test method 094
Thickness all types	Nominal ± 10%	Test method 096
Maximum processing temperature	120 °C	
Maximum operating temperature	85 °C	Test method 012
(Low humidity < 10% RH)		
Maximum operating temperature (High humidity 85% RH)	85 °C	Test method 012
Minimum operating temperature	-40 °C	Test method 012

22.1.1.5 Front glass

Glass has a fairly high resistance to most liquids or gases. Only hydrofluoric acid is able to attack glass. A reaction occurs when aqueous solutions come into contact with the glass surface.

Characteristics

- unadulterated colour perception
- reflection-free view
- improved light transmittance
- hard, corrosion-resistant multi-layer coating

22.2 Coating compatibility

Function / Equipment	PM E52A PM M52A	PM E54A PM M54A	PM E59A PM M59A	OS E59A OS M59A
Material P1		VMQ		-
Material P2		-		HokoFLEX®
Material usage P1		Front plate seal		-
Material usage P2	-		Door seal stainless steel enclosure	
Test method	Paint wetting impairment substances according to VDMA 24364			
Paint material	Spray paint LLS 0U3 B9A (Candy white)) Spray pain		Spray paint L 090 E03 (Alpine white)	
Product group	С			
Test class	C 2 - Blow-off			
Test result	no surface disturbances			

23 Appendix G

23.1 Defective pixels

As a result of the manufacturing process (production tolerances and errors) for the displays they may be delivered with defective pixels. These potential defective pixels are not a display or HMI error or defect, provided they are within the range of the specification below.

23.1.1 Terminology

Defective pixels Pixels or sub-pixels that do not perform as expected and are either always on

or always off

Pixel Image point on the display consisting of 3 sub-pixels in the basic colours red,

green and blue

R G B

Dot Sub-pixel in the basic colour red, green or blue

R

or

G

or

В


Bright Sub-pixel (dot) to which light is passing through, creating a bright dot that is on

Dark Sub-pixel (dot) to which no light is passing through, creating a dark dot that is

off


Adjacent dots

Dots positioned next to one another, horizontally, vertically or diagonally, bright or dark (e.g. the following pattern and sub-pixels)



Distance between Dots

Definition of distance between two defective dots horizontal, vertical or diagonal, bright or dark (e.g. the following pattern and sub-pixels)



23.1.2 Display specification

Type of defect / description	max. number of permitted defects		
	12" display	15" display	22" display
Linear defect (horizontal, vertical)		not acceptable	
Defective pixels			
bright dots	≤ 2	≤ 2	≤ 2
dark dots	≤ 3	≤ 3	≤ 5
total number of dots	≤ 3	≤ 5	≤ 5
adjacent dots			
2 bright dots	≤ 0 pairs	≤ 1 pairs	≤ 1 pairs
more than 3 bright dots	not acceptable		
2 dark dots	≤ 1 pairs	≤ 1 pairs	≤ 2 pairs
more than 3 dark dots		not acceptable	
Distance between the dots			
between 2 bright dots	not defined	not defined	not defined
between 2 dark dots	not defined	not defined	not defined
between 1 bright and	not defined	not defined	not defined
1 dark dot	Hot delilled	Hot delined	not denned
ND filter for mura effects, bright and dark dots	not defined	not defined	5 %

23.2 Optical specification front glass

For glass with a surface of >0.1m² to ≤ 0.35 m²

Type of defect / description	Value	Corresponds to specification on the basis of DIN10110		
Largest point defect	max. 0.4 mm ²	0.63 - 1 mm		
max. number		7		
additional small point defects	max. 0.16 - 0.4 mm ²	0.4 - 0.63 mm		
max. number		7		
In general, any number of point defects smaller than the following specified surface are always permitted, that is, they are not considered to be defects.				
Surface	< 0.16 mm ² < 0.4 mm			
Scratches				
max. Width	0.16 mm			
max. Number	7			
max. Length	42	mm		
Cumulative length of all scratches	42 mm			
In general, any number of scratches narrower than the following specified width are always permitted, that is, they are not considered to be defects.				
Width	< 0.16 mm			
Minimum distance of defects	70 mm			




The defect sizes are listed here as the square root of the surface in mm.

Defect size = $\sqrt{\text{defect length * defect width}}$


23.2.1 Test criteria

Test setup: transmitted light / transmission



Background black / white

Test setup: Reflexion



Tester	Trained, experienced person with normal eyesight
Distance tester to tested object	500 mm
Viewing angle (to surface)	
for transmitted light / transmission	90°
for reflexion	30° - 60°
Lighting	Standard, 800 - 1000 lx standard D50 or D65 light
Test light density	Light table with 500 lux

23.3 Optical acceptance of surfaces

This section covers the acceptance criteria applicable to the minimum requirements for surfaces of devices and components.

The values for imperfection types listed under "tolerance limits" do not constitute a defect or an imperfection of the device or component and must therefore be tolerated.

23.3.1 Optical acceptance glass

Imperfection type	Criterion	Tolerance limits
Total imperfections	Number	max. 3
Cleanness of glass surface	Clearly visible dirt	not permitted
Edge crack / incipient crack	Visible	not permitted
Scratches	Width	up to 0.16 mm
	Length	up to 40 mm
	Cumulative length of all scratches	max. 40 mm
	Long side of glass < 300 mm, distance >	70 mm
	Number	2
	Long side of glass 300 - 600 mm, distance	e > 70 mm
	Number	3
Hairline scratches /	Width	max. 0.05 mm
scraper damage	Length	max. 40 mm
Large point defects	Size	max. 0.4 mm ²
	Number	2
Small point defects	Size	max. 0.16 - 0.4 mm ²
	Number	5
Permitted point defects	Size	< 0.16 mm², provided there is no cluster ***
Interference points	Ø < 0.2 mm	Permitted
	0.2 mm < Ø ≤ 0.6 mm	Permitted provided there is no cluster ***
	$0.6 \text{ mm} < \emptyset \le 1.3 \text{ mm}$	5
	$1.3 \text{ mm} < \emptyset \le 2.0 \text{ mm}$	2
	Ø > 2.0 mm	not permitted
Inhomogeneity *	Minor colour variations	Permitted
White haze **	Only visible in reflection	Permitted
	Not visible when device is in operating position.	Permitted



- * In the case of coated float glass, inhomogeneity in the form of minor colour variations can occur and cannot be prevented by any technical means.
- ** Large, cloudy blemish can be more pronounced towards the centre of the glass, but can also affect larger parts of the glass.
- *** A cluster is an accumulation of more than 7 disregarded, permitted imperfections that occur within an inspected area of a diameter of 40 mm.

23.3.2 Optical acceptance printing

Description	Tolerance limits
Labelling	Clearly legible, minimum stroke weight 0.3 mm
Characters	Clearly legible
Lines and symbols	Interruptions not permitted
Ink coverage	Sufficient if underlying layers and structures not visible
Acutance	+/- 0.15 mm
Edge blurring	+/- 0.15 mm
Print overlap	Possible colour variations in the overlap area are
	permitted
Variations of stroke weight	10 %
Within a shaping print	"Fine" as specified in DIN ISO 2768-1 General tolerance
	class
Between shaping prints	< 400 mm +/- 0.3 mm
	≥ 400 mm +/- 0.5 mm

Imperfection type	Criterion	Tolerance limits
Dirt and dust particle inclusions,	Size	max. 0.16 mm ²
stains, fluff,	Size for weak colour contrast	max. 0.25 mm ²
	Number / 100 cm ²	1
	Minimum distance	80 mm
	Lower limit	0.063 mm ²

23.3.3 Optical acceptance, other surfaces

Definitions

Scratch straight or curved / wavy surface damage
Dents / dings plastic deformation inwards or outwards
Scuff mark without dent "punch mark"-type depression

Surface categories

If not specified otherwise in the drawing, the following applies:

A surface	Surface is frequently viewed, typically the front plate. Surface is in customer's field of vision			
	Colour code			
B surface	Surface is occasionally viewed, typically the sides of the device			
	Colour code			
C surface	Surface is rarely viewed, typically the back or bottom of device			
	Colour code			
D surface	Surface is never viewed, typically the inside of the device			
	Colour code			


Accessories such as stand, wall bracket etc. are termed C surfaces





Imperfection type	A surface	B surface	C surface	D surface
Scratches	max. 1 per side	max. 2 per side	1x up to 100 mm with	permitted
	0.05 – 0.1 mm wide and max. 10 mm long	0.05 – 0.1 mm wide and max. 10 mm long	the grain	
	or	or	and	
	0.01 – 0.05 mm wide and max. 40 mm long	0.01 – 0.05 mm wide and max. 40 mm long	3x up to 15 mm against the grain or	
	only with the grain	only with the grain	1x up to 30 mm against the grain	
Gouges,			max. 2 per side	
depressions	not permitted	not permitted	max. 0.3 mm wide	permitted
(punch-mark-type depression)			max. 3 mm long	Pommoo
Dents / cavities	not permitted	not permitted	not permitted	not permitted
Welding flaws	not permitted	not permitted	not permitted	not permitted
Chatter marks	not permitted	not permitted	not permitted	not permitted
Material flaws	not permitted	not permitted	not permitted	not permitted
Orange peel: surface not homogeneous	not permitted	not permitted	not permitted	permitted


24 Appendix H


24.1 Control Drawing











25 Appendix I

Declarations of conformity

25.1.1 EU

25.1.1.1 ORCA01E

EU Konformitätserklärung

EU Declaration of Conformity Déclaration de Conformité UE



R. STAHL HMI Systems GmbH • Adolf-Grimme-Allee 8 • 50829 Köln, Germany

erklärt in alleiniger Verantwortung, declares in ist sole responsability, déclare sous sa seule responsabilité,

dass das Produkt: that the product: que le produit:

Typ(en), type(s), type(s):

Bedien- und Beobachtungsgeräte Operating and Monitoring Devices Moniteur de commande et de visualisation

ORCA01ETCS3..., ORCA01ETCP3 ... ORCA01ETCS4..., ORCA01ETCP4 ... ORCA01ETCS6..., ORCA01ETCP6 ...

mit den Anforderungen der folgenden Richtlinien und Normen übereinstimmt.

is in conformity with the requirements of the following directives and standards.

est conforme aux exigences des directives et des normes suivantes.

Richtlinie(n)	/ Directive(s) / Directive(s)	Norm(en) / Standard(s) / Norme(s)		
2014/34/UE	ATEX-Richtlinie ATEX Directive Directive ATEX of the EU L96, 29/03/2014, p. 309–356	EN IEC 60079-0:2018 EN 60079-5:2015 EN IEC 60079-7: 2015 + A1:2018 EN 60079-11:2012 EN 60079-31:2014		
Kennzeichnu marking, marq		(Example 2) Il 2(1) G Ex eb ib qb [ib] [ia Ga] IIC T4 Gb II 2(1) D Ex tb [ib] [ia Da] IIIC T115°C Db		
EU Type Exam	erprüfbescheinigung: nination Certificate: xamen UE de type:	UL 23 ATEX 2902X (UL International Demko A/S Borupvang 5A, 2750 Ballerup, Denmark NB 0539)		
2014/35/EU 2014/35/EU 2014/35/EU Official Journal of	Niederspannungsrichtlinie: Low Voltage Directive: Directive Basse Tension: of the EU L96, 29/03/2014, p. 357–374	EN 62368-1 : 2014 + AC : 2015		
2014/30/UE	EMV-Richtlinie EMC Directive Directive CEM of the EU L96, 29/03/2014, p. 79–106	EN 61000-3-2: 2014 EN 61000-3-3: 2013 EN 61000-6-2: 2005 + AC: 2005 EN 61000-6-3: 2007 + A1: 2011 + AC: 2012 EN 61000-6-4: 2007 + A1: 2011 EN 55035: 2017 EN 55032: 2015		
2014/53/EU 2014/53/EU 2014/53/UE Official Journal o	Funkanlagen-Richtlinie Radio Equipment Directive Directive Équipement Radioélectrique of the EU L153, 22/05/2014, p. 62–106	ETSI EN 301489-1 V2.2.3 : 2019-11 ETSI EN 301489-3 V2.1.1 : 2019-01 ETSI EN 300330 V2.1.1 : 2017-02		
2011/65/EU RoHS-Richtlinie 2011/65/EU RoHS Directive 2011/65/UE Directive RoHS Official Journal of the EU L174, 1/07/2011, p. 88–110		EN IEC 63000:2018		

Für spezifische Merkmale und Bedingungen siehe Betriebsanleitung. For specific characteristics and conditions see operating instructions. Pour les caractéristiques et conditions spécifiques, voir le mode d'emploi.

Unterzeichnet für und im Namen von: / signed for and on behalf of: / signé pour et au nom de:

i.V.

R. STAHL HMI Systems GmbH

Köln, 2023-05-15

Alexander Jung

Nabil Benighil

i.V.

Document generated fromTemplate_EGEU_Konf_20150720.docx

Ort und Datum Place and date Lieu et date

Director R&D

Page 1 von / of 1

25.1.1.2 ORCA01M

EU Konformitätserklärung

EU Declaration of Conformity Déclaration de Conformité UE



R. STAHL HMI Systems GmbH • Adolf-Grimme-Allee 8 • 50829 Köln, Germany

erklärt in alleiniger Verantwortung, declares in ist sole responsability, déclare sous sa seule responsabilité,

dass das Produkt: that the product: que le produit:

Bedien- und Beobachtungsgeräte Operating and Monitoring Devices Moniteur de commande et de visualisation

Typ(en), type(s), type(s):

ORCA01MTCS3..., ORCA01MTCS4..., ORCA01MTCS6..., ORCA01MTCP3 ... ORCA01MTCP4 ... ORCA01MTCP6 ...

mit den Anforderungen der folgenden Richtlinien und Normen übereinstimmt. is in conformity with the requirements of the following directives and standards.

Richtlinie(n) / Directive(s) / Directive(s)	Norm(en) / Standard(s) / Norme(s)
2014/34/EU ATEX-Richtlinie 2014/34/EU ATEX Directive 2014/34/UE Directive ATEX Official Journal of the EU L96, 29/03/2014, p. 309–350	EN IEC 60079-0:2018 EN 60079-5:2015 EN IEC 60079-7: 2015 + A1:2018 EN 60079-11:2012 EN 60079-31:2014
Kennzeichnung, marking, marquage:	(€o158 € II 3(1) G Ex ec ib qb [ib] [ia Ga] IIC T4 Gc
EU Baumusterprüfbescheinigung: EU Type Examination Certificate: Attestation d'examen UE de type:	UL 23 ATEX 2902X (UL International Demko A/S Borupvang 5A, 2750 Ballerup, Denmark NB 0539)
2014/35/EU Niederspannungsrichtlinie: 2014/35/EU Low Voltage Directive: 2014/35/EU Directive Basse Tension: Official Journal of the EU L96, 29/03/2014, p. 357–374	EN 62368-1 : 2014 + AC : 2015
2014/30/EU EMV-Richtlinie 2014/30/EU EMC Directive 2014/30/UE Directive CEM Official Journal of the EU L96, 29/03/2014, p. 79–106	EN 61000-3-2: 2014 EN 61000-3-3: 2013 EN 61000-6-2: 2005 + AC: 2005 EN 61000-6-3: 2007 + A1: 2011 + AC: 2012 EN 61000-6-4: 2007 + A1: 2011 EN 55035: 2017 EN 55032: 2015
2014/53/EU Funkanlagen-Richtlinie 2014/53/EU Radio Equipment Directive 2014/53/UE Directive Équipement Radioéle Official Journal of the EU L153, 22/05/2014, p. 62–106	
2011/65/EU RoHS-Richtlinie 2011/65/EU RoHS Directive 2011/65/UE Directive RoHS Official Journal of the EU L174, 1/07/2011, p. 88–110	EN IEC 63000:2018

Pour les caractéristiques et conditions spécifiques, voir le mode d'emploi.

Unterzeichnet für und im Namen von: / signed for and on behalf of: / signé pour et au nom de:

i.V.

R. STAHL HMI Systems GmbH

20231970110 Rev00 Konformitätserklärung ORCA01M.docx

Köln, 2023-05-15 Ort und Datum

Alexander Jung Director R&D

Nabil Benighil Head of Certification

Place and date Lieu et date

Document generated fromTemplate_EGEU_Konf_20150720.docx

i.V.

Page 1 von / of 1

Declaration of conformity for Equipment Compilation

R. STAHL HMI Systems GMBH

Adolf-Grimme-Allee 8 = 50829 Köln / Cologne = Germany



Betriebsanleitung für Gerätezusammenstellung / Instruction Manual for Equipment Compilation:

Diese Betriebsanleitung verweist auf die jeweilige Betriebsanleitung der verbauten Geräte. In den Betriebsanleitungen der verbauten Geräte sind alle sicherheitsrelevanten und für Installation und Betrieb erforderlichen Angaben enthalten.

Für den ordnungsgemäßen Betrieb aller zusammengehörigen Komponenten sind, außer dieser Betriebsanleitung, alle weiteren der Lieferung beigelegten Betriebsanleitungen sowie die Betriebsanleitungen der anzuschließenden Zusatzgeräte zu beachten!

Beachten Sie weiterhin, dass alle Zertifikate der Bediengeräte in einem separaten Dokument zu finden sind, welches im Internet (www.r-stahl.com) zur Verfügung steht.

This Instruction Manual refers to the documents of the devices used. All instructions concerning the installation and safe use of these devices are documented in the attached detailed instruction manuals.

It is important for safe use to follow these instructions as well all instructions of other associated devices!

Please note that all certificates of the operating and monitoring devices are available at (www.r-stahl.com).

Konformitätserklärung für Gerätezusammenstellung / Declaration of Conformity for Equipment Compilation:

Die R. STAHL HMI Systems GmbH erklärt in alleiniger Verantwortung, dass durch die Zusammenschaltung der Geräte, welche im zugehörigen Lieferschein aufgeführt sind, die Gesamtkonformität gemäß Richtlinie 2014/34/EU und 2014/30/EU und ggf. 2014/34/EU und 2014/53/EU gegeben ist.

Des Weiteren verweisen wir auf die jeweilige Konformitätserklärung der bei diesem Zusammenbau verwendeten Geräte. Diese liegen bei bzw. sind in der beiliegenden Betriebsanleitung abgedruckt.

R. STAHL HMI Systems GmbH declares in its sole responsibility that the interconnection of the devices listed in the accompanying delivery note is in conformity with directives 2014/34/EU, 2014/30/EU and, where applicable, 2014/34/EU and 2014/53/EU

Furthermore, we refer to the individual Declarations of Conformity of the devices used, which are attached or are part of the attached operating instructions.

Köln/Cologne, September 2022

S. Zehrer

Production Director

Management:

Philipp Öhler

Carsten Brenner

Jung

Director R&D

R. STAHL HMI Systems GmbH Adolf-Grimme-Allee 8 50829 Köln (Cologne)

F +49 221 76 806-4200 sales.dehm@r-stahl.com Headquarters: Köln Local Court – Court of Registration: Köln HRB 73049 VAT REG No. DE279883744

26 Appendix J

26.1 Release notes

The chapter entitled "Release Notes" contains all the changes made in this version of the Operating Instructions.

Version 01.00.06

- Deletion of all old release notes
- Addition of "Heat dissipation" in "Technical data Ambient conditions"
- Addition of "Altitude" in "Technical data Ambient conditions"
- Correction of type code field system "Digit 20 Additional options" Exchange of value 1 and 2
- Addition of note on "PA / earth connection DC devices connected to X1-3 and X1-4" in the sections "Note on mounting and installation", "General information on electrical connection" and "Grounding the device"
- Addition of information on "Fibre optic interfaces" in section "Technical data E/M5xA" "Electrical data" and in section "Connection overview terminal assignment" "E-Box PRO"
- Addition of information on "Windows 10 IoT Enterprise 2021 LTSC operating system" in section "Operating systems and drivers"
- Addition of "Windows™ 10 2021 LTSC 64-Bit and Remote HMI Firmware V7" in section "Technical data E/M5xA" - "Electrical data"
- Addition of type code field system "Digit 23 / 24 Operating system / image" with "2021 LTSC" and "Remote V7"
- Addition note on X7 "When connected to X7: Ex ib only applies for use in Zone 1/2"
- Correction "Example of type code for field system"
- Correction in table "Available configuration versions"
- Addition of table "Coating compatibility" in Appendix F
- Deletion of cell "Further national certificates" in section "Certificates"
- Correction of CE / ATEX listing in section "Approvals"
- Addition of column "Comment" in table "Approvals"
- Formal changes

R. STAHL HMI Systems GmbH Adolf-Grimme-Allee 8 D 50829 Cologne

T: (Sales Support) +49 221 768 06 - 1200 (Technical Support) +49 221 768 06 - 5000 +49 221 768 06 - 5000 +49 221 768 06 - 4200 E: (Sales Support) sales.dehm@r-stahl.com (Technical Support) support.dehm@r-stahl.com

r-stahl.com

